

A
B
C
D
E
F
G
H
IP
J
K
L
M

SECTION **IP**
INSTRUMENT PANEL

CONTENTS

PRECAUTIONS	2	KICKING PLATE (LH/RH)	13	F
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	2	FOOT REST	13	
Precautions for Battery Service	2	DASH SIDE FINISHER (LH/RH)	13	
Precautions	2	INSTRUMENT DRIVER PANEL LOWER	13	G
PREPARATION	4	STEERING COLUMN LOWER COVER	13	
Special Service Tool	4	COMBINATION METER	13	
Commercial Service Tool	4	COMBINATION SWITCH	13	H
SQUEAK AND RATTLE TROUBLE DIAGNOSES	5	CONSOLE FINISHER (A/T RING) (A/T)	13	
Work Flow	5	SHIFT KNOB (M/T)	14	
CUSTOMER INTERVIEW	5	CONSOLE FINISHER (A/T)	14	IP
DUPLICATE THE NOISE AND TEST DRIVE	6	CONSOLE BOOT (M/T)	14	
CHECK RELATED SERVICE BULLETINS	6	CENTER CONSOLE	14	
LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE	6	INSTRUMENT PASSENGER PANEL LOWER ...	14	J
REPAIR THE CAUSE	6	INSTRUMENT SIDE PANEL	14	
CONFIRM THE REPAIR	7	NAVI SWITCH / SWITCH MASK	14	
Generic Squeak and Rattle Troubleshooting	7	UNIFIED METER AND A/C AMP	15	
INSTRUMENT PANEL	7	CLUSTER LID C	15	K
CENTER CONSOLE	7	DISPLAY	15	
DOORS	7	FRONT PILLAR GARNISH	15	
TRUNK	8	INSTRUMENT DRIVER PANEL UPPER	15	L
SUNROOF/HEADLINER	8	INSTRUMENT PASSENGER PANEL UPPER ...	15	
SEATS	8	INSTRUMENT SIDE FINISHER (RH)	15	
UNDERHOOD	8	INSTRUMENT PANEL	15	M
Diagnostic Worksheet	9	Installation	15	
INSTRUMENT PANEL ASSEMBLY	11	CONSOLE FINISHER (A/T)	15	
Component Parts Drawing	11	CONSOLE BOOT (M/T)	15	
Removal and Installation	12	INSTRUMENT PASSENGER PANEL LOWER ...	16	
WORK STEP	12	Disassembly and Assembly	17	
		CENTER CONSOLE	17	
		CLUSTER LID C	18	

PRECAUTIONS

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

AIS000HQ

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.

Precautions for Battery Service

AIS001PB

This vehicle is equipped with the automatic window adjusting function. When a door is opened, the window automatically lowers slightly to avoid contact between the window and the side roof panel. After the door is closed, the window will automatically raise slightly.

On vehicles equipped with the automatic window adjusting function, lower both the driver and front passenger side windows before disconnecting the battery cables. This will prevent interference between the side window and the roof panel when either door is opened/closed.

CAUTION:

After the battery cables are disconnected, do not open/close the driver and/or front passenger door with the window in the full up position. The automatic window adjusting function will not work and the side roof panel may be damaged.

Precautions

AIS000HR

- Disconnect both battery cables in advance.
- Disconnect air bag system line in advance.
- Never tamper with or force air bag lid open, as this may adversely affect air bag performance.
- Be careful not to scratch pad and other parts.
- When removing or disassembling any part, be careful not to damage or deform it. Protect parts, which may get in the way with cloth.
- When removing parts with a screwdriver or other tool, protect parts by wrapping them with vinyl or tape.
- Keep removed parts protected with cloth.
- If a clip is deformed or damaged, replace it.
- If an un reusable part is removed, replace it with a new one.
- Tighten bolts and nuts firmly to the specified torque.
- After re-assembly has been completed, make sure each part functions correctly.
- Remove stains in the following way.

Water-soluble stains:

Dip a soft cloth in warm water, and then squeeze it tightly. After wiping the stain, wipe with a soft dry cloth.

Oil stain:

Dissolve a synthetic detergent in warm water (density of 2 to 3% or less), dip the cloth, then clean off the stain with the cloth. Next, dip the cloth in fresh water and squeeze it tightly. Then clean off the detergent completely. Then wipe the area with a soft dry cloth.

PRECAUTIONS

- Do not use any organic solvent, such as thinner or benzine.

A

B

C

D

E

F

G

H

IP

J

K

L

M

PREPARATION



PREPARATION

PFP:00002

Special Service Tool



AIS000HS

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
(J-39570) Chassis ear  SIIA0993E	Locating the noise
(J-43980) NISSAN Squeak and Rattle Kit  SIIA0994E	Repairing the cause of noise

Commercial Service Tool

AIS000HT

Tool name	Description
Engine ear  SIIA0995E	Locating the noise
Power tool  PBIC0191E	


SQUEAK AND RATTLE TROUBLE DIAGNOSES

SQUEAK AND RATTLE TROUBLE DIAGNOSES

PPF:00000

Work Flow

AIS000HU



CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [IP-9, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak—(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces=higher pitch noise/softer surfaces=lower pitch noises/edge to surface=chirping
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock—(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on A/T model).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear: J-39565 and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.
Refer to [IP-7, "Generic Squeak and Rattle Troubleshooting"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A NISSAN Squeak and Rattle Kit (J-43980) is available through your authorized NISSAN Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

Always check with the Parts Department for the latest parts information.

The following materials are contained in the NISSAN Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60 × 85 mm (2.36 × 3.35 in)/76884-71L02: 15 × 25 mm (0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-50Y00: 10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

INSULATOR (Light foam block)

SQUEAK AND RATTLE TROUBLE DIAGNOSES

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18 × 1.97 in)

FELT CLOTH TAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used in of UHMW tape that will be visible or not fit.

Note: Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Generic Squeak and Rattle Troubleshooting

AIS000HV

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the NISSAN Squeak and Rattle Kit (J-43980) to repair the noise.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner. In addition look for:

1. Trunk lid dumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINER

Noises in the sunroof/headliner area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headliner and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seat back lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noise can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting securing, or insulating the component causing the noise.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Diagnostic Worksheet

AIS000HW




SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Nissan Customer:

We are concerned about your satisfaction with your Nissan vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Nissan right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to the back of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

SBT843

SQUEAK AND RATTLE TROUBLE DIAGNOSES

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET- page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (check the boxes that apply)

- | | |
|--|---|
| <input type="checkbox"/> anytime | <input type="checkbox"/> after sitting out in the sun |
| <input type="checkbox"/> 1 st time in the morning | <input type="checkbox"/> when it is raining or wet |
| <input type="checkbox"/> only when it is cold outside | <input type="checkbox"/> dry or dusty conditions |
| <input type="checkbox"/> only when it is hot outside | <input type="checkbox"/> other: _____ |

III. WHEN DRIVING:

- ☐ through driveways
- ☐ over rough roads
- ☐ over speed bumps
- ☐ only at about _____ mph
- ☐ on acceleration
- ☐ coming to a stop
- ☐ on turns : left, right or either (circle)
- ☐ with passengers or cargo
- ☐ other: _____
- ☐ after driving _____ miles or _____ minutes

IV. WHAT TYPE OF NOISE?

- ☐ squeak (like tennis shoes on a clean floor)
- ☐ creak (like walking on an old wooden floor)
- ☐ rattle (like shaking a baby rattle)
- ☐ knock (like a knock on a door)
- ☐ tick (like a clock second hand)
- ☐ thump (heavy, muffled knock noise)
- ☐ buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

	<u>YES</u>	<u>NO</u>	<u>Initials of person performing</u>
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: _____ Customer Name: _____

W.O. #: _____ Date: _____

SBT844

This form must be attached to Work Order

INSTRUMENT PANEL ASSEMBLY


INSTRUMENT PANEL ASSEMBLY

Component Parts Drawing

PFP:68200

AIS000HX

A
B
C
D
E
F
G
H
IP
J
K
L
M



PIIA2269E

INSTRUMENT PANEL ASSEMBLY

- | | | |
|--------------------------------------|-----------------------------------|--------------------------------------|
| 1. Instrument panel | 2. Instrument side finisher (LH) | 3. Instrument driver panel upper |
| 4. Display | 5. Combination meter | 6. Instrument driver panel lower |
| 7. Steering lock escutcheon | 8. Steering column lower cover | 9. Fuse cover |
| 10. Dash side finisher (LH) | 11. Foot rest plate | 12. Foot rest |
| 13. Center console | 14. Console finisher (A/T ring) | 15. Console finisher (A/T) |
| 16. Console boot (M/T) | 17. Unified meter and A/C amp | 18. Instrument side panel (LH) |
| 19. Instrument side panel (RH) | 20. Dash side finisher (RH) | 21. Instrument passenger panel lower |
| 22. Knee protector | 23. NAVI switch / Switch mask | 24. Cluster lid C |
| 25. Instrument passenger panel upper | 26. Instrument side finisher (RH) | |

Removal and Installation WORK STEP

AIS000HY

When removing instrument panel, combination meter, audio and display, navigator control unit and console assembly, take steps in the order shown by the numbers below.

CAUTION:

- **Disconnect both battery cables in advance.**
- **Disconnect air bag system line in advance.**
- **Never tamper with or force air bag lid open, as this may adversely affect air bag performance.**
- **Be careful not to scratch pad and other parts.**

Parts	Instrument panel	Combination meter	Audio	Display	Center console
Kicking plate (LH/RH)	1	1			
Foot rest	2	2			
Dash side finisher (LH/RH)	3	3			
Instrument driver panel lower	4	4			
Steering column lower cover	5	5			
Combination meter	6	6			
Combination switch	7				
Console finisher (A/T ring) / Shift knob (M/T)	8		1	1	1
Console finisher (A/T) / Console boot (M/T)	9		2	2	2
Coin holder / Ashtray	10		3	3	3
Center console *1	11		4	4	4
Instrument passenger panel lower	12				
Instrument side panel (LH / RH)	13				
NAVI switch / Switch mask	14		5	5	
Unified meter and A/C amp	15		6	6	
Cluster lid C*2	16		7	7	
Display	17				
Front pillar garnish (LH / RH)	18				
Instrument driver panel upper	19				
Instrument passenger panel upper	20				
Instrument side finisher (RH)	21				
Instrument panel	22				

NOTE:

*1: Console rear pocket and coin holder bracket assembly. Refer to [IP-17, "CENTER CONSOLE"](#).

*2: Audio, cluster lid D, and triple meter assembly. Refer to [IP-18, "CLUSTER LID C"](#)

INSTRUMENT PANEL ASSEMBLY

KICKING PLATE (LH/RH)

Remove kicking plate(LH/RH). Refer to [EI-30, "BODY SIDE TRIM"](#) .

FOOT REST


Remove foot rest. Refer to [EI-34, "FLOOR TRIM"](#) .

DASH SIDE FINISHER (LH/RH)

1. Remove plastics nut.
2. Remove dash side finisher(LH/RH).

INSTRUMENT DRIVER PANEL LOWER

1. Remove screws.
2. Remove data link connector.
3. Pull to disengage metal clip by removing panel in horizontal direction.
4. Disconnect in-vehicle sensor and each electrical parts.
5. Remove the grommet, and remove hood lock cable.




STEERING COLUMN LOWER COVER

1. Remove screws.
2. Disengage the tab, remove only lower side. (Upper side is integrated in combination meter.)

COMBINATION METER

After removing bolts, remove harness connector.




COMBINATION SWITCH

Remove bolts and remove combination switch. Refer to [SRS-40, "Removal and Installation"](#) .

CONSOLE FINISHER (A/T RING) (A/T)

1. Move selector lever to the drive position.
2. Insert a flat-bladed screwdriver wrapped with tape from behind console finisher (A/T ring) and remove by lifting.



INSTRUMENT PANEL ASSEMBLY

SHIFT KNOB (M/T)


Remove shift knob with turning counterclockwise.

CONSOLE FINISHER (A/T)

1. Insert a thin flat-bladed screwdriver wrapped with tape from behind console finisher A/T, and remove metal clip on back. Then pull up and back to disengage from front metal clip.
2. Disconnect A/C harness connector, and remove console finisher.

NOTE:

A/C controller is assembled in the console finisher (A/T). Therefore, when installing and removing be careful not to use excessive force, etc.



CONSOLE BOOT (M/T)

1. Insert a thin flat-bladed screwdriver wrapped with tape from behind console boot M/T, and remove metal clip on back. Then pull up and back to disengage from front metal clip.
2. Disconnect A/C harness connector, and remove console boot M/T.

NOTE:

A/C controller is assembled in the console boot (M/T). Therefore, when installing and removing be careful not to use excessive force, etc.

CENTER CONSOLE

1. Remove screws.
2. Remove console sub-harness.
3. After removing, disassemble each parts. Refer to [IP-17. "CENTER CONSOLE"](#)

NOTE:

When removing console, be careful not to pull the harness.


INSTRUMENT PASSENGER PANEL LOWER

1. Remove cup holder.

NOTE:

Insert a screwdriver wrapped with tape into square hole that can be seen from lower side. Pull stopper tab forward while pressing to lower side.

2. Remove screws and bolt.
3. Pull panel horizontally toward you and disengage from metal clip.



INSTRUMENT SIDE PANEL


1. Remove screws.
2. Pull to the side, disconnect metal clips, and remove instrument side panel.

NAVI SWITCH / SWITCH MASK

1. Insert a screwdriver wrapped with tape into center square hole for cluster lid D pawl. Bend cluster lid D backward to create a front/back gap.
2. Insert another screwdriver wrapped with tape into the gap made in No. 1. Push up NAVI switch and switch mask, and remove.

NOTE:

For NAVI switch, disconnect and remove harness connector.



INSTRUMENT PANEL ASSEMBLY

UNIFIED METER AND A/C AMP

Remove screws, and disconnect harness connector, and remove unified meter and A/C amp. Refer to [ATC-111, "AUTO AMP"](#) .

CLUSTER LID C

1. Remove screws.
2. Disconnect upper edge central pawl and metal clip.
3. Disconnect audio harness connector and pull out toward you.

CAUTION:

Unit is heavy, so be careful not to pinch your fingers when working.

4. After remove cluster lid C and then remove triple meter, cluster lid D and audio unit. Refer to [IP-18, "CLUSTER LID C"](#)

DISPLAY

Remove screws, and disconnect harness connector, and remove display.

FRONT PILLAR GARNISH

Pull to inside of vehicle, disconnect metal clips and remove front pillar garnish. Refer to [EI-30, "BODY SIDE TRIM"](#)

INSTRUMENT DRIVER PANEL UPPER

1. Remove screws.
2. Disconnect metal clips, then remove instrument driver panel upper.

INSTRUMENT PASSENGER PANEL UPPER

1. Remove screws.
2. Disconnect metal clips, then remove instrument passenger panel upper.

INSTRUMENT SIDE FINISHER (RH)

Using a screwdriver wrapped with tape, pry up and remove instrument side finisher. Disconnect from metal clip and pull toward you.

INSTRUMENT PANEL

Remove bolts, nut and screws, and remove instrument panel from passenger door opening portion.

Installation


To install, reverse the removal procedure sequence. Assemble the following three parts carefully.

CONSOLE FINISHER (A/T)

1. Move selector lever to the drive position.
2. Bring console finisher (A/T) to front side and connect front section metal clip.
3. After confirming secure connection of front section metal clip, connect rear section metal clip.

NOTE:

Insert securely to make sure there is on clearance of seam between lower section of cluster lid C and front section of center console.



CONSOLE BOOT (M/T)

1. Bring console boot (M/T) to front side and connect front section metal clip.
2. After confirming secure connection of front section metal clip, connect rear section metal clip.


NOTE:

Insert securely to make sure there is on clearance of seam between lower section of cluster lid C and front section of center console.

INSTRUMENT PANEL ASSEMBLY

INSTRUMENT PASSENGER PANEL LOWER

After finishing work, check the lower clip from lower angle which the clip is properly inserted.



INSTRUMENT PANEL ASSEMBLY

Disassembly and Assembly CENTER CONSOLE

AI/S00010

A

B

C

D

E

F

G

H


IP

J

K

L

M




- | | | |
|-----------------------|------------------------|-------------------|
| 1. Center console | 2. Coin holder bracket | 3. Switch bracket |
| 4. Bracket | 5. Console rear pocket | 6. Console tray |
| 7. Console cover mask | 8. Coin holder/Ashtray | |

1. Remove coin holder/ashtray.
2. Remove screws of back side and remove coin holder bracket.
3. Remove screws of back side and remove console rear pocket.

INSTRUMENT PANEL ASSEMBLY

CLUSTER LID C



- | | | |
|------------------|----------------|------------------|
| 1. Triple meter | 2. Audio | 3. Cluster lid C |
| 4. NAVI switch | 5. Switch mask | 6. Pocket mat |
| 7. Cluster lid D | | |