

SECTION **AT**

AUTOMATIC TRANSMISSION

CONTENTS

INDEX FOR DTC	5	How To Perform Trouble Diagnosis For Quick and	F
Alphabetical Index	5	Accurate Repair	41
DTC No. Index	6	A/T Electrical Parts Location	46
PRECAUTIONS	7	Circuit Diagram	48
Precautions for Supplemental Restraint System		Wiring Diagram — AT —	49
(SRS) "AIR BAG" and "SEAT BELT PRE-TEN-		Inspections Before Trouble Diagnosis	55
SIONER"	7	Check Before Engine is Started	59
Precautions for Battery Service	7	Check at Idle	59
Precautions for On Board Diagnostic (OBD) System		Cruise Test - Part 1	61
of A/T and Engine	7	Cruise Test - Part 2	63
Precautions	7	Cruise Test - Part 3	64
Service Notice or Precautions	8	Vehicle Speed When Shifting Gears	65
Wiring Diagrams and Trouble Diagnosis	8	Vehicle Speed When Performing and Releasing	
PREPARATION	9	Complete Lock-up	65
Special Service Tools	9	Vehicle Speed When Performing and Releasing	
Commercial Service Tools	9	Slip Lock-up	65
A/T FLUID	10	Symptom Chart	65
Changing A/T Fluid	10	TCM Input/Output Signal Reference Values	74
Checking A/T Fluid	10	CONSULT-II	75
A/T Fluid Cooler Cleaning	11	Diagnostic Procedure Without CONSULT-II	86
A/T CONTROL SYSTEM	15	DTC U1000 CAN COMMUNICATION LINE	88
Cross-Sectional View	15	Description	88
Shift Mechanism	16	On Board Diagnosis Logic	88
TCM Function	27	Possible Cause	88
CAN Communication	28	DTC Confirmation Procedure	88
Input/Output Signal of TCM	28	Diagnostic Procedure	89
Line Pressure Control	29	DTC P0615 START SIGNAL CIRCUIT	90
Shift Control	30	Description	90
Lock-Up Control	31	CONSULT-II Reference Value	90
Engine Brake Control	33	On Board Diagnosis Logic	90
Control Valve	33	Possible Cause	90
ON BOARD DIAGNOSTIC (OBD) SYSTEM	35	DTC Confirmation Procedure	90
Introduction	35	Diagnostic Procedure	91
OBD-II Function for A/T System	35	DTC P0700 TCM	93
One or Two Trip Detection Logic of OBD-II	35	Description	93
OBD-II Diagnostic Trouble Code (DTC)	35	On Board Diagnosis Logic	93
Malfunction Indicator Lamp (MIL)	38	Possible Cause	93
TROUBLE DIAGNOSIS	39	DTC Confirmation Procedure	93
DTC Inspection Priority Chart	39	Diagnostic Procedure	93
Fail-Safe	39	DTC P0705 PARK/NEUTRAL POSITION SWITCH..	94

Description	94	CONSULT-II Reference Value	113
CONSULT-II Reference Value	94	On Board Diagnosis Logic	113
On Board Diagnosis Logic	94	Possible Cause	113
Possible Cause	94	DTC Confirmation Procedure	113
DTC Confirmation Procedure	94	Diagnostic Procedure	113
Diagnostic Procedure	95	DTC P1710 A/T FLUID TEMPERATURE SENSOR CIRCUIT	115
DTC P0720 VEHICLE SPEED SENSOR A/T (REVOLUTION SENSOR)	97	Description	115
Description	97	CONSULT-II Reference Value	115
CONSULT-II Reference Value	97	On Board Diagnosis Logic	115
On Board Diagnosis Logic	97	Possible Cause	115
Possible Cause	97	DTC Confirmation Procedure	115
DTC Confirmation Procedure	97	Diagnostic Procedure	116
Diagnostic Procedure	98	DTC P1716 TURBINE REVOLUTION SENSOR ...	118
DTC P0725 ENGINE SPEED SIGNAL	100	Description	118
Description	100	CONSULT-II Reference Value	118
CONSULT-II Reference Value	100	On Board Diagnosis Logic	118
On Board Diagnosis Logic	100	Possible Cause	118
Possible Cause	100	DTC Confirmation Procedure	118
DTC Confirmation Procedure	100	Diagnostic Procedure	119
Diagnostic Procedure	100	DTC P1721 VEHICLE SPEED SENSOR MTR	121
DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE	102	Description	121
Description	102	CONSULT-II Reference Value	121
CONSULT-II Reference Value	102	On Board Diagnosis Logic	121
On Board Diagnosis Logic	102	Possible Cause	121
Possible Cause	102	DTC Confirmation Procedure	121
DTC Confirmation Procedure	102	Diagnostic Procedure	122
Diagnostic Procedure	103	DTC P1730 A/T INTERLOCK	123
DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)	105	Description	123
Description	105	On Board Diagnosis Logic	123
CONSULT-II Reference Value	105	Possible Cause	123
On Board Diagnosis Logic	105	DTC Confirmation Procedure	123
Possible Cause	105	Judgement of A/T Interlock	123
DTC Confirmation Procedure	105	Diagnostic Procedure	124
Diagnostic Procedure	106	DTC P1731 A/T 1ST ENGINE BRAKING	126
DTC P0745 LINE PRESSURE SOLENOID VALVE	108	Description	126
Description	108	CONSULT-II Reference Value	126
CONSULT-II Reference Value	108	On Board Diagnosis Logic	126
On Board Diagnosis Logic	108	Possible Cause	126
Possible Cause	108	DTC Confirmation Procedure	126
DTC Confirmation Procedure	108	Diagnostic Procedure	127
Diagnostic Procedure	109	DTC P1752 INPUT CLUTCH SOLENOID VALVE	129
DTC P1702 TRANSMISSION CONTROL MODULE (RAM)	111	Description	129
Description	111	CONSULT-II Reference Value	129
On Board Diagnosis Logic	111	On Board Diagnosis Logic	129
Possible Cause	111	Possible Cause	129
DTC Confirmation Procedure	111	DTC Confirmation Procedure	129
Diagnostic Procedure	111	Diagnostic Procedure	130
DTC P1703 TRANSMISSION CONTROL MODULE (ROM)	112	DTC P1754 INPUT CLUTCH SOLENOID VALVE FUNCTION	132
Description	112	Description	132
On Board Diagnosis Logic	112	CONSULT-II Reference Value	132
Possible Cause	112	On Board Diagnosis Logic	132
DTC Confirmation Procedure	112	Possible Cause	132
Diagnostic Procedure	112	DTC Confirmation Procedure	132
DTC P1705 THROTTLE POSITION SENSOR	113	Diagnostic Procedure	133
Description	113	DTC P1757 FRONT BRAKE SOLENOID VALVE ..	135
		Description	135
		CONSULT-II Reference Value	135

On Board Diagnosis Logic	135	DTC P1815 MANUAL MODE SWITCH	159	
Possible Cause	135	Description	159	A
DTC Confirmation Procedure	135	CONSULT-II Reference Value in Data Monitor Mode	159	
Diagnostic Procedure	136			
DTC P1759 FRONT BRAKE SOLENOID VALVE FUNCTION	138	On Board Diagnosis Logic	159	B
Description	138	Possible Cause	159	
CONSULT-II Reference Value	138	DTC Confirmation Procedure	159	
On Board Diagnosis Logic	138	Diagnostic Procedure	160	AT
Possible Cause	138	Component Inspection	161	
DTC Confirmation Procedure	138	Position Indicator	161	
Diagnostic Procedure	139	DTC P1841 ATF PRESSURE SWITCH 1	163	D
DTC P1762 DIRECT CLUTCH SOLENOID VALVE	141	Description	163	
Description	141	CONSULT-II Reference Value	163	E
CONSULT-II Reference Value	141	On Board Diagnosis Logic	163	
On Board Diagnosis Logic	141	Possible Cause	163	
Possible Cause	141	DTC Confirmation Procedure	163	F
DTC Confirmation Procedure	141	Diagnostic Procedure	164	
Diagnostic Procedure	142	DTC P1843 ATF PRESSURE SWITCH 3	166	G
DTC P1764 DIRECT CLUTCH SOLENOID VALVE FUNCTION	144	Description	166	
Description	144	CONSULT-II Reference Value	166	H
CONSULT-II Reference Value	144	On Board Diagnosis Logic	166	
On Board Diagnosis Logic	144	Possible Cause	166	I
Possible Cause	144	DTC Confirmation Procedure	166	
DTC Confirmation Procedure	144	Diagnostic Procedure	167	J
Diagnostic Procedure	145	DTC P1845 ATF PRESSURE SWITCH 5	169	
DTC P1767 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE	147	Description	169	K
Description	147	CONSULT-II Reference Value	169	
CONSULT-II Reference Value	147	On Board Diagnosis Logic	169	L
On Board Diagnosis Logic	147	Possible Cause	169	
Possible Cause	147	DTC Confirmation Procedure	169	M
DTC Confirmation Procedure	147	Diagnostic Procedure	170	
Diagnostic Procedure	148	DTC P1846 ATF PRESSURE SWITCH 6	172	
DTC P1769 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE FUNCTION	150	Description	172	
Description	150	CONSULT-II Reference Value	172	
CONSULT-II Reference Value	150	On Board Diagnosis Logic	172	
On Board Diagnosis Logic	150	Possible Cause	172	
Possible Cause	150	DTC Confirmation Procedure	172	
DTC Confirmation Procedure	150	Diagnostic Procedure	173	
Diagnostic Procedure	151	CLOSED THROTTLE POSITION AND WIDE OPEN THROTTLE POSITION CIRCUIT	175	
DTC P1772 LOW COAST BRAKE SOLENOID VALVE	153	CONSULT-II Reference Value	175	
Description	153	Diagnostic Procedure	175	
CONSULT-II Reference Value	153	BRAKE SIGNAL CIRCUIT	176	
On Board Diagnosis Logic	153	CONSULT-II Reference Value	176	
Possible Cause	153	Diagnostic Procedure	176	
DTC Confirmation Procedure	153	TROUBLE DIAGNOSIS FOR SYMPTOMS	177	
Diagnostic Procedure	154	A/T CHECK Indicator Lamp Does Not Come On ..	177	
DTC P1774 LOW COAST BRAKE SOLENOID VALVE FUNCTION	156	Engine Cannot Be Started In "P" or "N" Position ..	178	
Description	156	In "P" Position, Vehicle Moves When Pushed	179	
CONSULT-II Reference Value	156	In "N" Position, Vehicle Moves	180	
On Board Diagnosis Logic	156	Large Shock ("N" to "D" Position)	181	
Possible Cause	156	Vehicle Does Not Creep Backward In "R" Position ..	182	
DTC Confirmation Procedure	156	Vehicle Does Not Creep Forward In "D" Position ..	183	
Diagnostic Procedure	157	Vehicle Cannot Be Started From D1	184	
		A/T Does Not Shift: D1 → D2	185	
		A/T Does Not Shift: D2 → D3	186	
		A/T Does Not Shift: D3 → D4	187	
		A/T Does Not Shift: D4 → D5	188	
		A/T Does Not Perform Lock-up	190	

A/T Does Not Hold Lock-up Condition	191	KEY INTERLOCK CABLE	207
Lock-up Is Not Released	191	Components	207
Engine Speed Does Not Return To Idle	192	Removal and Installation	208
Cannot Be changed to Manual Mode	193	ON-VEHICLE SERVICE	210
A/T Does Not Shift: 5th gear → 4th gear	193	Oil Pan	210
A/T Does Not Shift: 4th gear → 3rd gear	194	AIR BREATHER HOSE	211
A/T Does Not Shift: 3rd gear → 2nd gear	195	Removal and Installation	211
A/T Does Not Shift: 2nd gear → 1st gear	197	TRANSMISSION ASSEMBLY	212
Vehicle Does Not Decelerate By Engine Brake ...	198	Removal and Installation	212
SHIFT CONTROL SYSTEM	200	SERVICE DATA AND SPECIFICATIONS (SDS) ...	215
Control Device Removal and Installation	200	General Specifications	215
Adjustment of A/T Position	201	Vehicle Speed When Shifting Gears	215
Checking of A/T Position	201	Vehicle Speed When Performing and Releasing	
A/T SHIFT LOCK SYSTEM	203	Complete Lock-up	215
Description	203	Vehicle Speed When Performing and Releasing	
Shift Lock System Electrical Parts Location	203	Slip Lock-up	215
Wiring Diagram — AT — SHIFT	204	Stall Speed	215
Diagnostic Procedure	205	Line Pressure	216

INDEX FOR DTC

INDEX FOR DTC

PFP:00024

Alphabetical Index

ACS000GR

NOTE:

If DTC U1000 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000. Refer to [AT-88](#).

Items (CONSULT-II screen terms)	DTC		Reference page
	OBD-II	Except OBD-II	
	CONSULT-II GST*1	CONSULT-II only "A/T"	
A/T 1ST E/BRAKING	—	P1731	AT-126
ATF PRES SW 1/CIRC	—	P1841	AT-163
ATF PRES SW 3/CIRC	—	P1843	AT-166
ATF PRES SW 5/CIRC	—	P1845	AT-169
ATF PRES SW 6/CIRC	—	P1846	AT-172
A/T INTERLOCK	P1730	P1730	AT-123
A/T TCC S/V FNCTN	P0744	P0744	AT-105
ATF TEMP SEN/CIRC	P0710	P1710	AT-115
CAN COMM CIRCUIT	U1000	U1000	AT-88
D/C SOLENOID/CIRC	P1762	P1762	AT-141
D/C SOLENOID FNCTN	P1764	P1764	AT-144
ENGINE SPEED SIG	P0725	P0725	AT-100
FR/B SOLENOID/CIRC	P1757	P1757	AT-135
FR/B SOLENOID FNCT	P1759	P1759	AT-138
HLR/C SOL/CIRC	P1767	P1767	AT-147
HLR/C SOL FNCTN	P1769	P1769	AT-150
I/C SOLENOID/CIRC	P1752	P1752	AT-129
I/C SOLENOID FNCTN	P1754	P1754	AT-132
L/PRESS SOL/CIRC	P0745	P0745	AT-108
LC/B SOLENOID/CIRC	P1772	P1772	AT-153
LC/B SOLENOID FNCT	P1774	P1774	AT-156
MANU MODE SW/CIR	—	P1815	AT-159
PNP SW/CIRC	P0705	P0705	AT-94
STARTER RELAY/CIRC	—	P0615	AT-90
TCC SOLENOID/CIRC	P0740	P0740	AT-102
TCM	P0700	P0700	AT-93
TCM-RAM	—	P1702	AT-111
TCM-ROM	—	P1703	AT-112
TP SEN/CIRC A/T	P1705	P1705	AT-113
TURBINE REV S/CIRC	P1716	P1716	AT-118
VEH SPD SE/CIR-MTR	—	P1721	AT-121
VEH SPD SEN/CIR AT	P0720	P0720	AT-97

*1: These numbers are prescribed by SAE J2012.

INDEX FOR DTC

DTC No. Index

ACS000GS

NOTE:

If DTC U1000 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000. Refer to [AT-88](#).

DTC		Items (CONSULT-II screen terms)	Reference page
OBD-II	Except OBD-II		
CONSULT-II GST*1	CONSULT-II only "A/T"		
—	P0615	STARTER RELAY/CIRC	AT-90
P0700	P0700	TCM	AT-93
P0705	P0705	PNP SW/CIRC	AT-94
P0710	P1710	ATF TEMP SEN/CIRC	AT-115
P0720	P0720	VEH SPD SEN/CIR AT	AT-97
P0725	P0725	ENGINE SPEED SIG	AT-100
P0740	P0740	TCC SOLENOID/CIRC	AT-102
P0744	P0744	A/T TCC S/V FNCTN	AT-105
P0745	P0745	L/PRESS SOL/CIRC	AT-108
—	P1702	TCM-RAM	AT-111
—	P1703	TCM-ROM	AT-112
P1705	P1705	TP SEN/CIRC A/T	AT-113
P1716	P1716	TURBINE REV S/CIRC	AT-118
—	P1721	VEH SPD SE/CIR-MTR	AT-121
P1730	P1730	A/T INTERLOCK	AT-123
—	P1731	A/T 1ST E/BRAKING	AT-126
P1752	P1752	I/C SOLENOID/CIRC	AT-129
P1754	P1754	I/C SOLENOID FNCTN	AT-132
P1757	P1757	FR/B SOLENOID/CIRC	AT-135
P1759	P1759	FR/B SOLENOID FNCT	AT-138
P1762	P1762	D/C SOLENOID/CIRC	AT-141
P1764	P1764	D/C SOLENOID FNCTN	AT-144
P1767	P1767	HLR/C SOL/CIRC	AT-147
P1769	P1769	HLR/C SOL FNCTN	AT-150
P1772	P1772	LC/B SOLENOID/CIRC	AT-153
P1774	P1774	LC/B SOLENOID FNCT	AT-156
—	P1815	MANU MODE SW/CIRC	AT-159
—	P1841	ATF PRES SW 1/CIRC	AT-163
—	P1843	ATF PRES SW 3/CIRC	AT-166
—	P1845	ATF PRES SW 5/CIRC	AT-169
—	P1846	ATF PRES SW 6/CIRC	AT-172
U1000	U1000	CAN COMM CIRCUIT	AT-88

*1: These numbers are prescribed by SAE J2012.

PRECAUTIONS

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

ACS006FV

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions for Battery Service

ACS001NN

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

Precautions for On Board Diagnostic (OBD) System of A/T and Engine

ACS000GU

The ECM has an on board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.

CAUTION:

- Be sure to turn the ignition switch “OFF” and disconnect the negative battery cable before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. Will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MIL to light up due to an open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Be sure to route and secure the harnesses properly after work. Interference of the harness with a bracket, etc. May cause the MIL to light up due to a short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MIL to light up due to a malfunction of the EGR system or fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the TCM and ECM before returning the vehicle to the customer.

Precautions


ACS000GW

NOTE:


If any malfunctions occur in the RE5R05A model transmission, replace the entire transmission assembly.

PRECAUTIONS

- Before connecting or disconnecting the A/T assembly harness connector, turn ignition switch "OFF" and disconnect negative battery cable. Because battery voltage is applied to TCM even if ignition switch is turned "OFF".



- After performing each TROUBLE DIAGNOSIS, perform "DTC (Diagnostic Trouble Code) Confirmation Procedure". If the repair is completed the DTC should not be displayed in the "DTC Confirmation Procedure".



- Always use the specified brand of A/T fluid. Refer to [MA-12, "Fluids and Lubricants"](#).
- Use paper rags not cloth rags during work.
- After replacing the A/T fluid, dispose of the waste oil using the methods prescribed by law, ordinance, etc.

Service Notice or Precautions ATF COOLER SERVICE

ACS000GX

If A/T fluid contains frictional material (clutches, bands, etc.), or if an A/T is repaired, overhauled, or replaced, inspect and clean the A/T fluid cooler mounted in the radiator or replace the radiator. Flush cooler lines using cleaning solvent and compressed air after repair. For A/T fluid cooler cleaning procedure, refer to [AT-11, "A/T Fluid Cooler Cleaning"](#). For radiator replacement, refer to [CO-12, "RADIATOR"](#).

OBD-II SELF-DIAGNOSIS

- A/T self-diagnosis is performed by the TCM in combination with the ECM. The results can be read through the blinking pattern of the A/T CHECK indicator or the malfunction indicator lamp (MIL). Refer to the table on [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) for the indicator used to display each self-diagnostic result.
- The self-diagnostic results indicated by the MIL are automatically stored in both the ECM and TCM memories.
Always perform the procedure on [AT-36, "HOW TO ERASE DTC"](#) to complete the repair and avoid unnecessary blinking of the MIL.

For details of OBD-II, refer to [EC-47, "ON BOARD DIAGNOSTIC \(OBD\) SYSTEM"](#).

- Certain systems and components, especially those related to OBD, may use the new style slide-locking type harness connector. For description and how to disconnect, refer to [PG-80, "HARNESS CONNECTOR"](#).

Wiring Diagrams and Trouble Diagnosis

ACS000GY

When you read wiring diagrams, refer to the following:

- [GI-15, "How to Read Wiring Diagrams"](#).
- [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) for power distribution circuit.

When you perform trouble diagnosis, refer to the following:

- [GI-11, "How to Follow Trouble Diagnoses"](#).
- [GI-27, "How to Perform Efficient Diagnosis for an Electrical Incident"](#).

PREPARATION



PREPARATION

PFP:00002

Special Service Tools


ACS000GZ

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
ST2505S001 (J34301-C) Oil pressure gauge set 1 ST25051001 (—) Oil pressure gauge 2 ST25052000 (—) Hose 3 ST25053000 (—) Joint pipe 4 ST25054000 (—) Adapter 5 ST25055000 (—) Adapter	Measuring line pressure
	
KV31103600 (J45674) Joint pipe adapter (With ST25054000)	Measuring line pressure
	

Commercial Service Tools

ACS000H0

Tool name	Description
Power tool	Loosening bolts and nuts
	

A/T FLUID

PFP:KLE40

Changing A/T Fluid

ACS003S7

1. Warm up ATF.
2. Stop engine.
3. Loosen the level gauge bolt.
4. Drain ATF from drain plug and refill with new ATF. Always refill same volume with drained fluid.
 - To replace the ATF, pour in new fluid at the charging pipe with the engine idling and at the same time drain the old fluid from the radiator cooler hose return side.
 - When the color of the fluid coming out is about the same as the color of the new fluid, the replacement is complete. The amount of new transmission fluid to use should be 30 to 50% of the stipulated amount.

A/T fluid: Genuine Nissan Matic J ATF

Fluid capacity: 10.3 ℓ (10-7/8 US qt, 9-1/8 Imp qt)

CAUTION:

- Use only Genuine Nissan Matic J ATF. Do not mix with other fluid.
- Using automatic transmission fluid other than Genuine Nissan Matic J ATF will cause deterioration in driveability and automatic transmission durability, and may damage the automatic transmission, which is not covered by the warranty.
- When filling ATF, take care not to scatter heat generating parts such as exhaust.
- Do not reuse drain plug gasket.

Drain plug:

 : 34 N·m (3.5 kg-m, 25 ft-lb)

5. Run engine at idle speed for 5 minutes.
6. Check fluid level and condition. Refer to [AT-10, "Checking A/T Fluid"](#) . If fluid is still dirty, repeat step 2. through 5.
7. Install the removed A/T fluid level gauge in the A/T fluid charging pipe.
8. Tighten the level gauge bolt.

Level gauge bolt:

 : 5.1 N·m (0.52 kg-m, 45 in-lb)

Checking A/T Fluid

ACS003S8

1. Warm up engine.
2. Check for fluid leakage.
3. Loosen the level gauge bolt.
4. Before driving, fluid level can be checked at fluid temperatures of 30 to 50°C (86 to 122°F) using "COLD" range on A/T fluid level gauge as follows.
 - a. Park vehicle on level surface and set parking brake.
 - b. Start engine and move selector lever through each gear position. Leave selector lever in "P" position.
 - c. Check fluid level with engine idling.
 - d. Remove A/T fluid level gauge and wipe clean with lint-free paper.

CAUTION:

When wiping away the A/T fluid level gauge, always use lint-free paper, not a cloth one.

- e. Re-insert A/T fluid level gauge into A/T fluid charging pipe as far as it will go.

CAUTION:

To check fluid level, insert the A/T fluid level gauge until the cap contacts the end of the A/T fluid charging pipe, with the A/T fluid level gauge reversed from the normal attachment conditions.

- f. Remove A/T fluid level gauge and note reading. If reading is at low side of range, add fluid to the A/T fluid charging pipe.

A/T FLUID


CAUTION:

Do not overfill.

5. Drive vehicle for approximately 5 minutes in urban areas.
6. Make the fluid temperature approximately 65°C (149°F).

NOTE:

Fluid level will be greatly affected by temperature as shown in figure. Therefore, be certain to perform operation while checking data with CONSULT-II.




- a. Connect CONSULT-II to data link connector.
- b. Select "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
- c. Read out the value of "ATF TEMP 1".
7. Re-check fluid level at fluid temperatures of approximately 65°C (149°F) using "HOT" range on A/T fluid level gauge.

CAUTION:

- When wiping away the A/T fluid level gauge, always use lint-free paper, not a cloth one.
- To check fluid level, insert the A/T fluid level gauge until the cap contacts the end of the A/T fluid charging pipe, with the gauge reversed from the normal attachment conditions as shown.

8. Check fluid condition.

- If fluid is very dark or smells burned, refer to check operation of A/T. Flush cooling system after repair of A/T.
- If ATF contains frictional material (clutches, bands, etc.), replace radiator and flush cooler line using cleaning solvent and compressed air after repair of A/T. Refer to [CO-12, "RADIATOR"](#) and [AT-11, "A/T Fluid Cooler Cleaning"](#).



9. Install the removed A/T fluid level gauge in the A/T fluid charging pipe.
10. Tighten the level gauge bolt.

Level gauge bolt:

: 5.1N-m (0.52 kg-m, 45 in-lb)

A/T Fluid Cooler Cleaning

ACS004LL

Whenever an automatic transmission is replaced, the A/T fluid cooler mounted in the radiator must be inspected and cleaned.

A/T FLUID

Metal debris and friction material, if present, can become trapped in the A/T fluid cooler. This debris can contaminate the newly serviced A/T or, in severe cases, can block or restrict the flow of A/T fluid. In either case, malfunction of the newly serviced A/T may result.

Debris, if present, may build up as A/T fluid enters the cooler inlet. It will be necessary to back flush the cooler through the cooler outlet in order to flush out any built up debris.


A/T FLUID COOLER CLEANING PROCEDURE

1. Position an oil pan under the automatic transmission's inlet and outlet cooler hoses.
2. Identify the inlet and outlet fluid cooler hoses.
3. Disconnect the fluid cooler inlet and outlet rubber hoses from the steel cooler tubes or bypass valve.

NOTE:

Replace the cooler hoses if rubber material from the hose remains on the tube fitting.

4. Allow any A/T fluid that remains in the cooler hoses to drain into the oil pan.




5. Insert the extension adapter hose of a can of Transmission Cooler Cleaner (Nissan P/N 999MP-AM006) into the cooler outlet hose.


CAUTION:

- Wear safety glasses and rubber gloves when spraying the Transmission Cooler Cleaner.
- Spray cooler cleaner only with adequate ventilation.
- Avoid contact with eyes and skin.
- Do not breath vapors or spray mist.

6. Hold the hose and can as high as possible and spray Transmission Cooler Cleaner in a continuous stream into the cooler outlet hose until fluid flows out of the cooler inlet hose for 5 seconds.
7. Insert the tip of an air gun into the end of the cooler outlet hose.
8. Wrap a shop rag around the air gun tip and of the cooler outlet hose.



9. Blow compressed air regulated to 5 - 9 kg/cm² (70 - 130 psi) through the cooler outlet hose for 10 seconds to force out any remaining fluid.
10. Repeat steps 5 through 9 three additional times.
11. Position an oil pan under the banjo bolts that connect the fluid cooler steel lines to the transmission.
12. Remove the banjo bolts.
13. Flush each steel line from the cooler side back toward the transmission by spraying Transmission Cooler Cleaner in a continuous stream for 5 seconds.
14. Blow compressed air regulated to 5 - 9 kg/cm² (70 - 130 psi) through each steel line from the cooler side back toward the transmission for 10 seconds to force out any remaining fluid.
15. Ensure all debris is removed from the steel cooler lines.
16. Ensure all debris is removed from the banjo bolts and fittings.



17. Perform [AT-13, "A/T FLUID COOLER DIAGNOSIS PROCEDURE"](#).

A/T FLUID COOLER DIAGNOSIS PROCEDURE



NOTE:

Insufficient cleaning of the cooler inlet hose exterior may lead to inaccurate debris identification.


1. Position an oil pan under the automatic transmission's inlet and outlet cooler hoses.
2. Clean the exterior and tip of the cooler inlet hose.
3. Insert the extension adapter hose of a can of Transmission Cooler Cleaner (Nissan P/N 999MP-AM006) into the cooler outlet hose.

CAUTION:

- Wear safety glasses and rubber gloves when spraying the Transmission Cooler Cleaner.
 - Spray cooler cleaner only with adequate ventilation.
 - Avoid contact with eyes and skin.
 - Do not breath vapors or spray mist.
4. Hold the hose and can as high as possible and spray Transmission Cooler Cleaner in a continuous stream into the cooler outlet hose until fluid flows out of the cooler inlet hose for 5 seconds.
 5. Tie a common white, basket-type coffee filter to the end of the cooler inlet hose.




6. Insert the tip of an air gun into the end of the cooler outlet hose.
7. Wrap a shop rag around the air gun tip and end of cooler outlet hose.
8. Blow compressed air regulated to 5 - 9 kg/cm² (70 - 130 psi) through the cooler outlet hose to force any remaining A/T fluid into the coffee filter.
9. Remove the coffee filter from the end of the cooler inlet hose.
10. Perform [AT-13, "A/T FLUID COOLER INSPECTION PROCEDURE"](#).




A/T FLUID COOLER INSPECTION PROCEDURE

1. Inspect the coffee filter for debris.
- a. If small metal debris less than 1mm (0.040 in) in size or metal powder is found in the coffee filter, this is normal. If normal debris is found, the A/T fluid cooler/radiator can be re-used and the procedure is ended.



A/T FLUID

- b. If one or more pieces of debris are found that are over 1mm (0.040 in) in size and/or peeled clutch facing material is found in the coffee filter, the fluid cooler is not serviceable. The A/T fluid cooler/radiator must be replaced and the inspection procedure is ended. Refer to [CO-12, "RADIATOR"](#) and [CO-15, "RADIATOR \(ALUMINUM TYPE\)"](#).



A/T FLUID COOLER FINAL INSPECTION

After performing all procedures, ensure that all remaining oil is cleaned from all components.


A/T CONTROL SYSTEM

A/T CONTROL SYSTEM

PFP:31036

Cross-Sectional View

ACS000H3



- | | | |
|----------------------------|--------------------------------|------------------------|
| 1. Front planetary gear | 2. Mid planetary gear | 3. Rear planetary gear |
| 4. Direct clutch | 5. High and low reverse clutch | 6. Reverse brake |
| 7. Forward brake | 8. Low coast brake | 9. Input shaft |
| 10. Torque converter | 11. Oil pump | 12. Front brake |
| 13. 3rd one-way clutch | 14. Input clutch | 15. 1st one-way clutch |
| 16. Control valve with TCM | 17. Forward one-way clutch | 18. Rear extension |
| 19. Output shaft | | |


A/T CONTROL SYSTEM

ACS000H4

Shift Mechanism

The automatic transmission uses compact dual planetary gear systems to improve power-transmission efficiency, simplify construction and reduce weight. It also employs an optimum shift control and super wide gear ratios. They improve starting performance and acceleration during medium and high-speed operation.

CONSTRUCTION



- | | | |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake | 2. Input clutch | 3. Direct clutch |
| 4. High and low reverse clutch | 5. Reverse brake | 6. Forward brake |
| 7. Low coast brake | 8. 1st one-way clutch | 9. Forward one-way clutch |
| 10. 3rd one-way clutch | 11. Front sun gear | 12. Input shaft |
| 13. Mid internal gear | 14. Front internal gear | 15. Rear carrier |
| 16. Rear sun gear | 17. Mid sun gear | 18. Front carrier |
| 19. Mid carrier | 20. Rear internal gear | 21. Output shaft |
| 22. Parking gear | 23. Parking pawl | |

FUNCTION OF CLUTCH AND BRAKE

Name of the Part	Abbreviation	Function
Front brake (1)	FR/B	Fastens the front sun gear (11).
Input clutch (2)	I/C	Connects the input shaft (12), the front internal gear (14) and the mid internal gear (13).
Direct clutch (3)	D/C	Connects the rear carrier (15) and the rear sun gear (16).
High and low reverse clutch (4)	HLR/C	Connects the mid sun gear (17) and the rear sun gear (16).
Reverse brake (5)	R/B	Fastens the rear carrier (15).
Forward brake (6)	Fwd/B	Fastens the mid sun gear (17).
Low coast brake (7)	LC/B	Fastens the mid sun gear (17).
1st one-way clutch (8)	1st/OWC	Allows the rear sun gear (16) to turn freely forward relative to the mid sun gear (17) but fastens it for reverse rotation.
Forward one-way clutch (9)	Fwd/OWC	Allows the mid sun gear (17) to turn freely in the forward direction but fastens it for reverse rotation.
3rd one-way clutch (10)	3rd/OWC	Allows the front sun gear (11) to turn freely in the forward direction but fastens it for reverse rotation.

A/T CONTROL SYSTEM

CLUTCH AND BAND CHART

Shift position		I/C	HLR/C	D/C	R/B	FR/B	LC/B	Fwd/B	1st OWC	Fwd OWC	3rd OWC	Remarks
P			△			△						PARK POSITION
R			○		○	○			◎		◎	REVERSE POSITION
N			△			△						NEUTRAL POSITION
D	1 st		△ *			△	△ **	○	◎	◎	◎	Automatic shift 1↔2↔3↔4↔5
	2 nd			○		△		○		◎	◎	
	3 rd		○	○		○		△	◇		◎	
	4 th	○	○	○				△	◇			
	5 th	○	○			○		△	◇		◇	
M5	5 th	○	○			○		△	◇		◇	Locks (held stationary) in 5th gear
M4	4 th	○	○	○				△	◇			Locks (held stationary) in 4th gear
M3	3 rd		○	○		○		△	◇		◎	Locks (held stationary) in 3th gear
M2	2 nd			○		○	○	○		◎	◎	Locks (held stationary) in 2th gear
M1	1 st		○			○	○	○	◎	◎	◎	Locks (held stationary) in 1th gear

○ — Operates


◎ — Operates during “progressive” acceleration.

◇ — Operates and affects power transmission while coasting.

△ — Line pressure is applied but does not affect power transmission.

△ * — Operates under conditions shown in illustration ①.

△ ** — Operates under conditions shown in illustration ②. Delay control is applied during D(4,3,2,1) → N shift.



A/T CONTROL SYSTEM


POWER TRANSMISSION

“N” position

Since both the forward brake and the reverse brake are released, torque from the input shaft drive is not transmitted to the output shaft.

“P” position

- The same as for the “N” position, both the forward brake and the reverse brake are released, so torque from the input shaft drive is not transmitted to the output shaft.
- The parking pawl linked with the selector lever meshes with the parking gear and fastens the output shaft mechanically.




- | | | |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake | 2. Input clutch | 3. Direct clutch |
| 4. High and low reverse clutch | 5. Reverse brake | 6. Forward brake |
| 7. Low coast brake | 8. 1st one-way clutch | 9. Forward one-way clutch |
| 10. 3rd one-way clutch | 11. Front sun gear | 12. Input shaft |
| 13. Mid internal gear | 14. Front internal gear | 15. Rear carrier |
| 16. Rear sun gear | 17. Mid sun gear | 18. Front carrier |
| 19. Mid carrier | 20. Rear internal gear | 21. Output shaft |
| 22. Parking gear | 23. Parking pawl | |

A/T CONTROL SYSTEM

“D1 ” position

- The forward brake and the forward one-way clutch regulate reverse rotation of the mid sun gear.
- The 1st one-way clutch regulates reverse rotation of the rear sun gear.
- The 3rd one-way clutch regulates reverse rotation of the front sun gear.
- During deceleration, the mid sun gear turns forward, so the forward one-way clutch idles and the engine brake is not activated.




- | | | |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake | 2. Input clutch | 3. Direct clutch |
| 4. High and low reverse clutch | 5. Reverse brake | 6. Forward brake |
| 7. Low coast brake | 8. 1st one-way clutch | 9. Forward one-way clutch |
| 10. 3rd one-way clutch | 11. Front sun gear | 12. Input shaft |
| 13. Mid internal gear | 14. Front internal gear | 15. Rear carrier |
| 16. Rear sun gear | 17. Mid sun gear | 18. Front carrier |
| 19. Mid carrier | 20. Rear internal gear | 21. Output shaft |
| 22. Parking gear | 23. Parking pawl | |

A/T CONTROL SYSTEM

"M1" position

- The front brake fastens the front sun gear.
- The forward brake and the forward one-way clutch regulate reverse rotation of the mid sun gear.
- High and low reverse clutch connects the rear sun gear and the mid sun gear.
- The low coast brake fastens the mid sun gear.
- During deceleration, the low coast brake regulates forward rotation of the mid sun gear and the engine brake functions.




- | | | |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake | 2. Input clutch | 3. Direct clutch |
| 4. High and low reverse clutch | 5. Reverse brake | 6. Forward brake |
| 7. Low coast brake | 8. 1st one-way clutch | 9. Forward one-way clutch |
| 10. 3rd one-way clutch | 11. Front sun gear | 12. Input shaft |
| 13. Mid internal gear | 14. Front internal gear | 15. Rear carrier |
| 16. Rear sun gear | 17. Mid sun gear | 18. Front carrier |
| 19. Mid carrier | 20. Rear internal gear | 21. Output shaft |
| 22. Parking gear | 23. Parking pawl | |

A/T CONTROL SYSTEM

“D2 ” position

- The forward brake and the forward one-way clutch regulate reverse rotation of the mid sun gear.
- The 3rd one-way clutch regulates reverse rotation of the front sun gear.
- The direct clutch is coupled, and the rear carrier and rear sun gear are connected.
- During deceleration, the mid sun gear turns forward, so the forward one-way clutch idles and engine brake is not activated.




- | | | |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake | 2. Input clutch | 3. Direct clutch |
| 4. High and low reverse clutch | 5. Reverse brake | 6. Forward brake |
| 7. Low coast brake | 8. 1st one-way clutch | 9. Forward one-way clutch |
| 10. 3rd one-way clutch | 11. Front sun gear | 12. Input shaft |
| 13. Mid internal gear | 14. Front internal gear | 15. Rear carrier |
| 16. Rear sun gear | 17. Mid sun gear | 18. Front carrier |
| 19. Mid carrier | 20. Rear internal gear | 21. Output shaft |
| 22. Parking gear | 23. Parking pawl | |

A/T CONTROL SYSTEM

“M2” position

- The front brake fastens the front sun gear.
- The forward brake and the forward one-way clutch regulate reverse rotation of the mid sun gear.
- The direct clutch is coupled, and the rear carrier and rear sun gear are connected.
- The low coast brake fastens the mid sun gear.
- During deceleration, the low coast brake regulates forward rotation of the mid sun gear and the engine brake functions.




- | | | |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake | 2. Input clutch | 3. Direct clutch |
| 4. High and low reverse clutch | 5. Reverse brake | 6. Forward brake |
| 7. Low coast brake | 8. 1st one-way clutch | 9. Forward one-way clutch |
| 10. 3rd one-way clutch | 11. Front sun gear | 12. Input shaft |
| 13. Mid internal gear | 14. Front internal gear | 15. Rear carrier |
| 16. Rear sun gear | 17. Mid sun gear | 18. Front carrier |
| 19. Mid carrier | 20. Rear internal gear | 21. Output shaft |
| 22. Parking gear | 23. Parking pawl | |

A/T CONTROL SYSTEM

“D3 ” and “M3” position

- The front brake fastens the front sun gear.
- The direct clutch is coupled, and the rear carrier and rear sun gear are connected.
- The high and low reverse clutch is coupled, and the mid sun gear and rear sun gear are connected.




- | | | |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake | 2. Input clutch | 3. Direct clutch |
| 4. High and low reverse clutch | 5. Reverse brake | 6. Forward brake |
| 7. Low coast brake | 8. 1st one-way clutch | 9. Forward one-way clutch |
| 10. 3rd one-way clutch | 11. Front sun gear | 12. Input shaft |
| 13. Mid internal gear | 14. Front internal gear | 15. Rear carrier |
| 16. Rear sun gear | 17. Mid sun gear | 18. Front carrier |
| 19. Mid carrier | 20. Rear internal gear | 21. Output shaft |
| 22. Parking gear | 23. Parking pawl | |

A/T CONTROL SYSTEM

“D4 ” and “M4” position

- The direct clutch is coupled, and the rear carrier and rear sun gear are connected.
- The high and low reverse clutch is coupled, and the mid sun gear and rear sun gear are connected.
- The input clutch is coupled, and the front internal gear and mid internal gear are connected.
- The drive power is conveyed to the front internal gear, mid internal gear, and rear carrier and the three planetary gears rotate forward as one unit.




SCIA1517E

- | | | |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake | 2. Input clutch | 3. Direct clutch |
| 4. High and low reverse clutch | 5. Reverse brake | 6. Forward brake |
| 7. Low coast brake | 8. 1st one-way clutch | 9. Forward one-way clutch |
| 10. 3rd one-way clutch | 11. Front sun gear | 12. Input shaft |
| 13. Mid internal gear | 14. Front internal gear | 15. Rear carrier |
| 16. Rear sun gear | 17. Mid sun gear | 18. Front carrier |
| 19. Mid carrier | 20. Rear internal gear | 21. Output shaft |
| 22. Parking gear | 23. Parking pawl | |

A/T CONTROL SYSTEM

“D5 ” and “M5” position

- The front brake fastens the front sun gear.
- The input clutch is coupled, and the front internal gear and mid internal gear are connected.
- The high and low reverse clutch is coupled, and the mid sun gear and rear sun gear are connected.




- | | | |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake | 2. Input clutch | 3. Direct clutch |
| 4. High and low reverse clutch | 5. Reverse brake | 6. Forward brake |
| 7. Low coast brake | 8. 1st one-way clutch | 9. Forward one-way clutch |
| 10. 3rd one-way clutch | 11. Front sun gear | 12. Input shaft |
| 13. Mid internal gear | 14. Front internal gear | 15. Rear carrier |
| 16. Rear sun gear | 17. Mid sun gear | 18. Front carrier |
| 19. Mid carrier | 20. Rear internal gear | 21. Output shaft |
| 22. Parking gear | 23. Parking pawl | |

A/T CONTROL SYSTEM

“R” position

- The front brake fastens the front sun gear.
- The high and low reverse clutch is coupled, and the mid sun gear and rear sun gear are connected.
- The reverse brake fastens the rear carrier.



- | | | |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake | 2. Input clutch | 3. Direct clutch |
| 4. High and low reverse clutch | 5. Reverse brake | 6. Forward brake |
| 7. Low coast brake | 8. 1st one-way clutch | 9. Forward one-way clutch |
| 10. 3rd one-way clutch | 11. Front sun gear | 12. Input shaft |
| 13. Mid internal gear | 14. Front internal gear | 15. Rear carrier |
| 16. Rear sun gear | 17. Mid sun gear | 18. Front carrier |
| 19. Mid carrier | 20. Rear internal gear | 21. Output shaft |
| 22. Parking gear | 23. Parking pawl | |

TCM Function

The function of the TCM is to:


- Receive input signals sent from various switches and sensors.
- Determine required line pressure, shifting point, lock-up operation, and engine brake operation.
- Send required output signals to the respective solenoids.

CONTROL SYSTEM OUTLINE

The automatic transmission senses vehicle operating conditions through various sensors or signals. It always controls the optimum shift position and reduces shifting and lock-up shocks.

SENSORS (or SIGNALS)		TCM		ACTUATORS
PNP switch Accelerator pedal position signal Closed throttle position signal Wide open throttle position signal Engine speed signal A/T fluid temperature sensor Revolution sensor Vehicle speed signal Manual mode switch signal Stop lamp switch signal Turbine revolution sensor	⇒	Shift control Line pressure control Lock-up control Engine brake control Timing control Fail-safe control Self-diagnosis CONSULT-II communication line Duet-EA control CAN system	⇒	Input clutch solenoid valve Direct clutch solenoid valve Front brake solenoid valve High & low reverse clutch solenoid valve Low coast brake solenoid valve Torque converter clutch solenoid valve Line pressure solenoid valve A/T CHECK indicator lamp

CONTROL SYSTEM DIAGRAM



A/T CONTROL SYSTEM

CAN Communication SYSTEM DESCRIPTION

ACS000H6

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only. For details, refer to [LAN-5, "CAN Communication Unit"](#).

Input/Output Signal of TCM

ACS000H7

Control item		Line pressure control	Vehicle speed control	Shift control	Lock-up control	Engine brake control	Fail-safe function (*3)	Self-diagnostics function
Input	Accelerator pedal position signal (*5)	X	X	X	X	X	X	X
	Vehicle speed sensor A/T (revolution sensor)	X	X	X	X		X	X
	Vehicle speed sensor MTR(*1) (*5)	X	X	X	X			X
	Closed throttle position signal(*5)	(*2) X	(*2) X		X	(*2) X		(*4) X
	Wide open throttle position signal(*5)	(*2) X	(*2) X			(*2) X		(*4) X
	Turbine revolution sensor 1	X	X		X		X	X
	Turbine revolution sensor 2 (for 4th speed only)	X	X		X		X	X
	Engine speed signals(*5)				X			X
	PNP switch	X	X	X	X	X	X	(*4) X
	Stop lamp switch signal(*5)		X			X		(*4) X
	A/T fluid temperature sensors 1, 2	X	X	X	X	X	X	X
	ASCD	Operation signal(*5)	X	X	X	X		
		Overdrive cancel signal(*5)	X		X	X		
	TCM power supply voltage signal	X	X	X	X	X		X
Output	Direct clutch solenoid (ATF pressure switch 5)		X	X			X	X
	Input clutch solenoid (ATF pressure switch 3)		X	X			X	X
	High and low reverse clutch solenoid (ATF pressure switch 6)		X	X			X	X
	Front brake solenoid (ATF pressure switch 1)		X	X			X	X
	Low coast brake solenoid (ATF pressure switch 2)		X	X		X	X	X
	Line pressure solenoid	X	X	X	X	X	X	X
	TCC solenoid				X		X	X
	Self-diagnostics table(*5)							X
	Starter relay						X	X

*1: Spare for vehicle speed sensor-A/T (revolution sensor)

*2: Spare for accelerator pedal position signal

*3: If these input and output signals are different, the TCM triggers the fail-safe function.


*4: Used as a condition for starting self-diagnostics; if self-diagnostics are not started, it is judged that there is some kind of error.

*5: CAN communications

Line Pressure Control

ACS000HB

- When an input torque signal equivalent to the engine drive force is sent from the ECM to the TCM, the TCM controls the line pressure solenoid.
- This line pressure solenoid controls the pressure regulator valve as the signal pressure and adjusts the pressure of the operating oil discharged from the oil pump to the line pressure most appropriate to the driving state.




LINE PRESSURE CONTROL IS BASED ON THE TCM LINE PRESSURE CHARACTERISTIC PATTERN

- The TCM has stored in memory a number of patterns for the optimum line pressure characteristic for the driving state.
- In order to obtain the most appropriate line pressure characteristic to meet the current driving state, the TCM controls the line pressure solenoid current valve and thus controls the line pressure.


Normal Control

Each clutch is adjusted to the necessary pressure to match the engine drive force.



Back-up Control (Engine Brake)


When the select operation is executed during driving and the transmission is shifted down, the line pressure is set according to the vehicle speed.



A/T CONTROL SYSTEM


During Shift Change

The necessary and adequate line pressure for shift change is set. For this reason, line pressure pattern setting corresponds to input torque and gearshift selection. Also, line pressure characteristic is set according to engine speed, during engine brake operation.



At Low Fluid Temperature


When the A/T fluid temperature drops below the prescribed temperature, in order to speed up the action of each friction element, the line pressure is set higher than the normal line pressure characteristic.



Shift Control

ACS000H9


The clutch pressure control solenoid is controlled by the signals from the switches and sensors. Thus, the clutch pressure is adjusted to be appropriate to the engine load state and vehicle driving state. It becomes possible to finely control the clutch hydraulic pressure with high precision and a smoother shift change characteristic is attained.



SHIFT CHANGE

The clutch is controlled with the optimum timing and oil pressure by the engine speed, engine torque information, etc.

Shift change system diagram



*1: Full phase real-time feedback control monitors movement of gear ratio at gear change, and controls oil pressure at real-time to achieve the best gear ratio.

Lock-Up Control

ACS000HA

The torque converter clutch piston in the torque converter is engaged to eliminate torque converter slip to increase power transmission efficiency.


The torque converter clutch control valve operation is controlled by the torque converter clutch solenoid valve, which is controlled by a signal from TCM, and the torque converter clutch control valve engages or releases the torque converter clutch piston.

Lock-up Operation Condition Table

selector lever	D position		M5 position	M4 position	M3 position	M2 position
Gear position	5	4	5	4	3	2
Lock-up	×	—	×	×	×	×
Slip lock-up	×	×	—	—	—	—

TORQUE CONVERTER CLUTCH CONTROL VALVE CONTROL

Lock-up control system diagram



Lock-up released

- In the lock-up released state, the torque converter clutch control valve is set into the unlocked state by the torque converter clutch solenoid and the lock-up apply pressure is drained. In this way, the torque converter clutch piston is not coupled.

A/T CONTROL SYSTEM

Lock-up applied

- In the lock-up applied state, the torque converter clutch control valve is set into the locked state by the torque converter clutch solenoid and lock-up apply pressure is generated.
In this way, the torque converter clutch piston is pressed and coupled.

SMOOTH LOCK-UP CONTROL

When shifting from the lock-up released state to the lock-up applied state, the current output to the torque converter clutch solenoid is controlled with the TCM. In this way, when shifting to the lock-up applied state, the torque converter clutch is temporarily set to the half-clutched state to reduce the shock.

Half-clutched state

- The current output from the TCM to the torque converter clutch solenoid is varied to gradually increase the torque converter clutch solenoid pressure.
In this way, the lock-up apply pressure gradually rises and while the torque converter clutch piston is put into half-clutched status, the torque converter clutch piston operating pressure is increased and the coupling is completed smoothly.


Slip lock-up control

- In the slip region, the torque converter clutch solenoid current is controlled with the TCM to put it into the half-clutched state. This absorbs the engine torque fluctuation and lock-up operates from low speed. This raises the fuel efficiency for 4th and 5th gears at both low speed and when the accelerator has a low degree of opening.

Engine Brake Control

ACS000HB

- The forward one-way clutch transmits the drive force from the engine to the rear wheels. But the reverse drive from the rear wheels is not transmitted to the engine because the one-way clutch is idling. Therefore, the low coast brake solenoid is operated to prevent the forward one-way clutch from idling and the engine brake is operated in the same manner as conventionally.



SCIA1520E

- The operation of the low coast brake solenoid switches the low coast brake switching valve and controls the coupling and releasing of the low coast brake. The low coast brake reducing valve controls the low coast brake coupling force.

Control Valve

FUNCTION OF CONTROL VALVE

ACS000HC

Name	Function
Torque converter regulator valve	In order to prevent the pressure supplied to the torque converter from being excessive, the line pressure is adjusted to the optimum pressure (torque converter operating pressure).
Pressure regulator valve Pressure regulator plug Pressure regulator sleeve	Adjusts the oil discharged from the oil pump to the optimum pressure (line pressure) for the driving state.
Front brake control valve	When the front brake is coupled, adjusts the line pressure to the optimum pressure (front brake pressure) and supplies it to the front brake. (In 1st, 2nd, 3rd, and 5th gears, adjusts the clutch pressure.)
Accumulator control valve	Adjusts the pressure (accumulator control pressure) acting on the accumulator piston and low coast reducing valve to the pressure appropriate to the driving state.
Pilot valve A	Adjusts the line pressure and produces the constant pressure (pilot pressure) required for line pressure control, shift change control, and lock-up control.
Pilot valve B	Adjusts the line pressure and produces the constant pressure (pilot pressure) required for shift change control.
Low coast brake switching valve	During engine braking, supplies the line pressure to the low coast brake reducing valve.
Low coast brake reducing valve	When the low coast brake is coupled, adjusts the line pressure to the optimum pressure (low coast brake pressure) and supplies it to the low coast brake.
N-R accumulator	Produces the stabilizing pressure for when N-R is selected.
Direct clutch piston switching valve	Operates in 4th gear and switches the direct clutch coupling capacity.
High and low reverse clutch control valve	When the high and low reverse clutch is coupled, adjusts the line pressure to the optimum pressure (high and low reverse clutch pressure) and supplies it to the high and low reverse clutch. (In 1st, 3rd, 4th and 5th gears, adjusts the clutch pressure.)

A/T CONTROL SYSTEM

Name	Function
Input clutch control valve	When the input clutch is coupled, adjusts the line pressure to the optimum pressure (input clutch pressure) and supplies it to the input clutch. (In 4th and 5th gears, adjusts the clutch pressure.)
Direct clutch control valve	When the direct clutch is coupled, adjusts the line pressure to the optimum pressure (direct clutch pressure) and supplies it to the direct clutch. (In 2nd, 3rd, and 4th gears, adjusts the clutch pressure.)
TCC control valve TCC control plug TCC control sleeve	Switches the lock-up to operating or released. Also, by executing the lock-up operation transiently, lock-up smoothly.
Torque converter lubrication valve	Operates during lock-up to switch the torque converter, cooling, and lubrication system oil path.
Cool bypass valve	Allows excess oil to bypass cooler circuit without being fed into it.
Line pressure relief valve	Discharges excess oil from line pressure circuit.
N-D accumulator	Produces the stabilizing pressure for when N-D is selected.
Manual valve	Sends line pressure to each circuit according to the select position. The circuits to which the line pressure is not sent drain.

FUNCTION OF ATF PRESSURE SWITCH

Name	Function
ATF pressure switch 1 (FR/B)	Detects any malfunction in the front brake hydraulic pressure. When it detects any malfunction, it puts the system into fail-safe mode.
ATF pressure switch 2 (LC/B)	Detects any malfunction in the low coast brake hydraulic pressure. When it detects any malfunction, it puts the system into fail-safe mode.
ATF pressure switch 3 (I/C)	Detects any malfunction in the input clutch hydraulic pressure. When it detects any malfunction, it puts the system into fail-safe mode.
ATF pressure switch 5 (D/C)	Detects any malfunction in the direct clutch hydraulic pressure. When it detects any malfunction, it puts the system into fail-safe mode.
ATF pressure switch 6 (HLR/C)	Detects any malfunction in the high & low reverse clutch hydraulic pressure. When it detects any malfunction, it puts the system into fail-safe mode.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

PPF:00028

Introduction

ACS000HD

The A/T system has two self-diagnostic systems.

The first is the emission-related on board diagnostic system (OBD-II) performed by the TCM in combination with the ECM. The malfunction is indicated by the MIL (malfunction indicator lamp) and is stored as a DTC in the ECM memory but not the TCM memory.

The second is the TCM original self-diagnosis indicated by the A/T CHECK indicator lamp. The malfunction is stored in the TCM memory. The detected items are overlapped with OBD-II self-diagnostic items. For detail, refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#).

OBD-II Function for A/T System

ACS000HE

The ECM provides emission-related on board diagnostic (OBD-II) functions for the A/T system. One function is to receive a signal from the TCM used with OBD-related parts of the A/T system. The signal is sent to the ECM when a malfunction occurs in the corresponding OBD-related part. The other function is to indicate a diagnostic result by means of the MIL (malfunction indicator lamp) on the instrument panel. Sensors, switches and solenoid valves are used as sensing elements.

The MIL automatically illuminates in One or Two Trip Detection Logic when a malfunction is sensed in relation to A/T system parts.

One or Two Trip Detection Logic of OBD-II

ACS000HF

ONE TRIP DETECTION LOGIC

If a malfunction is sensed during the first test drive, the MIL will illuminate and the malfunction will be stored in the ECM memory as a DTC. The TCM is not provided with such a memory function.

TWO TRIP DETECTION LOGIC

When a malfunction is sensed during the first test drive, it is stored in the ECM memory as a 1st trip DTC (diagnostic trouble code) or 1st trip freeze frame data. At this point, the MIL will not illuminate. — First Trip

If the same malfunction as that experienced during the first test drive is sensed during the second test drive, the MIL will illuminate. — Second Trip

The "trip" in the "One or Two Trip Detection Logic" means a driving mode in which self-diagnosis is performed during vehicle operation.

OBD-II Diagnostic Trouble Code (DTC)

ACS000HG

HOW TO READ DTC AND 1ST TRIP DTC

DTC and 1st trip DTC can be read by the following methods.

(with **CONSULT-II** or (**GST**) CONSULT-II or GST (Generic Scan Tool) Examples: P0705, P0720 etc. These DTC are prescribed by SAE J2012.

(CONSULT-II also displays the malfunctioning component or system.)

- **1st trip DTC No. is the same as DTC No.**
- **Output of the diagnostic trouble code indicates that the indicated circuit has a malfunction. However, in case of the Mode II and GST, they do not indicate whether the malfunction is still occurring or occurred in the past and returned to normal.**
CONSULT-II can identify them as shown below, therefore, CONSULT-II (if available) is recommended.

A sample of CONSULT-II display for DTC and 1st trip DTC is shown on the next page. DTC or 1st trip DTC of a malfunction is displayed in SELF-DIAGNOSTIC RESULTS mode for "ENGINE" with CONSULT-II. Time data indicates how many times the vehicle was driven after the last detection of a DTC.

SELECT SYSTEM
A/T
ENGINE

SAT014K

ON BOARD DIAGNOSTIC (OBD) SYSTEM

If the DTC is being detected currently, the time data will be "0".

SELF-DIAG RESULTS	
DTC RESULTS	TIME
PNP SW/CIRC [P0705]	0

SAT015K

If a 1st trip DTC is stored in the ECM, the time data will be "1 t".

SELF-DIAG RESULTS	
DTC RESULTS	TIME
PNP SW/CIRC [P0705]	1 t

SAT016K

Freeze frame data and 1st trip freeze frame data

The ECM has a memory function, which stores the driving condition such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed and vehicle speed at the moment the ECM detects a malfunction.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data, and the data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-II or GST. The 1st trip freeze frame data can only be displayed on the CONSULT-II screen, not on the GST. For detail, refer to [EC-104, "CONSULT-II Function"](#).

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MIL on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM. The ECM has the following priorities to update the data.

Priority	Items	
1	Freeze frame data	Misfire — DTC: P0300 - P0306 Fuel Injection System Function — DTC: P0171, P0172, P0174, P0175
2		Except the above items (Includes A/T related items)
3	1st trip freeze frame data	

Both 1st trip freeze frame data and freeze frame data (along with the DTC) are cleared when the ECM memory is erased.

HOW TO ERASE DTC

The diagnostic trouble code can be erased by CONSULT-II, GST or ECM DIAGNOSTIC TEST MODE as described following.

- If the battery cable is disconnected, the diagnostic trouble code will be lost within 24 hours.
- When you erase the DTC, using CONSULT-II or GST is easier and quicker than switching the mode selector on the ECM.

The following emission-related diagnostic information is cleared from the ECM memory when erasing DTC related to OBD-II. For details, refer to [EC-48, "Emission-related Diagnostic Information"](#).

- Diagnostic trouble codes (DTC)
- 1st trip diagnostic trouble codes (1st trip DTC)
- Freeze frame data

ON BOARD DIAGNOSTIC (OBD) SYSTEM

- 1st trip freeze frame data
- System readiness test (SRT) codes
- Test values

HOW TO ERASE DTC (WITH CONSULT-II)

- If a DTC is displayed for both ECM and TCM, it is necessary to be erased for both ECM and TCM.
1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 10 seconds and then turn it "ON" (engine stopped) again.
 2. Turn CONSULT-II "ON" and touch "A/T".
 3. Touch "SELF-DIAG RESULTS".
 4. Touch "ERASE". (The DTC in the TCM will be erased.) Then touch "BACK" twice.
 5. Touch "ENGINE".
 6. Touch "SELF-DIAG RESULTS".
 7. Touch "ERASE". (The DTC in the ECM will be erased.)

How to erase DTC (With CONSULT-II)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 10 seconds and then turn it "ON" (engine stopped) again.

SELECT SYSTEM
A/T
ENGINE

2. Turn CONSULT-II "ON", and touch "A/T".

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
DTC WORK SUPPORT
ECU PART NUMBER

3. Touch "SELF-DIAG RESULTS".

SELF-DIAG RESULTS
DTC RESULTS
TCC SOLENOID/CIRC [P0740]

4. Touch "ERASE". (The DTC in the TCM will be erased.)

SELECT SYSTEM
A/T
ENGINE

5. Touch "ENGINE".

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

6. Touch "SELF-DIAG RESULTS".

SELF-DIAG RESULTS	
DTC RESULTS	TIME
TCC SOLENOID/CIRC [P0740]	0

7. Touch "ERASE". (The DTC in the ECM will be erased.)

SCIA1477E

HOW TO ERASE DTC (WITH GST)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 10 seconds and then turn it "ON" (engine stopped) again.
2. Perform "TCM SELF-DIAGNOSTIC PROCEDURE (No Tools)". Refer to [AT-86, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#). (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
3. Select Mode 4 with Generic Scan Tool (GST). For details, refer to [EC-117, "Generic Scan Tool \(GST\) Function"](#).

ON BOARD DIAGNOSTIC (OBD) SYSTEM



HOW TO ERASE DTC (NO TOOLS)

The A/T CHECK indicator lamp is located on the instrument panel.


1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 10 seconds and then turn it "ON" (engine stopped) again.
2. Perform "TCM SELF-DIAGNOSTIC PROCEDURE (No Tools)". Refer to [AT-86. "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#). (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
3. Perform "OBD-II SELF-DIAGNOSTIC PROCEDURE (No tools)". Refer to [EC-61. "How to Erase DTC"](#).

Malfunction Indicator Lamp (MIL) DESCRIPTION

ACS000HH

The MIL is located on the instrument panel.

1. The MIL will light up when the ignition switch is turned "ON" without the engine running. This is a bulb check.
 - If the MIL does not light up, refer to [DI-65. "WARNING LAMPS"](#), or see [EC-672. "MIL AND DATA LINK CONNECTOR"](#).
2. When the engine is started, the MIL should go off. If the MIL remains on, the on board diagnostic system has detected an engine system malfunction.



TROUBLE DIAGNOSIS

PFP:00004

DTC Inspection Priority Chart

ACS000HI

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

NOTE:

If DTC U1000 is displayed with other DTCs, first perform the trouble diagnosis for DTC U1000. Refer to [AT-88](#).

Priority	Detected items (DTC)
1	U1000 CAN communication line
2	Except above

Fail-Safe

ACS000HJ

The TCM has an electrical fail-safe mode. This mode makes it possible to operate even if there is a an error in a main electronic control input/output signal circuit.

In fail-safe mode, even if the selector lever is "D" or "M" mode, the transmission is fixed in 2nd or 4th (depending on the breakdown position), so the customer should feel "slipping" or "poor acceleration". When fail-safe mode is triggered, when the ignition switch is switched "ON", the A/T CHECK indicator lamp flashes for about 8 seconds. (Refer to [AT-86, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#)).

Even when the electronic circuits are normal, under special conditions (for example, when slamming on the brake with the wheels spinning drastically and stopping the tire rotation), the transmission can go into fail-safe mode. If this happens, switch "OFF" the ignition switch for 10 seconds, then switch it "ON" again to return to the normal shift pattern. Also, the A/T CHECK indicator lamp flashes for about 8 seconds once, then is cleared. Therefore, the customer's vehicle has returned to normal, so handle according to the "diagnostics flow" (Refer to [AT-42](#)).

FAIL-SAFE FUNCTION

If any malfunction occurs in a sensor or solenoid, this function controls the A/T to mark driving possible.

Vehicle speed sensor A/T (revolution sensor)

- Signals are input from two systems - from vehicle speed sensor A/T (revolution sensor) installed on the transmission and from combination meter so normal driving is possible even if there is a malfunction in one of the systems. And if vehicle speed sensor A/T (revolution sensor) has unusual cases, 5th gear and manual mode are prohibited.

Accelerator pedal position sensor

- If there is a malfunction in one of the systems, the accelerator opening angle is controlled by ECM according to a pre-determined accelerator angle to make driving possible. And if there are malfunctions in tow systems, the engine speed is fixed by ECM to a pre-determined engine speed to make driving possible.

Throttle position sensor

- If there is a malfunction in one of the systems, the accelerator opening angle is controlled by ECM according to a pre-determined accelerator angle to make driving possible. And if there are malfunctions in tow systems, the accelerator opening angle is controlled by the idle signal sent from the ECM which is based on input indicating either idle condition or off-idle condition (pre-determined accelerator opening) in order to make driving possible.

PNP switch

- In the unlikely event that a malfunction signal enters the TCM, the position indicator is switched "OFF", the starter relay is switched "OFF" (starter starting is disabled), the back-up lamp relay switched "OFF" (back-up lamp is OFF) and the position is fixed to the "D" range to make driving possible.

Starter relay

- The starter relay is switched "OFF". (Starter starting is disabled.)

TROUBLE DIAGNOSIS

A/T Interlock

- If there is an A/T interlock judgment malfunction, the transmission is fixed in 2nd gear to make driving possible.

NOTE:

When the vehicle is driven fixed in 2nd gear a turbine revolution sensor malfunction is displayed, but this is not a turbine revolution sensor malfunction.

- When the coupling pattern below is detected, the fail-safe action corresponding to the pattern is executed.

A/T INTERLOCK COUPLING PATTERN TABLE

●: NG X: OK

Gear position		ATF pressure switch output					Fail-safe function	Clutch pressure output pattern after fail-safe function					
		SW3 (I/C)	SW6 (HLR/C)	SW5 (D/C)	SW1 (FR/B)	SW2 (LC/B)		I/C	HLR/C	D/C	FR/B	LC/B	L/U
A/T inter-lock coupling pattern	3rd	—	X	X	—	●	Held in 2nd gear	OFF	OFF	ON	OFF	OFF	OFF
	4th	—	X	X	—	●	Held in 2nd gear	OFF	OFF	ON	OFF	OFF	OFF
	5th	X	X	—	X	●	Held in 2nd gear	OFF	OFF	ON	OFF	OFF	OFF

A/T 1st engine braking

- When there is an A/T first gear engine brake judgment malfunction, the low coast brake solenoid is switched “OFF” to avoid the engine brake operation.

Line pressure solenoid

- The solenoid is switched “OFF” and the line pressure is set to the maximum hydraulic pressure to make driving possible.

Torque converter clutch solenoid

- The solenoid is switched “OFF” to release the lock-up.

Low coast brake solenoid

- When a (electrical or functional) malfunction occurs, in order to make driving possible, if the solenoid is “ON”, the transmission is held in 2nd gear; if the solenoid is “OFF”, the transmission is held in 4th gear. (engine brake is not applied in 1st and 2nd gear.)

Input clutch solenoid

- If a (electrical or functional) malfunction occurs with the solenoid either “ON” or “OFF”, the transmission is held in 4th gear to make driving possible.

Direct clutch solenoid

- If a (electrical or functional) malfunction occurs with the solenoid either “ON” or “OFF”, the transmission is held in 4th gear to make driving possible.

Front brake solenoid

- If a (electrical or functional) malfunction occurs with the solenoid “ON”, in order to make driving possible, the A/T is held in 5th gear; if the solenoid is OFF, 4th gear.

High and low reverse clutch solenoid

- If a (electrical or functional) malfunction occurs with the solenoid either “ON” or “OFF”, the transmission is held in 4th gear to make driving possible.

Turbine revolution sensor 1 or 2

- The control is the same as if there were no turbine revolution sensors, 5th gear and manual mode are prohibited.

TROUBLE DIAGNOSIS


How To Perform Trouble Diagnosis For Quick and Accurate Repair INTRODUCTION

ACS000HK

The TCM receives a signal from the vehicle speed sensor, accelerator pedal position sensor (throttle position sensor) or PNP switch and provides shift control or lock-up control via A/T solenoid valves.


The TCM also communicates with the ECM by means of a signal sent from sensing elements used with the OBD-related parts of the A/T system for malfunction-diagnostic purposes. The TCM is capable of diagnosing malfunctioning parts while the ECM can store malfunctions in its memory.

Input and output signals must always be correct and stable in the operation of the A/T system. The A/T system must be in good operating condition and be free of valve seizure, solenoid valve malfunction, etc.



It is much more difficult to diagnose a error that occurs intermittently rather than continuously. Most intermittent errors are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.


A visual check only may not find the cause of the errors. A road test with CONSULT-II (or GST) or a circuit tester connected should be performed. Follow the [AT-42. "WORK FLOW"](#) .



Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such errors, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" as shown on the example (Refer to [AT-43](#)) should be used.

Start your diagnosis by looking for "conventional" errors first. This will help troubleshoot driveability errors on an electronically controlled engine vehicle.

Also check related Service bulletins.




TROUBLE DIAGNOSIS

WORK FLOW

A good understanding of the malfunction conditions can make troubleshooting faster and more accurate. In general, each customer feels differently about a malfunction. It is important to fully understand the symptoms or conditions for a customer complaint. Make good use of the two sheets provided, "Information From Customer" (Refer to [AT-43](#)) and "Diagnostic Worksheet" (Refer to [AT-43](#)), to perform the best troubleshooting possible.

Work flow chart



*1. [AT-43](#)

*4. [AT-55](#)

*7. [AT-77](#)

*10. [AT-88](#)

*13. [AT-198](#)

*16. [AT-88](#)

*2. [AT-43](#)

*5. [AT-56](#), [AT-57](#)

*8. [AT-35](#)

*11. [AT-176](#)

*14. [AT-65](#)

*17. [AT-172](#)

*3. [AT-39](#)

*6. [AT-59](#)

*9. [AT-86](#)

*12. [AT-177](#)

*15. [AT-36](#)

*18. [EC-48](#)

SCIA4968E

A

DIAGNOSTIC WORKSHEET

Information from customer

KEY POINTS

- **WHAT.....** Vehicle & A/T model
- **WHEN.....** Date, Frequencies
- **WHERE.....** Road conditions
- **HOW.....** Operating conditions, Symptoms

B

AT

Customer name	MR/MS	Model & Year	VIN
Trans. Model		Engine	Mileage
Incident Date		Manuf. Date	In Service Date
Frequency		<input type="checkbox"/> Continuous <input type="checkbox"/> Intermittent (times a day)	
Symptoms		<input type="checkbox"/> Vehicle does not move. (<input type="checkbox"/> Any position <input type="checkbox"/> Particular position)	
		<input type="checkbox"/> No up-shift (<input type="checkbox"/> 1st → 2nd <input type="checkbox"/> 2nd → 3rd <input type="checkbox"/> 3rd → 4th <input type="checkbox"/> 4th → 5th)	
		<input type="checkbox"/> No down-shift (<input type="checkbox"/> 5th → 4th <input type="checkbox"/> 4th → 3rd <input type="checkbox"/> 3rd → 2nd <input type="checkbox"/> 2nd → 1st)	
		<input type="checkbox"/> Lock-up malfunction	
		<input type="checkbox"/> Shift point too high or too low.	
		<input type="checkbox"/> Shift shock or slip (<input type="checkbox"/> N → D <input type="checkbox"/> Lock-up <input type="checkbox"/> Any drive position)	
		<input type="checkbox"/> Noise or vibration	
		<input type="checkbox"/> No kick down	
		<input type="checkbox"/> No pattern select	
		<input type="checkbox"/> Others ()	
A/T CHECK indicator lamp		Blinks for about 8 seconds.	
		<input type="checkbox"/> Continuously lit	<input type="checkbox"/> Not lit
Malfunction indicator lamp (MIL)		<input type="checkbox"/> Continuously lit	<input type="checkbox"/> Not lit

D

E

F

G

H

1

J

Diagnostic worksheet chart

1	<input type="checkbox"/> Read the item on “cautions concerning fail-safe and understand the customer's complaint.			AT-39
2	<input type="checkbox"/> A/T fluid inspection			AT-55
		<input type="checkbox"/> Leak (Repair leak location.) <input type="checkbox"/> State <input type="checkbox"/> Amount		
3	<input type="checkbox"/> Stall test and line pressure test			AT-56, AT-57
		<input type="checkbox"/> Stall test		
		<input type="checkbox"/> Torque converter one-way clutch <input type="checkbox"/> Front brake <input type="checkbox"/> High and low reverse clutch <input type="checkbox"/> Low coast brake <input type="checkbox"/> Forward brake <input type="checkbox"/> Reverse brake <input type="checkbox"/> Forward one-way clutch	<input type="checkbox"/> 1st one-way clutch <input type="checkbox"/> 3rd one-way clutch <input type="checkbox"/> Engine <input type="checkbox"/> Line pressure low <input type="checkbox"/> Except for input clutch and direct clutch, clutches and brakes OK	
	<input type="checkbox"/> Line pressure inspection - Suspected part:			

K

L

M

TROUBLE DIAGNOSIS

<input type="checkbox"/> Execute all road tests and enter checks in required inspection items.		AT-59
4	4-1. Check before engine is started	AT-59
	<input type="checkbox"/> The A/T CHECK Indicator Lamp does come on. AT-177 . <input type="checkbox"/> Execute self-diagnostics Enter checks for detected items. AT-77 , AT-86	
	<div> <input type="checkbox"/> AT-88, "DTC U1000 CAN COMMUNICATION LINE" . <input type="checkbox"/> AT-90, "DTC P0615 START SIGNAL CIRCUIT" . <input type="checkbox"/> AT-93, "DTC P0700 TCM" . <input type="checkbox"/> AT-94, "DTC P0705 PARK/NEUTRAL POSITION SWITCH" . <input type="checkbox"/> AT-97, "DTC P0720 VEHICLE SPEED SENSOR A/T (REVOLUTION SENSOR)" . <input type="checkbox"/> AT-100, "DTC P0725 ENGINE SPEED SIGNAL" . <input type="checkbox"/> AT-100, "DTC P0725 ENGINE SPEED SIGNAL" . <input type="checkbox"/> AT-102, "DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE" . <input type="checkbox"/> AT-105, "DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)" . <input type="checkbox"/> AT-108, "DTC P0745 LINE PRESSURE SOLENOID VALVE" . <input type="checkbox"/> AT-111, "DTC P1702 TRANSMISSION CONTROL MODULE (RAM)" . <input type="checkbox"/> AT-112, "DTC P1703 TRANSMISSION CONTROL MODULE (ROM)" . <input type="checkbox"/> AT-113, "DTC P1705 THROTTLE POSITION SENSOR" . <input type="checkbox"/> AT-115, "DTC P1710 A/T FLUID TEMPERATURE SENSOR CIRCUIT" . <input type="checkbox"/> AT-118, "DTC P1716 TURBINE REVOLUTION SENSOR" . <input type="checkbox"/> AT-121, "DTC P1721 VEHICLE SPEED SENSOR MTR" . <input type="checkbox"/> AT-123, "DTC P1730 A/T INTERLOCK" . <input type="checkbox"/> AT-126, "DTC P1731 A/T 1ST ENGINE BRAKING" . <input type="checkbox"/> AT-129, "DTC P1752 INPUT CLUTCH SOLENOID VALVE" . <input type="checkbox"/> AT-132, "DTC P1754 INPUT CLUTCH SOLENOID VALVE FUNCTION" . <input type="checkbox"/> AT-135, "DTC P1757 FRONT BRAKE SOLENOID VALVE" . <input type="checkbox"/> AT-138, "DTC P1759 FRONT BRAKE SOLENOID VALVE FUNCTION" . <input type="checkbox"/> AT-141, "DTC P1762 DIRECT CLUTCH SOLENOID VALVE" . <input type="checkbox"/> AT-144, "DTC P1764 DIRECT CLUTCH SOLENOID VALVE FUNCTION" . <input type="checkbox"/> AT-147, "DTC P1767 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE" . <input type="checkbox"/> AT-150, "DTC P1769 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE FUNCTION" . <input type="checkbox"/> AT-153, "DTC P1772 LOW COAST BRAKE SOLENOID VALVE" . <input type="checkbox"/> AT-156, "DTC P1774 LOW COAST BRAKE SOLENOID VALVE FUNCTION" . <input type="checkbox"/> AT-159, "DTC P1815 MANUAL MODE SWITCH" . <input type="checkbox"/> AT-163, "DTC P1841 ATF PRESSURE SWITCH 1" . <input type="checkbox"/> AT-166, "DTC P1843 ATF PRESSURE SWITCH 3" . <input type="checkbox"/> AT-169, "DTC P1845 ATF PRESSURE SWITCH 5" . <input type="checkbox"/> AT-172, "DTC P1846 ATF PRESSURE SWITCH 6" . </div>	
4	4-2. Check at Idle	AT-59
	<input type="checkbox"/> AT-178, "Engine Cannot Be Started In "P" or "N" Position" . <input type="checkbox"/> AT-179, "In "P" Position, Vehicle Moves When Pushed" . <input type="checkbox"/> AT-180, "In "N" Position, Vehicle Moves" . <input type="checkbox"/> AT-181, "Large Shock ("N" to "D" Position)" . <input type="checkbox"/> AT-182, "Vehicle Does Not Creep Backward In "R" Position" . <input type="checkbox"/> AT-183, "Vehicle Does Not Creep Forward In "D" Position" .	
4	4-3. Cruise test	AT-61
	Part 1 <input type="checkbox"/> AT-184, "Vehicle Cannot Be Started From D₁" . <input type="checkbox"/> AT-185, "A/T Does Not Shift: D₁ → D₂" . <input type="checkbox"/> AT-186, "A/T Does Not Shift: D₂ → D₃" . <input type="checkbox"/> AT-187, "A/T Does Not Shift: D₃ → D₄" . <input type="checkbox"/> AT-188, "A/T Does Not Shift: D₄ → D₅" . <input type="checkbox"/> AT-190, "A/T Does Not Perform Lock-up" . <input type="checkbox"/> AT-191, "A/T Does Not Hold Lock-up Condition" . <input type="checkbox"/> AT-191, "Lock-up Is Not Released" . <input type="checkbox"/> AT-192, "Engine Speed Does Not Return To Idle" .	

TROUBLE DIAGNOSIS





4	4-3	Part 2		AT-63
		<div><input type="checkbox"/> AT-184, "Vehicle Cannot Be Started From D1" .</div> <div><input type="checkbox"/> AT-185, "A/T Does Not Shift: D1 → D2" .</div> <div><input type="checkbox"/> AT-186, "A/T Does Not Shift: D2 → D3" .</div> <div><input type="checkbox"/> AT-187, "A/T Does Not Shift: D3 → D4" .</div>		
		Part 3		AT-64
		<div><input type="checkbox"/> AT-193, "Cannot Be changed to Manual Mode" .</div> <div><input type="checkbox"/> AT-193, "A/T Does Not Shift: 5th gear → 4th gear" .</div> <div><input type="checkbox"/> AT-194, "A/T Does Not Shift: 4th gear → 3rd gear" .</div> <div><input type="checkbox"/> AT-195, "A/T Does Not Shift: 3rd gear → 2nd gear" .</div> <div><input type="checkbox"/> AT-197, "A/T Does Not Shift: 2nd gear → 1st gear" .</div> <div><input type="checkbox"/> AT-198, "Vehicle Does Not Decelerate By Engine Brake" .</div> <div><input type="checkbox"/> Execute self-diagnostics Enter checks for detected items. AT-77 , AT-86</div>		
<div><input type="checkbox"/> AT-88, "DTC U1000 CAN COMMUNICATION LINE" .</div> <div><input type="checkbox"/> AT-90, "DTC P0615 START SIGNAL CIRCUIT" .</div> <div><input type="checkbox"/> AT-93, "DTC P0700 TCM" .</div> <div><input type="checkbox"/> AT-94, "DTC P0705 PARK/NEUTRAL POSITION SWITCH" .</div> <div><input type="checkbox"/> AT-97, "DTC P0720 VEHICLE SPEED SENSOR A/T (REVOLUTION SENSOR)" .</div> <div><input type="checkbox"/> AT-100, "DTC P0725 ENGINE SPEED SIGNAL" .</div> <div><input type="checkbox"/> AT-100, "DTC P0725 ENGINE SPEED SIGNAL" .</div> <div><input type="checkbox"/> AT-102, "DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE" .</div> <div><input type="checkbox"/> AT-105, "DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)" .</div> <div><input type="checkbox"/> AT-108, "DTC P0745 LINE PRESSURE SOLENOID VALVE" .</div> <div><input type="checkbox"/> AT-111, "DTC P1702 TRANSMISSION CONTROL MODULE (RAM)" .</div> <div><input type="checkbox"/> AT-112, "DTC P1703 TRANSMISSION CONTROL MODULE (ROM)" .</div> <div><input type="checkbox"/> AT-113, "DTC P1705 THROTTLE POSITION SENSOR" .</div> <div><input type="checkbox"/> AT-115, "DTC P1710 A/T FLUID TEMPERATURE SENSOR CIRCUIT" .</div> <div><input type="checkbox"/> AT-118, "DTC P1716 TURBINE REVOLUTION SENSOR" .</div> <div><input type="checkbox"/> AT-121, "DTC P1721 VEHICLE SPEED SENSOR MTR" .</div> <div><input type="checkbox"/> AT-123, "DTC P1730 A/T INTERLOCK" .</div> <div><input type="checkbox"/> AT-126, "DTC P1731 A/T 1ST ENGINE BRAKING" .</div> <div><input type="checkbox"/> AT-129, "DTC P1752 INPUT CLUTCH SOLENOID VALVE" .</div> <div><input type="checkbox"/> AT-132, "DTC P1754 INPUT CLUTCH SOLENOID VALVE FUNCTION" .</div> <div><input type="checkbox"/> AT-135, "DTC P1757 FRONT BRAKE SOLENOID VALVE" .</div> <div><input type="checkbox"/> AT-138, "DTC P1759 FRONT BRAKE SOLENOID VALVE FUNCTION" .</div> <div><input type="checkbox"/> AT-141, "DTC P1762 DIRECT CLUTCH SOLENOID VALVE" .</div> <div><input type="checkbox"/> AT-144, "DTC P1764 DIRECT CLUTCH SOLENOID VALVE FUNCTION" .</div> <div><input type="checkbox"/> AT-147, "DTC P1767 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE" .</div> <div><input type="checkbox"/> AT-150, "DTC P1769 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE FUNCTION" .</div> <div><input type="checkbox"/> AT-153, "DTC P1772 LOW COAST BRAKE SOLENOID VALVE" .</div> <div><input type="checkbox"/> AT-156, "DTC P1774 LOW COAST BRAKE SOLENOID VALVE FUNCTION" .</div> <div><input type="checkbox"/> AT-159, "DTC P1815 MANUAL MODE SWITCH" .</div> <div><input type="checkbox"/> AT-163, "DTC P1841 ATF PRESSURE SWITCH 1" .</div> <div><input type="checkbox"/> AT-166, "DTC P1843 ATF PRESSURE SWITCH 3" .</div> <div><input type="checkbox"/> AT-169, "DTC P1845 ATF PRESSURE SWITCH 5" .</div> <div><input type="checkbox"/> AT-172, "DTC P1846 ATF PRESSURE SWITCH 6" .</div>				
5	<input type="checkbox"/> Inspect each system for items found to be NG in the self-diagnostics and repair or replace the malfunction parts.			
6	<input type="checkbox"/> Execute all road tests and enter the checks again for the required items.			AT-59
7	<input type="checkbox"/> For any remaining NG items, execute the “diagnostics procedure” and repair or replace the malfunction parts. See the chart for diagnostics by symptoms. (This chart also contains other symptoms and inspection procedures.)			AT-65
8	<input type="checkbox"/> Erase the results of the self-diagnostics from the TCM.			AT-36, AT-87

TROUBLE DIAGNOSIS


A/T Electrical Parts Location

ACS000HL

COUPE MODEL




A/T



Control valve assembly

- TCM
- Turbine revolution sensor 1, 2
- Revolution sensor
- A/T fluid temperature sensor 1, 2
- PNP switch
- Line pressure solenoid valve
- Torque converter clutch solenoid valve
- Direct clutch solenoid valve, ATF pressure SW 5
- High and low reverse clutch solenoid Valve,
- ATF pressure SW 6
- Input clutch solenoid valve,
- ATF pressure SW 3
- Front brake solenoid valve,
- ATF pressure SW 1
- Low coast brake solenoid valve, ATF pressure SW 2



SCIA4859E

TROUBLE DIAGNOSIS

ROADSTER MODEL

A

B

AT

D

E

F

G

H







I

J

K

L

M




- TCM
- Turbine revolution sensor 1, 2
- Revolution sensor
- A/T fluid temperature sensor 1, 2
- PNP switch
- Line pressure solenoid valve
- Torque converter clutch solenoid valve
- Direct clutch solenoid valve, ATF pressure SW 5
- High and low reverse clutch solenoid valve, ATF pressure SW 6
- Input clutch solenoid valve, ATF pressure SW 3
- Front brake solenoid valve, ATF pressure SW 1
- Low coast brake solenoid valve, ATF pressure SW 2

SCIA4969E

TROUBLE DIAGNOSIS

Circuit Diagram

ACS000HM




TCWT0276E

TROUBLE DIAGNOSIS




Wiring Diagram — AT —

ACS001LH

AT-A/T-01



23	22	21	20	19	18	17
32	31	30	29	28	27	26
25	24					





REFER TO THE FOLLOWING.

(F102) -SUPER MULTIPLE JUNCTION (SMJ)


TCWT0253E

TROUBLE DIAGNOSIS


AT-A/T-02




(M8)
W




(E7)
GY



(F3)
GY




(F6)
GY



(F103)
W




REFER TO THE FOLLOWING.

(E108), (F102) -SUPER MULTIPLE JUNCTION (SMJ)




TROUBLE DIAGNOSIS


AT-A/T-04



REFER TO THE FOLLOWING.
(F102) -SUPER MULTIPLE JUNCTION (SMJ)

A
B
AT
D
E
F
G
H
I
J
K
L
M





1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20

(M48)
GY







4	3
2	1

(E111)
W

REFER TO THE FOLLOWING.
(E108) -SUPER MULTIPLE JUNCTION (SMJ)
(E101) -FUSE BLOCK-JUNCTION BOX (J/B)

TROUBLE DIAGNOSIS

TCM terminals and data are reference value. Measured between each terminal and ground.

Terminal	Wire color	Item	Condition		Data (Approx.)
1	R/W	Power supply (Memory back-up)	Always		Battery voltage
2	R/W	Power supply (Memory back-up)	Always		Battery voltage
3	L	CAN-H	-		-
4	PU/W	K-line (CONSULT-II signal)	The terminal is connected to the data link connector for CONSULT-II.		-
5	B	Ground	Always		0V
6	Y/R	Power supply		-	Battery voltage
				-	0V
7	P	Back-up lamp relay		Selector lever in "R" position.	0V
				Selector lever in other positions.	Battery voltage
8	P	CAN-L	-		-
9	GY/R	Starter relay		Selector lever in "N", "P" positions.	Battery voltage
				Selector lever in other positions.	0V
10	B	Ground	Always		0V

Inspections Before Trouble Diagnosis

A/T FLUID CHECK

ACS000HN


Fluid leakage and fluid level check

- Inspect for fluid leakage and check the fluid level. Refer to [AT-10, "Checking A/T Fluid"](#).

Fluid condition check

Inspect the fluid condition.

Fluid condition	Conceivable Cause	Required Operation
Varnished (viscous varnish state)	Clutch, brake scorched	Replace the A/T fluid and check the A/T main unit and the vehicle for malfunctions (wire harnesses, cooler pipes, etc.)
Milky white or cloudy	Water in the fluid	Replace the A/T fluid and check for places where water is getting in.
Large amount of metal powder mixed in	Unusual wear of sliding parts within A/T	Replace the A/T fluid and check for improper operation of the A/T.




TROUBLE DIAGNOSIS


STALL TEST

Stall test procedure

1. Inspect the amount of engine oil. Replenish the engine oil if necessary.
2. Drive for about 10 minutes to warm up the vehicle so that the A/T fluid temperature is 50 to 80°C (122 to 176°F). Inspect the amount of A/T fluid. Replenish if necessary.



3. Securely engage the parking brake so that the tires do not turn.



4. Engine start, apply foot brake, and place selector lever in "D" position.
5. While holding down the foot brake, gradually press down the accelerator pedal.
6. Quickly read off the stall speed, then quickly remove your foot from the accelerator pedal.

CAUTION:


Do not hold down the accelerator pedal for more than 5 seconds during this test.

7. Move the selector lever to the "N" position.
8. Cool down the A/T fluid.

CAUTION:

Run the engine at idle for at least one minute.

Stall speed: 2,650 - 2,950 rpm



Judgement stall test

	Selector lever position		Expected problem location
	D, M	R	
Stall speed	H	O	<ul style="list-style-type: none"> ● Forward brake ● Forward one-way clutch ● 1st one-way clutch ● 3rd one-way clutch
	O	H	<ul style="list-style-type: none"> ● Reverse clutch
	L	L	<ul style="list-style-type: none"> ● Engine and torque converter one-way clutch
	H	H	<ul style="list-style-type: none"> ● Line pressure low

O: Stall speed within standard value position

H: Stall speed higher than standard value

TROUBLE DIAGNOSIS


L: Stall speed lower than standard value

Stall test standard value position

Does not shift up D, M position 1 → 2	Slipping in 2nd, 3rd, 4th gears	Direct clutch slippage
Does not shift up D, M position 2 → 3	Slipping in 3rd, 4th, 5th gears	high and low reverse clutch slippage
Does not shift up D, M position 3 → 4	Slipping in 4th, 5th gears	Input clutch slippage
Does not shift up D, M position 4 → 5	Slipping in 5th gear	Front brake slippage

LINE PRESSURE TEST

Line pressure test port



Line pressure test procedure

1. Inspect the amount of engine oil and replenish if necessary.
2. Drive the car for about 10 minutes to warm it up so that the A/T fluid reaches in range of 50 to 80°C (122 to 176°F), then inspect the amount of A/T fluid and replenish if necessary.


NOTE:

The A/T fluid temperature rises in range of 50 to 80°C (122 to 176°F) during 10 minutes of driving.


3. After warming up remove the oil pressure detection plug and install the oil pressure gauge.

CAUTION:

When using the oil pressure gauge, be sure to use the O-ring attached to the oil pressure detection plug.



4. Securely engage the parking brake so that the tires do not turn.



TROUBLE DIAGNOSIS

5. Start the engine, then measure the line pressure at both idle and the stall speed.

CAUTION:


- Keep the brake pedal pressed all the way down during measurement.
- When measuring the line pressure at the stall speed, refer to [AT-56, "STALL TEST"](#).

6. After the measurements are complete, install the oil pressure detection plug and tighten to the regulation torque below.

 :7.3 N·m (0.74 kg-m, 65 in-lb)

CAUTION:

Do not reuse the O-ring.



Line pressure

Engine speed	Line pressure [kPa (kg/cm ² , psi)]	
	R position	D, M positions
At idle speed	392 - 441 (4.0 - 4.5, 57 - 64)	373 - 422 (3.8 - 4.3, 54 - 61)
At stall speed	1,700 - 1,890 (17.3 - 19.3, 247 - 274)	1,310 - 1,500 (13.3 - 15.3, 190 - 218)

Judgement of line pressure test

Judgement		Possible cause
Idle speed	Low for all positions (P, R, N, D, M)	<p>Possible causes include malfunctions in the pressure supply system and low oil pump output. For example</p> <ul style="list-style-type: none"> ● Oil pump wear ● Pressure regulator valve or plug sticking or spring fatigue ● Oil strainer ⇒ oil pump ⇒ pressure regulator valve passage oil leak ● Engine idle speed too low
	Only low for a specific position	<p>Possible causes include an oil pressure leak in a passage or device related to the position after the pressure is distributed by the manual valve.</p>
	High	<p>Possible causes include a sensor malfunction or malfunction in the line pressure adjustment function. For example</p> <ul style="list-style-type: none"> ● Accelerator pedal position signal malfunction ● ATF temperature sensor malfunction ● Line pressure solenoid malfunction (sticking in "OFF" state, filter clog, cut line) ● Pressure regulator valve or plug sticking
Stall speed	Oil pressure does not rise higher than the oil pressure for idle.	<p>Possible causes include a sensor malfunction or malfunction in the pressure adjustment function. For example</p> <ul style="list-style-type: none"> ● Accelerator pedal position signal malfunction ● TCM breakdown ● Line pressure solenoid malfunction (shorting, sticking in "ON" state) ● Pressure regulator valve or plug sticking ● Pilot valve sticking or pilot filter clogged
	The pressure rises, but does not enter the standard position.	<p>Possible causes include malfunctions in the pressure supply system and malfunction in the pressure adjustment function. For example</p> <ul style="list-style-type: none"> ● Accelerator pedal position signal malfunction ● Line pressure solenoid malfunction (sticking, filter clog) ● Pressure regulator valve or plug sticking ● Pilot valve sticking or pilot filter clogged
	Only low for a specific position	<p>Possible causes include an oil pressure leak in a passage or device related to the position after the pressure is distributed by the manual valve.</p>

TROUBLE DIAGNOSIS

ROAD TEST

Description

- The road test inspects overall performance of the A/T and analyzes possible malfunction causes.
 - The road test is carried out in the following three stages.
1. Check before engine is started. Refer to [AT-59](#) .
 2. Check at idle. Refer to [AT-59](#) .
 3. Cruise test
 - Inspect all the items from Part 1 to Part 3. Refer to [AT-61](#) , [AT-63](#) , [AT-64](#) .
 - Before beginning the road test, check the test procedure and inspection items.
 - Test all inspection items until the symptom is uncovered. Diagnose NG items when all road tests are complete.

Check Before Engine is Started

ACS000HO

1. CHECK A/T CHECK INDICATOR LAMP

1. Park vehicle on level surface.
2. Move selector lever to “P” position.
3. Turn ignition switch “OFF” and wait at least 10 seconds.
4. Turn ignition switch “ON”. (Do not start engine.)

Does A/T CHECK indicator lamp light up for about 2 seconds?

YES >> GO TO 2.

NO >> Stop the road test and go to [AT-177, "A/T CHECK Indicator Lamp Does Not Come On"](#) .

2. CHECK A/T CHECK INDICATOR LAMP

Does A/T CHECK indicator lamp flash for about 8 seconds?

YES >> For TCM fail-safe mode, carry out self-diagnostics and record all NG items on the diagnostics worksheet. Refer to [AT-77](#) , [AT-86](#) .

- NO >> 1. Turn ignition switch “OFF”.
2. Carry out the self-diagnostics and record all NG items on the diagnostics worksheet. Refer to [AT-77](#) , [AT-86](#) .
3. Go to [AT-59, "Check at Idle"](#) .

Check at Idle

ACS000HP

1. CHECK STARTING THE ENGINE

1. Park vehicle on level surface.
2. Move selector lever to “P” or “N” position.
3. Turn ignition switch “OFF”.
4. Turn ignition switch “START”.

Does the engine start?

YES >> GO TO 2.

NO >> Stop the road test and go to [AT-178, "Engine Cannot Be Started In “P” or “N” Position"](#) .

2. CHECK STARTING THE ENGINE

1. Turn ignition switch “ON”. (Do not start engine.)
2. Move selector lever in “D” “M” or “R” position.
3. Turn ignition switch “START”.

Does the engine start in either position?

YES >> Stop the road test and go to [AT-178, "Engine Cannot Be Started In “P” or “N” Position"](#) .

NO >> GO TO 3.

TROUBLE DIAGNOSIS

3. CHECK "P" POSITION FUNCTIONS

1. Move selector lever to "P" position.
2. Turn ignition switch "OFF".
3. Release the parking brake.
4. Push the vehicle forward or backward.
5. Engage the parking brake.

When you push the vehicle with disengaging the parking brake, does it move?

- YES >> Enter a check mark at "In "P" position, Vehicle Moves When Pushed" on the diagnostics worksheet [AT-43](#) , then continue the road test.
- NO >> GO TO 4.

4. CHECK "N" POSITION FUNCTIONS

1. Start the engine.
2. Move selector lever to "N" position.
3. Release the parking brake.

Does vehicle move forward or backward?

- YES >> Enter a check mark at "In "N" position Vehicle Moves" on the diagnostics worksheet [AT-43](#) , then continue the road test.
- NO >> GO TO 5.

5. CHECK SHIFT SHOCK

1. Engage the brake.
2. Move selector lever to "D" position.

When the transmission is shifted from "N" to "D", is there an excessive shock?

- YES >> Enter a check mark at "Large Shock ("N" to "D" Position)" on the diagnostics worksheet [AT-43](#) , then continue the road test.
- NO >> GO TO 6.

6. CHECK "R" POSITION FUNCTIONS

1. Engage the brake.
2. Move selector lever to "R" position.
3. Release the brake for 4 to 5 seconds.

Does the vehicle creep backward?

- YES >> GO TO 7.
- NO >> Enter a check mark at "Vehicle Does Not Creep Backward In "R" Position" on the diagnostics worksheet [AT-43](#) , then continue the road test.

7. CHECK "D" POSITION FUNCTIONS

Inspect whether the vehicle moves forward when the transmission is put into the "D" position.

Does the vehicle move forward in the "D" positions?

- YES >> Go to [AT-61, "Cruise Test - Part 1"](#) , [AT-63, "Cruise Test - Part 2"](#) and [AT-64, "Cruise Test - Part 3"](#)
- NO >> Enter a check mark at "Vehicle Does not Creep Forward In "D" Position" on the diagnostics worksheet [AT-43](#) , then continue the road test. Go to [AT-61](#) , [AT-63](#) and [AT-64](#) .

Cruise Test - Part 1

Cruise test Part 1

1. CHECK STARTING OUT FROM D1

1. Drive the vehicle for about 10 minutes to warm up the engine oil and A/T fluid.
Appropriate temperature for the A/T fluid: 50 - 80°C (122 - 176°F)
2. Park the vehicle on a level surface.
3. Move selector lever to "P" position.
4. Start the engine.
5. Move selector lever to "D" position.
6. Press the accelerator pedal about half way down to accelerate the vehicle.

With CONSULT-II

Read off the gear positions. Refer to [AT-80, "DATA MONITOR MODE"](#).

Starts from D1?

YES >> GO TO 2.

NO >> Enter a check mark at "Vehicle Cannot Be Started From D1" on the diagnostics worksheet [AT-43](#), then continue the road test.

2. CHECK SHIFT UP D1 → D2

Press down the accelerator pedal about half way and inspect if the vehicle shifts up (D1 → D2) at the appropriate speed.

- Refer to [AT-65](#).

With CONSULT-II

Read the gear position, throttle degree of opening, and vehicle speed. Refer to [AT-80, "DATA MONITOR MODE"](#).

Does the A/T shift up D1 → D2 at the correct speed?

YES >> GO TO 3.

NO >> Enter a check mark at "A/T Does Not Shift:D1 → D2" on the diagnostics worksheet [AT-43](#), then continue the road test.

3. CHECK SHIFT UP D2 → D3

Press down the accelerator pedal about half way and inspect if the vehicle shifts up (D2 → D3) at the appropriate speed.

- Refer to [AT-65](#).

With CONSULT-II

Read the gear position, throttle degree of opening, and vehicle speed. Refer to [AT-80, "DATA MONITOR MODE"](#).

Does the A/T shift up D2 → D3 at the correct speed?

YES >> GO TO 4.

NO >> Enter a check mark at "A/T Does Not Shift:D2 → D3" on the diagnostics worksheet [AT-43](#), then continue the road test.

TROUBLE DIAGNOSIS

4. CHECK SHIFT UP D3 → D4

Press down the accelerator pedal about half way and inspect if the vehicle shifts up (D3 → D4) at the appropriate speed.

- Refer to [AT-65](#) .

④ **With CONSULT-II**

Read the gear position, throttle degree of opening, and vehicle speed. Refer to Data [AT-80, "DATA MONITOR MODE"](#) .

Does the A/T shift up D3 → D4 at the correct speed?

YES >> GO TO 5.

NO >> Enter a check mark at "A/T Does Not Shift:D3 → D4" on the diagnostics worksheet [AT-43](#) , then continue the road test.

5. CHECK SHIFT UP D4 → D5

Press down the accelerator pedal about half way and inspect if the vehicle shifts up (D4 → D5) at the appropriate speed.

- Refer to [AT-65](#) .

④ **With CONSULT-II**

Read the gear position, throttle degree of opening, and vehicle speed. Refer to [AT-80, "DATA MONITOR MODE"](#) .

Does the A/T shift up D4 → D5 at the correct speed?

YES >> GO TO 6.

NO >> Enter a check mark at "A/T Does Not Shift:D4 → D5" on the diagnostics worksheet [AT-43](#) , then continue the road test.

6. CHECK LOCK-UP

When releasing accelerator pedal from D5, check lock-up from D5 to L/U.

- Refer to [AT-65](#) .

④ **With CONSULT-II**

Select "TCC SOL 0.00A" with the "MAIN SIGNAL" mode for "A/T". Refer to [AT-75, "CONSULT-II REFERENCE VALUE"](#) .

Does it lock-up?

YES >> GO TO 7.

NO >> Enter a check mark at "A/T Does Not Perform Lock-up" on the diagnostics worksheet [AT-43](#) , then continue the road test.

7. CHECK LOCK-UP HOLD

Check hold lock-up.

④ **With CONSULT-II**

Select "TCC SOL 0.00A" with the "MAIN SIGNAL" mode for "A/T". Refer to [AT-75, "CONSULT-II REFERENCE VALUE"](#) .

Does it maintain lock-up status?

YES >> GO TO 8.

NO >> Enter a check mark at "A/T Does Not Hold Lock-up Condition" on the diagnostics worksheet [AT-43](#) , then continue the road test.

TROUBLE DIAGNOSIS

8. CHECK LOCK-UP RELEASE

Check lock-up cancellation by depressing brake pedal lightly to decelerate.

With CONSULT-II

Select "TCC SOL 0.00A" with the "MAIN SIGNAL" mode for "A/T". Refer to [AT-75, "CONSULT-II REFERENCE VALUE"](#).

Does lock-up cancel?

YES >> GO TO 9.

NO >> Enter a check mark at "Lock-up Is Not Released" on the diagnostics worksheet [AT-43](#), then continue the road test.

9. CHECK SHIFT DOWN D5 → D4

Decelerate by pressing lightly on the brake pedal.

With CONSULT-II

Read the gear position and engine speed. [AT-80, "DATA MONITOR MODE"](#).

When the A/T shift down D5 → D4, does the engine speed drop smoothly back to idle?

YES >> 1. Stop the vehicle.

2. Go to Cruise test - Part 2 (Refer to [AT-63](#)).

NO >> Enter a check mark at "Engine Speed Does Not Return To Idle" on the diagnostics worksheet, then continue the road test. Go to Cruise test - Part 2 (Refer to [AT-63](#)).

Cruise Test - Part 2

ACS000HR

Cruise test Part 2

1. CHECK STARTING FROM D1

1. Move selector lever the "D" position.

2. Accelerate at half throttle.

With CONSULT-II

Read the gear position. Refer to [AT-80, "DATA MONITOR MODE"](#).

Does it start from D1?

YES >> GO TO 2.

NO >> Enter a check mark at "Vehicle Cannot Be Started From D1" on the diagnostics worksheet [AT-43](#), then continue the road test.

2. CHECK SHIFT UP D1 → D2

Press the accelerator pedal down all the way and inspect whether or not the transmission shifts up (D1 → D2) at the correct speed.

- Refer to [AT-65](#).

With CONSULT-II

Read the gear position, throttle position and vehicle speed. Refer to [AT-80, "DATA MONITOR MODE"](#).

Does the A/T shift up D1 → D2 at the correct speed?

YES >> GO TO 3.

NO >> Enter a check mark at "Vehicle Does Not Shift D1 → D2" on the diagnostics worksheet [AT-43](#), then continue the road test.

TROUBLE DIAGNOSIS

3. CHECK SHIFT UP D2 → D3

Press the accelerator pedal down all the way and inspect whether or not the transmission shifts up (D2 → D3) at the correct speed.

- Refer to [AT-65](#).

With CONSULT-II

Read the gear position, throttle position and vehicle speed. Refer to [AT-80, "DATA MONITOR MODE"](#).

Does the A/T shift up D2 → D3 at the correct speed?

YES >> GO TO 4.

NO >> Enter a check mark at "Vehicle Does Not Shift D2 → D3" on the diagnostics worksheet [AT-43](#), then continue the road test.

4. CHECK SHIFT UP D3 → D4 AND ENGINE BRAKE

When the transmission changes speed D3 → D4, return the accelerator pedal.

With CONSULT-II

Read the gear position. Refer to [AT-80, "DATA MONITOR MODE"](#).

Does the A/T shift up D3 → D4 and apply the engine brake?

YES >> 1. Stop the vehicle.

2. Go to [AT-64](#).

NO >> Enter a check mark at "Vehicle Does Not Shift D3 → D4" on the diagnostics worksheet [AT-43](#), then continue the road test. (Refer to [AT-64](#)).

Cruise Test - Part 3

ACS000HS

Cruise test Part 3

1. MANUAL MODE FUNCTION

Move to manual mode from D position.

Does it switch to manual mode?

YES >> GO TO 2.

NO >> Continue road test and add checkmark to "Cannot Be Changed To Manual Mode" on diagnostics worksheet [AT-43](#).

2. CHECK SHIFT DOWN

During manual mode driving, is downshift from M5 → M4 → M3 → M2 → M1 performed?

With CONSULT-II

Read the gear position. Refer to Data monitor.

Is downshifting correctly performed?

YES >> GO TO 2.

NO >> Enter a check mark at "Vehicle Does Not Shift" at the corresponding position (5th → 4th, 4th → 3rd, 3rd → 2nd, 2nd → 1st) on the diagnostics worksheet [AT-43](#), then continue the road test.

3. CHECK ENGINE BRAKE

Check engine brake.

Does engine braking effectively reduce speed in M1 position?

YES >> 1. Stop the vehicle.

2. Carry out the self-diagnostics. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#), [AT-86, "Diagnostic Procedure Without CONSULT-II"](#).

NO >> Enter a check mark at "Vehicle Does Not Decelerate By Engine Brake" on the diagnostics worksheet [AT-43](#), then continue trouble diagnosis.

TROUBLE DIAGNOSIS

Vehicle Speed When Shifting Gears

ACS000HT

Throttle position	Vehicle speed km/h (MPH)							
	D1 →D2	D2 →D3	D3 →D4	D4 →D5	D5 →D4	D4 →D3	D3 →D2	D2 →D1
Full throttle	58 - 62 (36 - 39)	90 - 98 (56 - 61)	140 - 150 (87 - 93)	201 - 211 (125 - 131)	197 - 207 (122 - 129)	122 - 132 (76 - 82)	74 - 82 (46 - 51)	34 - 38 (23 - 25)
Half throttle	46 - 50 (29 - 31)	71 - 79 (44 - 49)	107 - 117 (66 - 73)	135 - 145 (84 - 90)	88 - 98 (55 - 61)	63 - 73 (39 - 45)	29 - 37 (18 - 23)	11 - 15 (7 - 9)

- At half throttle, the accelerator opening is 4/8 of the full opening.

Vehicle Speed When Performing and Releasing Complete Lock-up

ACS000HU

Throttle position	Vehicle speed km/h (MPH)	
	Lock-up "ON"	Lock-up "OFF"
Closed throttle	56 - 64 (35 - 40)	53 - 61 (33 - 38)
Half throttle	168 - 176 (104 - 109)	131 - 139 (81 - 86)

- At closed throttle, the accelerator opening is less than 1/8 condition.
- At half throttle, the accelerator opening is 4/8 of the full opening.

Vehicle Speed When Performing and Releasing Slip Lock-up

ACS000HV

Throttle position	Gear position	Vehicle speed km/h (MPH)	
		Slip lock-up "ON"	Slip lock-up "OFF"
Closed throttle	4th	37 - 45 (23 - 28)	34 - 42 (21 - 26)
	5th	44 - 52 (27 - 32)	41 - 49 (25 - 30)

- At closed throttle, the accelerator opening is less than 1/8 condition.

Symptom Chart

ACS000HW

The diagnostics item numbers show the sequence for inspection. Inspect in order from item 1.

CAUTION:

- If any malfunction occurs in the RE5R05A transmission, replace the transmission assembly.
- Condition for "on vehicle" only

Symptom	Diagnostic item	Reference page
Shift point is high in D position.	1. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97 , AT-121
	2. Accelerator pedal position sensor	EC-588 , EC-596 , EC-612
	3. Throttle position sensor	EC-454 , EC-456 , EC-604
	4. ATF temperature sensor	AT-115
Shift point is low in D position.	1. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97 , AT-121
	2. Accelerator pedal position sensor	EC-588 , EC-596 , EC-612
	3. Throttle position sensor	EC-454 , EC-456 , EC-604

TROUBLE DIAGNOSIS

Symptom	Diagnostic item	Reference page
Large shock. ("N" → "D" position)	1. Engine idle speed	EC-30
	2. Engine speed signal	AT-100
	3. Accelerator pedal position sensor	EC-588, EC-596 , EC-612
	4. Throttle position sensor	EC-454, EC-456 , EC-604
	5. Control linkage adjustment	AT-201
	6. ATF temperature sensor	AT-115
	7. ATF pressure switch 1, front brake solenoid valve	AT-163, AT-135
	8. CAN communication line	AT-88
	9. Fluid level and state	AT-55
Shock is too large when changing D1 → D2 or M1 → M2 .	1. Accelerator pedal position sensor	EC-588, EC-596 , EC-612
	2. Throttle position sensor	EC-454, EC-456 , EC-604
	3. Control linkage adjustment	AT-201
	4. ATF pressure switch 5, direct clutch solenoid valve	AT-169, AT-141
	5. CAN communication line	AT-88
	6. Engine speed signal	AT-100
	7. Turbine revolution sensor	AT-118
	8. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97, AT-121
	9. Fluid level and state	AT-55
Shock is too large when changing D2 → D3 or M2 → M3 .	1. Accelerator pedal position sensor	EC-588, EC-596 , EC-612
	2. Throttle position sensor	EC-454, EC-456 , EC-604
	3. Control linkage adjustment	AT-201
	4. ATF pressure switch 6, high and low reverse clutch solenoid valve	AT-172, AT-147
	5. CAN communication line	AT-88
	6. Engine speed signal	AT-100
	7. Turbine revolution sensor	AT-118
	8. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97, AT-121
	9. Fluid level and state	AT-55
Shock is too large when changing D3 → D4 or M3 → M4 .	1. Accelerator pedal position sensor	EC-588, EC-596 , EC-612
	2. Throttle position sensor	EC-454, EC-456 , EC-604
	3. Control linkage adjustment	AT-201
	4. ATF pressure switch 3, input clutch solenoid valve	AT-166, AT-129
	5. CAN communication line	AT-88
	6. Engine speed signal	AT-100
	7. Turbine revolution sensor	AT-118
	8. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97, AT-121
	9. Fluid level and state	AT-55

TROUBLE DIAGNOSIS

Symptom	Diagnostic item	Reference page	
Shock is too large when changing D4 → D5 or M4 → M5 .	1. Accelerator pedal position sensor	EC-588 , EC-596 , EC-612	A
	2. Throttle position sensor	EC-454 , EC-456 , EC-604	B
	3. Control linkage adjustment	AT-201	
	4. ATF pressure switch 1, front brake solenoid valve	AT-163 , AT-135	AT
	5. CAN communication line	AT-88	
	6. Engine speed signal	AT-100	
	7. Turbine revolution sensor	AT-118	D
	8. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97 , AT-121	
	9. Fluid level and state	AT-55	E
Shock is too large for downshift when accelerator pedal is pressed.	1. Accelerator pedal position sensor	EC-588 , EC-596 , EC-612	
	2. Throttle position sensor	EC-454 , EC-456 , EC-604	F
	3. Control linkage adjustment	AT-201	
	4. CAN communication line	AT-88	G
	5. Engine speed signal	AT-100	
	6. Turbine revolution sensor	AT-118	
	7. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97 , AT-121	H
	8. Fluid level and state	AT-55	
Shock is too large for upshift when accelerator pedal is released.	1. Accelerator pedal position sensor	EC-588 , EC-596 , EC-612	I
	2. Throttle position sensor	EC-454 , EC-456 , EC-604	
	3. Control linkage adjustment	AT-201	J
	4. Engine speed signal	AT-100	
	5. CAN communication line	AT-88	K
	6. Turbine revolution sensor	AT-118	
	7. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97 , AT-121	
	8. Fluid level and state	AT-55	L
Shock is too large for lock-up.	1. Accelerator pedal position sensor	EC-588 , EC-596 , EC-612	
	2. Throttle position sensor	EC-454 , EC-456 , EC-604	M
	3. Control linkage adjustment	AT-201	
	4. Engine speed signal	AT-100	
	5. CAN communication line	AT-88	
	6. Turbine revolution sensor	AT-118	
	7. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97 , AT-121	
	8. Torque converter clutch solenoid valve	AT-102	
	9. Fluid level and state	AT-55	

TROUBLE DIAGNOSIS

Symptom	Diagnostic item	Reference page
Shock is too large during engine brake.	1. Accelerator pedal position sensor	EC-588 , EC-596 , EC-612
	2. Throttle position sensor	EC-454 , EC-456 , EC-604
	3. Control linkage adjustment	AT-201
	4. CAN communication line	AT-88
	5. Fluid level and state	AT-55
Judder occurs during lock-up.	1. Fluid level and state	AT-55
	2. Engine speed signal	AT-100
	3. Turbine revolution sensor	AT-118
	4. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97 , AT-121
	5. Accelerator pedal position sensor	EC-588 , EC-596 , EC-612
	6. Throttle position sensor	EC-454 , EC-456 , EC-604
	7. Torque converter clutch solenoid valve	AT-102
Strange noise in R, N or D position.	1. Fluid level and state	AT-55
	2. Engine speed signal	AT-100
When D or M position, remains in 1st gear.	1. Fluid level and state	AT-55
	2. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97 , AT-121
	3. Direct clutch solenoid valve	AT-141
	4. Line pressure test	AT-57
When D or M position, remains in 2nd gear.	1. Fluid level and state	AT-55
	2. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97 , AT-121
	3. Low coast brake solenoid valve	AT-153
	4. Line pressure test	AT-57
When D or M position, remains in 3rd gear.	1. Fluid level and state	AT-55
	2. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97 , AT-121
	3. Line pressure test	AT-57
When D or M position, remains in 4th gear.	1. Fluid level and state	AT-55
	2. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97 , AT-121
	3. ATF pressure switch 3, input clutch solenoid valve	AT-166 , AT-129
	4. ATF pressure switch 5, direct clutch solenoid valve	AT-169 , AT-141
	5. ATF pressure switch 6, high and low reverse clutch solenoid valve	AT-172 , AT-147
	6. Low coast brake solenoid valve	AT-153
	7. Front brake solenoid valve	AT-135
	8. Line pressure test	AT-57
When D or M position, remains in 5th gear.	1. Fluid level and state	AT-55
	2. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97 , AT-121
	3. ATF pressure switch 1, front brake solenoid valve	AT-163 , AT-135
	4. Line pressure test	AT-57
Gear does not change from D1 → D2 or from M1 → M2 .	1. Fluid level and state	AT-55
	2. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97 , AT-121
	3. ATF pressure switch 5, direct clutch solenoid valve	AT-169 , AT-141
	4. Line pressure test	AT-57

TROUBLE DIAGNOSIS

Symptom	Diagnostic item	Reference page
Gear does not change from D2 → D3 or from M2 → M3 .	1. Fluid level and state	AT-55
	2. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97, AT-121
	3. ATF pressure switch 6, high and low reverse clutch solenoid valve	AT-172, AT-147
	4. Line pressure test	AT-57
Gear does not change from D3 → D4 or from M3 → M4 .	1. Fluid level and state	AT-55
	2. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97, AT-121
	3. ATF pressure switch 3, input clutch solenoid valve	AT-166, AT-129
	4. ATF pressure switch 1, front brake solenoid valve	AT-163, AT-135
	5. Line pressure test	AT-57
Gear does not change from D4 → D5 or from M4 → M5 .	1. Fluid level and state	AT-55
	2. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97, AT-121
	3. ATF pressure switch 1, front brake solenoid valve	AT-163, AT-135
	4. ATF pressure switch 5, direct clutch solenoid valve	AT-169, AT-141
	5. Turbine revolution sensor	AT-118
	6. Line pressure test	AT-57
In D range, does not downshift to 4th gear.	1. Fluid level and state	AT-55
	2. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97, AT-121
	3. ATF pressure switch 1, front brake solenoid valve	AT-163, AT-135
	4. ATF pressure switch 5, direct clutch solenoid valve	AT-169, AT-141
	5. Line pressure test	AT-57
In D range, does not downshift to 3rd gear.	1. Fluid level and state	AT-55
	2. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97, AT-121
	3. ATF pressure switch 3, input clutch solenoid valve	AT-166, AT-129
	4. ATF pressure switch 1, front brake solenoid valve	AT-163, AT-135
	5. Line pressure test	AT-57
In D range, does not downshift to 2nd gear.	1. Fluid level and state	AT-55
	2. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97, AT-121
	3. ATF pressure switch 6, high and low reverse clutch solenoid valve	AT-172, AT-147
	4. Line pressure test	AT-57
In D range, does not downshift to 1st gear.	1. Fluid level and state	AT-55
	2. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97, AT-121
	3. ATF pressure switch 5, direct clutch solenoid valve	AT-169, AT-141
	4. Line pressure test	AT-57
Does not lock up.	1. Fluid level and state	AT-55
	2. Line pressure test	AT-57
	3. Engine speed signal	AT-100
	4. Turbine revolution sensor	AT-118
	5. Torque converter clutch solenoid valve	AT-102
	6. CAN communication line	AT-88
Does not change M5 → M4.	1. PNP switch	AT-94
	2. Fluid level and state	AT-55
	3. Control linkage adjustment	AT-201
	4. Manual mode switch	AT-159
	5. ATF pressure switch 1	AT-163

TROUBLE DIAGNOSIS

Symptom	Diagnostic item	Reference page
Does not change M4 → M3.	1. PNP switch	AT-94
	2. Fluid level and state	AT-55
	3. Control linkage adjustment	AT-201
	4. Manual mode switch	AT-159
	5. ATF pressure switch 1, ATF pressure switch 3	AT-163, AT-166
Does not change M3 → M2.	1. PNP switch	AT-94
	2. Fluid level and state	AT-55
	3. Control linkage adjustment	AT-201
	4. Manual mode switch	AT-159
	5. ATF pressure switch 6	AT-172
Does not change M2 → M1.	1. PNP switch	AT-94
	2. Fluid level and state	AT-55
	3. Control linkage adjustment	AT-201
	4. Manual mode switch	AT-159
	5. ATF pressure switch 5	AT-169
No shock at all or the clutch slips when vehicle changes speed D1 → D2 or M1 → M2 .	1. Fluid level and state	AT-55
	2. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97, AT-121
	3. ATF pressure switch 5, direct clutch solenoid valve	AT-169, AT-141
	4. Line pressure test	AT-57
No shock at all or the clutch slips when vehicle changes speed D2 → D3 or M2 → M3 .	1. Fluid level and state	AT-55
	2. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97, AT-121
	3. ATF pressure switch 6, high and low reverse clutch solenoid valve	AT-172, AT-147
	4. Line pressure test	AT-57
No shock at all or the clutch slips when vehicle changes speed D3 → D4 or M3 → M4 .	1. Fluid level and state	AT-55
	2. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97, AT-121
	3. ATF pressure switch 3, input clutch solenoid valve	AT-166, AT-129
	4. ATF pressure switch 1, front brake solenoid valve	AT-163, AT-135
	5. Line pressure test	AT-57
No shock at all or the clutch slips when vehicle changes speed D4 → D5 or M4 → M5 .	1. Fluid level and state	AT-55
	2. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97, AT-121
	3. ATF pressure switch 1, front brake solenoid valve	AT-163, AT-135
	4. ATF pressure switch 5, direct clutch solenoid valve	AT-169, AT-141
	5. Line pressure test	AT-57
When you press the accelerator pedal and shift speed D5 → D4 or M5 → M4 the engine idles or the transmission slips.	1. Fluid level and state	AT-55
	2. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97, AT-121
	3. ATF pressure switch 1, front brake solenoid valve	AT-163, AT-135
	4. ATF pressure switch 5, direct clutch solenoid valve	AT-169, AT-141
	5. Line pressure test	AT-57
When you press the accelerator pedal and shift speed D4 → D3 or M4 → M3 the engine idles or the transmission slips.	1. Fluid level and state	AT-55
	2. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97, AT-121
	3. ATF pressure switch 3, input clutch solenoid valve	AT-166, AT-129
	4. ATF pressure switch 1, front brake solenoid valve	AT-163, AT-135
	5. Line pressure test	AT-57

TROUBLE DIAGNOSIS

Symptom	Diagnostic item	Reference page	
When you press the accelerator pedal and shift speed D3 → D2 or M3 → M2 the engine idles or the transmission slips.	1. Fluid level and state	AT-55	A
	2. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97, AT-121	
	3. ATF pressure switch 6, high and low reverse clutch solenoid valve	AT-172, AT-147	B
	4. ATF pressure switch 5, direct clutch solenoid valve	AT-169, AT-141	
	5. Line pressure test	AT-57	
When you press the accelerator pedal and shift speed D2 → D1 or M2 → M1 the engine idles or the transmission slips.	1. Fluid level and state	AT-55	AT
	2. Vehicle speed sensor A/T and vehicle speed sensor MTR	AT-97, AT-121	
	3. ATF pressure switch 5, direct clutch solenoid valve	AT-169, AT-141	D
	4. Line pressure test	AT-57	
Engine brake does not work M5 → M4.	1. PNP switch	AT-94	E
	2. Fluid level and state	AT-55	
	3. Control linkage adjustment	AT-201	
	4. Manual mode switch	AT-159	F
	5. ATF pressure switch 1	AT-163	
Engine brake does not work M4 → M3.	1. PNP switch	AT-94	G
	2. Fluid level and state	AT-55	
	3. Control linkage adjustment	AT-201	
	4. Manual mode switch	AT-159	H
	5. ATF pressure switch 1, ATF pressure switch 3	AT-163, AT-166	
Engine brake does not work M3 → M2.	1. PNP switch	AT-94	I
	2. Fluid level and state	AT-55	
	3. Control linkage adjustment	AT-201	
	4. Manual mode switch	AT-159	J
	5. ATF pressure switch 6	AT-172	
Engine brake does not work M2 → M1.	1. PNP switch	AT-94	K
	2. Fluid level and state	AT-55	
	3. Control linkage adjustment	AT-201	
	4. Manual mode switch	AT-159	L
	5. ATF pressure switch 5	AT-169	
With selector lever in D position, acceleration is extremely poor.	1. Fluid level and state	AT-55	M
	2. Line pressure test	AT-57	
	3. Accelerator pedal position sensor	EC-588, EC-596, EC-612	
	4. Throttle position sensor	EC-454, EC-456, EC-604	
	5. CAN communication line	AT-88	
	6. PNP switch	AT-94	
	7. Control linkage adjustment	AT-201	

TROUBLE DIAGNOSIS

Symptom	Diagnostic item	Reference page
With selector lever in R position, acceleration is extremely poor.	1. Fluid level and state	AT-55
	2. Line pressure test	AT-57
	3. Accelerator pedal position sensor	EC-588 , EC-596 , EC-612
	4. Throttle position sensor	EC-454 , EC-456 , EC-604
	5. ATF pressure switch 6, high and low reverse clutch solenoid valve	AT-172 , AT-147
	6. CAN communication line	AT-88
	7. PNP switch	AT-94
	8. Control linkage adjustment	AT-201
While starting off by accelerating in 1st, engine races or slippage occurs.	1. Fluid level and state	AT-55
	2. Line pressure test	AT-57
	3. Accelerator pedal position sensor	EC-588 , EC-596 , EC-612
	4. Throttle position sensor	EC-454 , EC-456 , EC-604
	5. CAN communication line	AT-88
While accelerating in 2nd, engine races or slippage occurs.	1. Fluid level and state	AT-55
	2. Line pressure test	AT-57
	3. Accelerator pedal position sensor	EC-588 , EC-596 , EC-612
	4. Throttle position sensor	EC-454 , EC-456 , EC-604
	5. CAN communication line	AT-88
	6. ATF pressure switch 5, direct clutch solenoid valve	AT-169 , AT-141
While accelerating in 3rd, engine races or slippage occurs.	1. Fluid level and state	AT-55
	2. Line pressure test	AT-57
	3. Accelerator pedal position sensor	EC-588 , EC-596 , EC-612
	4. Throttle position sensor	EC-454 , EC-456 , EC-604
	5. CAN communication line	AT-88
	6. ATF pressure switch 6, high and low reverse clutch solenoid valve	AT-172 , AT-147
While accelerating in 4th, engine races or slippage occurs.	1. Fluid level and state	AT-55
	2. Line pressure test	AT-57
	3. Accelerator pedal position sensor	EC-588 , EC-596 , EC-612
	4. Throttle position sensor	EC-454 , EC-456 , EC-604
	5. CAN communication line	AT-88
	6. ATF pressure switch 3, input clutch solenoid valve	AT-166 , AT-129

TROUBLE DIAGNOSIS


Symptom	Diagnostic item	Reference page
While accelerating in 5th, engine races or slippage occurs.	1. Fluid level and state	AT-55
	2. Line pressure test	AT-57
	3. Accelerator pedal position sensor	EC-588, EC-596 , EC-612
	4. Throttle position sensor	EC-454, EC-456 , EC-604
	5. CAN communication line	AT-88
	6. ATF pressure switch 1, front brake solenoid valve	AT-163, AT-135
Slips at lock-up.	1. Fluid level and state	AT-55
	2. Line pressure test	AT-57
	3. Engine speed signal	AT-100
	4. Turbine revolution sensor	AT-118
	5. Torque converter clutch solenoid valve	AT-102
	6. CAN communication line	AT-88
Maximum speed low.	1. Fluid level and state	AT-55
	2. Line pressure test	AT-57
	3. Accelerator pedal position sensor	EC-588, EC-596 , EC-612
	4. Throttle position sensor	EC-454, EC-456 , EC-604
	5. CAN communication line	AT-88
	6. Direct clutch solenoid valve	AT-141
No creep at all.	1. Fluid level and state	AT-55
	2. Engine speed signal	AT-100
	3. CAN communication line	AT-88
	4. ATF pressure switch 5, direct clutch solenoid valve	AT-169, AT-141
Extremely large creep.	1. Engine idle speed	EC-30
	2. CAN communication line	AT-88
	3. ATF pressure switch 5	AT-169
With selector lever in P position, vehicle does not enter parking condition or, with selector lever in another position, parking condition is not cancelled.	1. PNP switch	AT-94
	2. Control linkage adjustment	AT-201
Vehicle runs with transmission in P position.	1. PNP switch	AT-94
	2. Fluid level and state	AT-55
	3. Control linkage adjustment	AT-201
	4. Line pressure test	AT-57
Vehicle runs with transmission in N position.	1. PNP switch	AT-94
	2. Fluid level and state	AT-55
	3. Control linkage adjustment	AT-201
	4. Line pressure test	AT-57
Vehicle cannot run in all positions.	1. Fluid level and state	AT-55
	2. Line pressure test	AT-57
	3. PNP switch	AT-94
	4. Control linkage adjustment	AT-201

TROUBLE DIAGNOSIS

Symptom	Diagnostic item	Reference page
With selector lever in D position, driving is not possible.	1. Fluid level and state	AT-55
	2. Line pressure test	AT-57
	3. PNP switch	AT-94
	4. Control linkage adjustment	AT-201
With selector lever in R position, driving is not possible.	1. Fluid level and state	AT-55
	2. Line pressure test	AT-57
	3. PNP switch	AT-94
	4. Control linkage adjustment	AT-201
Engine does not start in N, P position.	1. Ignition switch and starter	PG-4, SC-10
	2. Control linkage adjustment	AT-201
	3. PNP switch	AT-94
Engine starts in positions other than N or P.	1. Ignition switch and starter	PG-4, SC-10
	2. Control linkage adjustment	AT-201
	3. PNP switch	AT-94
Engine stall.	1. Fluid level and state	AT-55
	2. Engine speed signal	AT-100
	3. Turbine revolution sensor	AT-118
	4. Torque converter clutch solenoid valve	AT-102
Engine stalls when selector lever shifted N → D, R.	1. Fluid level and state	AT-55
	2. Engine speed signal	AT-100
	3. Turbine revolution sensor	AT-118
	4. Torque converter clutch solenoid valve	AT-102

TCM Input/Output Signal Reference Values A/T ASSEMBLY HARNESS CONNECTOR TERMINAL LAYOUT

ACS000HX







TCM INSPECTION TABLE

Data are reference value and are measured between each terminal and ground.

Terminal	Wire color	Item	Condition	Data (Approx.)
1	R/W	Power supply (Memory back-up)	Always	Battery voltage
2	R/W	Power supply (Memory back-up)	Always	Battery voltage
3	L	CAN-H	—	—
4	PU/W	K-line (CONSULT-II signal)	The terminal is connected to the data link connector for CONSULT-II.	—
5	B	Ground	Always	0V

TROUBLE DIAGNOSIS

Terminal	Wire color	Item	Condition	Data (Approx.)
6	Y/R	Power supply	 –	Battery voltage
			 –	0V
7	P	Back-up lamp relay	 Selector lever in “R” position.	0V
			Selector lever in other positions.	Battery voltage
8	P	CAN-L	–	–
9	GY/R	Starter relay	 Selector lever in “N”, “P” positions.	Battery voltage
			Selector lever in other positions.	0V
10	B	Ground	Always	0V

CONSULT-II

ACS000HY

After performing [AT-86, "Diagnostic Procedure Without CONSULT-II"](#), place check marks for results on the [AT-43, "DIAGNOSTIC WORKSHEET"](#). Reference pages are provided following the items.

NOTICE:

- The CONSULT-II electrically displays shift timing and lock-up timing (that is, operation timing of each solenoid).
Check for time difference between actual shift timing and the CONSULT-II display. If the difference is noticeable, mechanical parts (except solenoids, sensors, etc.) may be malfunctioning. Check mechanical parts using applicable diagnostic procedures.
- Shift schedule (which implies gear position) displayed on CONSULT-II and that indicated in Service Manual may differ slightly. This occurs because of the following reasons:
 - Actual shift schedule has more or less tolerance or allowance,
 - Shift schedule indicated in Service Manual refers to the point where shifts start, and
 - Gear position displayed on CONSULT-II indicates the point where shifts are completed.
- Display of solenoid valves on CONSULT-II changes at the start of shifting, while gear position is displayed upon completion of shifting (which is computed by TCM).
- Additional CONSULT-II information can be found in the Operation Manual supplied with the CONSULT-II unit.

CONSULT-II REFERENCE VALUE

Item name	Condition	Display value (Approx.)
ATF TEMP SE 1	0°C (32° F) - 20°C (68°F) - 80°C (176°F)	3.2 - 2.5 - 0.8 V
ATF TEMP SE 2		3.2 - 2.4 - 0.65 V
TCC SOLENOID	When perform slip lock-up	0.2 - 0.4 A
	When perform lock-up	0.4 - 0.6 A
SLCT LVR POSI	Selector lever in “N”, “P” position.	N/P
	Selector lever in “R” position.	R
	Selector lever in “D” position.	D
VHCL/S SE-A/T	During driving	Approximately matches the speedometer reading.
ENGINE SPEED	Engine running	Closely matches the tachometer reading.
LINE PRES SOL	During driving	0.2 - 0.6 A
TURBINE REV	During driving (lock-up ON)	Approximately matches the engine speed.
VHCL/S SE-MTR	During driving	Approximately matches the speedometer reading.

TROUBLE DIAGNOSIS

Item name	Condition	Display value (Approx.)
ATF PRES SW 1	Front brake operates. Refer to AT-17 .	ON
	Other conditions	OFF
ATF PRES SW 2	Low coast brake operates. Refer to AT-17 .	ON
	Other conditions	OFF
ATF PRES SW 3	Input clutch operates. Refer to AT-17 .	ON
	Other conditions	OFF
ATF PRES SW 5	Direct clutch operates. Refer to AT-17 .	ON
	Other conditions	OFF
ATF PRES SW 6	High and low reverse clutch operates. Refer to AT-17 .	ON
	Other conditions	OFF
I/C SOLENOID	Input clutch solenoid valve operates. Refer to AT-17 .	0.6 - 0.8 A
	Other conditions	0 - 0.05 A
FR/B SOLENOID	Front brake solenoid valve operates. Refer to AT-17 .	0.6 - 0.8 A
	Other conditions	0 - 0.05 A
D/C SOLENOID	Direct clutch solenoid valve operates. Refer to AT-17 .	0.6 - 0.8 A
	Other conditions	0 - 0.05 A
HLR/C SOL	High and low reverse clutch solenoid valve operates. Refer to AT-17 .	0.6 - 0.8 A
	Other conditions	0 - 0.05 A
ON OFF SOL	Low coast brake operates. Refer to AT-17 .	ON
	Other conditions	OFF
ATF PRES SW 2	Low coast brake operates. Refer to AT-17 .	ON
	Other conditions	OFF
MANU MODE SW	Manual shift gate position (neutral)	ON
	Other than the above	OFF
NON M-MODE SW	Manual shift gate position	OFF
	Other than the above	ON
UP SW LEVER	Selector lever: + side	ON
	Other than the above	OFF
DOWN SW LEVER	Selector lever: - side	ON
	Other than the above	OFF
STARTER RELAY	Selector lever in N, P position.	ON
	Selector lever in other position.	OFF
ACCELE POSI	Released accelerator pedal.	0.0/8
	Fully depressed accelerator pedal.	8/8
THROTTLE POSI	Released accelerator pedal.	0.0/8
	Fully depressed accelerator pedal.	8/8
CLSD THL POS	Released accelerator pedal.	ON
	Fully depressed accelerator pedal.	OFF
W/O THL POS	Fully depressed accelerator pedal.	ON
	Released accelerator pedal.	OFF

TROUBLE DIAGNOSIS

Item name	Condition	Display value (Approx.)
BRAKE SW	Depressed brake pedal.	ON
	Released brake pedal.	OFF


CONSULT-II SETTING PROCEDURE

CAUTION:


If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which perform CAN communication.

- For details, refer to the separate "CONSULT-II Operations Manual".


- Turn ignition switch "OFF".
- Connect CONSULT-II and CONSULT-II CONVERTER to data link connector, which is located in instrument lower panel on driver side.



- Turn ignition switch "ON". (Do not start engine.)
- Touch "START (NISSAN BASED VHCL)".



- Touch "A/T".
If "A/T" is not indicated, go to [GI-39, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).
- Perform each diagnostic test mode according to each service procedure.



SELF-DIAGNOSTIC RESULT MODE

Operation procedure

- Perform "CONSULT-II SETTING PROCEDURE" Refer to [AT-77, "CONSULT-II SETTING PROCEDURE"](#).

TROUBLE DIAGNOSIS

2. Touch "SELF-DIAG RESULTS".
Display shows malfunction experienced since the last erasing operation.

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
DTC WORK SUPPORT
TCM PART NUMBER

SAT971J

Display items list

X: Applicable, —: Not applicable

Items (CONSULT-II screen terms)	Malfunction is detected when...	TCM self-diagnosis		OBD-II (DTC)
		A/T CHECK indicator lamp	"A/T" with CONSULT-II	MIL indicator lamp*1, "ENGINE" with CONSULT-II or GST
CAN COMM CIRCUIT	<ul style="list-style-type: none"> When a malfunction is detected in CAN communications 	X	U1000	U1000
STARTER RELAY/CIRC	<ul style="list-style-type: none"> If this signal is ON other than in P or N position, this is judged to be a malfunction. (And if it is OFF in P or N position, this too is judged to be a malfunction.) 	X	P0615	—
TCM	<ul style="list-style-type: none"> TCM is malfunctioning 	—	P0700	P0700
PNP SW/CIRC	<ul style="list-style-type: none"> PNP switch 1-4 signals input with impossible pattern P position is detected from N position without any other position being detected in between. 	X	P0705	P0705
VEH SPD SEN/CIR AT (Revolution sensor)	<ul style="list-style-type: none"> Signal from vehicle speed sensor A/T (Revolution sensor) not input due to cut line or the like Unexpected signal input during running After ignition switch is turned ON, unexpected signal input from vehicle speed sensor MTR before the vehicle starts moving 	X	P0720	P0720
ENGINE SPEED SIG	<ul style="list-style-type: none"> TCM does not receive the CAN communication signal from the ECM. 	X	P0725	P0725
TCC SOLENOID/CIRC	<ul style="list-style-type: none"> Normal voltage not applied to solenoid due to cut line, short, or the like 	X	P0740	P0740
A/T TCC S/V FNCTN	<ul style="list-style-type: none"> A/T cannot perform lock-up even if electrical circuit is good. TCM detects as irregular by comparing difference value with slip rotation. 	X	P0744	P0744*2
L/PRESS SOL/CIRC	<ul style="list-style-type: none"> Normal voltage not applied to solenoid due to cut line, short, or the like TCM detects as irregular by comparing target value with monitor value. 	X	P0745	P0745
TCM-RAM	<ul style="list-style-type: none"> TCM memory (RAM) is malfunctioning. 	—	P1702	—
TCM-ROM	<ul style="list-style-type: none"> TCM memory (ROM) is malfunctioning. 	—	P1703	—
TP SEN/CIRC A/T	<ul style="list-style-type: none"> TCM does not receive the proper accelerator pedal position signals (input by CAN communication) from ECM. 	X	P1705	P1705
ATF TEMP SEN/CIRC	<ul style="list-style-type: none"> During running, the ATF temperature sensor signal voltage is excessively high or low 	X	P1710	P1710

TROUBLE DIAGNOSIS

Items (CONSULT-II screen terms)	Malfunction is detected when...	TCM self-diagnosis		OBD-II (DTC)	
		A/T CHECK indicator lamp	"A/T" with CONSULT-II	MIL indicator lamp*1, "ENGINE" with CONSULT-II or GST	
TURBINE REV S/ CIRC	<ul style="list-style-type: none"> TCM does not receive the proper voltage signal from the sensor. TCM detects an irregularity only at position of 4th gear for turbine revolution sensor 2. 	X	P1716	P1716	AT
VEH SPD SE/ CIR-MTR	<ul style="list-style-type: none"> Signal (CAN communication) from vehicle speed sensor MTR not input due to cut line or the like Unexpected signal input during running 	—	P1721	—	D
A/T INTERLOCK	<ul style="list-style-type: none"> Except during shift change, the gear position and pressure switch states are monitored and comparative judgement made. 	X	P1730	P1730	E
A/T 1ST E/BRAK-ING	<ul style="list-style-type: none"> Each pressure switch and solenoid current is monitored and if a pattern is detected having engine braking 1st gear other than in the M1 position, a malfunction is detected. 	X	P1731	—	F
I/C SOLENOID/ CIRC	<ul style="list-style-type: none"> Normal voltage not applied to solenoid due to functional malfunction, cut line, short, or the like TCM detects as irregular by comparing target value with monitor value. 	X	P1752	P1752	G
I/C SOLENOID FNCTN	<ul style="list-style-type: none"> TCM detects that actual gear ratio is irregular, and relation between gear position and condition of pressure switch 3 is irregular during depressing accelerator pedal. (Other than during shift change) TCM detects that relation between gear position and condition of pressure switch 3 is irregular during releasing accelerator pedal. (Other than during shift change) 	X	P1754	P1754*2	H
FR/B SOLENOID/ CIRC	<ul style="list-style-type: none"> Normal voltage not applied to solenoid due to functional malfunction, cut line, short, or the like TCM detects as irregular by comparing target value with monitor value. 	X	P1757	P1757	I
FR/B SOLENOID FNCT	<ul style="list-style-type: none"> TCM detects that actual gear ratio is irregular, and relation between gear position and condition of pressure switch 1 is irregular during depressing accelerator pedal. (Other than during shift change) TCM detects that relation between gear position and condition of pressure switch 1 is irregular during releasing accelerator pedal. (Other than during shift change) 	X	P1759	P1759*2	J
D/C SOLENOID/ CIRC	<ul style="list-style-type: none"> Normal voltage not applied to solenoid due to cut line, short, or the like TCM detects as irregular by comparing target value with monitor value. 	X	P1762	P1762	K
D/C SOLENOID FNCTN	<ul style="list-style-type: none"> TCM detects that actual gear ratio is irregular, and relation between gear position and condition of pressure switch 5 is irregular during depressing accelerator pedal. (Other than during shift change) TCM detects that relation between gear position and condition of pressure switch 5 is irregular during releasing accelerator pedal. (Other than during shift change) 	X	P1764	P1764*2	L
HLR/C SOL/CIRC	<ul style="list-style-type: none"> Normal voltage not applied to solenoid due to functional malfunction, cut line, short, or the like TCM detects as irregular by comparing target value with monitor value. 	X	P1767	P1767	M

TROUBLE DIAGNOSIS

Items (CONSULT-II screen terms)	Malfunction is detected when...	TCM self-diagnosis		OBD-II (DTC)
		A/T CHECK indicator lamp	"A/T" with CONSULT-II	MIL indicator lamp*1, "ENGINE" with CONSULT-II or GST
HLR/C SOL FNCTN	<ul style="list-style-type: none"> ● TCM detects that actual gear ratio is irregular, and relation between gear position and condition of pressure switch 6 is irregular during depressing accelerator pedal. (Other than during shift change) ● TCM detects that relation between gear position and condition of pressure switch 6 is irregular during releasing accelerator pedal. (Other than during shift change) 	X	P1769	P1769*2
LC/B SOLENOID/ CIRC	<ul style="list-style-type: none"> ● Normal voltage not applied to solenoid due to functional malfunction, cut line, short, or the like 	X	P1772	P1772
LC/B SOLENOID FNCT	<ul style="list-style-type: none"> ● TCM detects an improper voltage drop when it tries to operate the solenoid valve. ● Condition of pressure switch 2 is different from monitor value, and relation between gear position and actual gear ratio is irregular. 	X	P1774	P1774*2
MANU MODE SW/ CIRC	<ul style="list-style-type: none"> ● When an impossible pattern of switch signals is detected, a malfunction is detected. 	—	P1815	—
ATF PRES SW 1/ CIRC	<ul style="list-style-type: none"> ● TCM detects that actual gear ratio is normal, and relation between gear position and condition of pressure switch 1 is irregular during depressing accelerator pedal. (Other than during shift change) 	—	P1841	—
ATF PRES SW 3/ CIRC	<ul style="list-style-type: none"> ● TCM detects that actual gear ratio is normal, and relation between gear position and condition of pressure switch 3 is irregular during depressing accelerator pedal. (Other than during shift change) 	—	P1843	—
ATF PRES SW 5/ CIRC	<ul style="list-style-type: none"> ● TCM detects that actual gear ratio is normal, and relation between gear position and condition of pressure switch 5 is irregular during depressing accelerator pedal. (Other than during shift change) 	—	P1845	—
ATF PRES SW 6/ CIRC	<ul style="list-style-type: none"> ● TCM detects that actual gear ratio is normal, and relation between gear position and condition of pressure switch 6 is irregular during depressing accelerator pedal. (Other than during shift change) 	—	P1846	—
NO DTC IS DETECTED FURTHER TESTING MAY BE REQUIRED	<ul style="list-style-type: none"> ● No NG item has been detected. 	—	X	X

*1: Refer to [AT-38, "Malfunction Indicator Lamp \(MIL\)"](#).

*2: These malfunctions cannot be displayed MIL if another malfunction is assigned to MIL.

DATA MONITOR MODE

Operation procedure

1. Perform "CONSULT-II SETTING PROCEDURE" Refer to [AT-77, "CONSULT-II SETTING PROCEDURE"](#).

TROUBLE DIAGNOSIS

2. Touch "DATA MONITOR".

NOTE:

When malfunction is detected, CONSULT-II performs "REAL-TIME DIAGNOSIS". Also, any malfunction detected while in this mode will be displayed at real time.

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
DTC WORK SUPPORT
TCM PART NUMBER

SAT971J

Display items list

X: Standard, —: Not applicable

Monitored item (Unit)	Monitor Item Selection				Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	CAN DIAG SUPPORT MNTR	SELECTION FROM MENU	
VHCL/S SE-A/T (km/h)	X	X	—	X	Revolution sensor
VHCL/S SE-MTR (km/h)	X	—	—	X	
ACCELE POSI (0.0/8)	X	—	—	X	Accelerator pedal position signal
THROTTLE POSI (0.0/8)	X	X	—	X	Degree of opening for accelerator recognized by the TCM For fail-safe operation, the specific value used for control is displayed.
BATTERY BOLT (V)	X	—	—	X	
ENGINE SPEED (rpm)	X	X	—	X	
TURBINE REV (rpm)	X	X	—	X	
ATF TEMP 1 (°C)	—	X	—	X	
ATF TEMP 2 (°C)	—	X	—	X	
OUTPUT REV (rpm)	X	X	—	X	
ATF TEMP SE 1 (V)	X	—	—	X	
ATF TEMP SE 2 (V)	X	—	—	X	
ATF PRES SW 1 (ON-OFF display)	X	X	—	X	(for FR/B solenoid)
ATF PRES SW 2 (ON-OFF display)	X	X	—	X	(for LC/B solenoid)
ATF PRES SW 3 (ON-OFF display)	X	X	—	X	(for I/C solenoid)
ATF PRES SW 5 (ON-OFF display)	X	X	—	X	(for D/C solenoid)
ATF PRES SW 6 (ON-OFF display)	X	X	—	X	(for HLR/C solenoid)
PNP SW 1 (ON-OFF display)	X	—	—	X	
PNP SW 2 (ON-OFF display)	X	—	—	X	
PNP SW 3 (ON-OFF display)	X	—	—	X	
PNP SW 4 (ON-OFF display)	X	—	—	X	
1 POSITION SW (ON-OFF display)	X	—	—	X	
ASCD-CRUISE (ON-OFF display)	X	—	—	X	
ASCD-OD CUT (ON-OFF display)	X	—	—	X	
OD OFF SW (ON-OFF display)	X	—	—	X	Not mounted but displayed.
MANU MODE SW (ON-OFF display)	X	—	—	X	
NON M-MODE SW (ON-OFF display)	X	—	—	X	
UP SW LEVER (ON-OFF display)	X	—	—	X	
DOWN SW LEVER (ON-OFF display)	X	—	—	X	

TROUBLE DIAGNOSIS

Monitored item (Unit)	Monitor Item Selection				Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	CAN DIAG SUP-PORT MNTR	SELECTION FROM MENU	
POWER SHIFT SW (ON-OFF display)	X	—	—	X	Not mounted but displayed.
CLSD THL POS (ON-OFF display)	X	—	—	X	Signal input with CAN communications.
W/O THL POS (ON-OFF display)	X	—	—	X	Signal input with CAN communications.
TCC SOLENOID (A)	—	X	—	X	
LINE PRES SOL (A)	—	X	—	X	
I/C SOLENOID (A)	—	X	—	X	
FR/B SOLENOID (A)	—	X	—	X	
D/C SOLENOID (A)	—	X	—	X	
HLR/C SOL (A)	—	X	—	X	
HOLD SW (ON-OFF display)	X	—	—	X	Not mounted but displayed.
BRAKE SW (ON-OFF display)	X	—	—	X	Stop lamp switch
GEAR	—	X	—	X	Gear position recognized by the TCM updated after gear-shifting.
GEAR RATIO	—	X	—	X	
SLCTLVR POSI	—	X	—	X	Selector lever position is recognized by the TCM. For fail safe operation, the specific value used for control is displayed.
VEHICLE SPEED (km/h)	—	X	—	X	Vehicle speed recognized by the TCM.
TC SLIP SPEED (rpm)	—	X	—	X	Difference between engine speed and torque converter input shaft speed.
CAN COMM (OK-NG)	—	—	X	—	
CAN CIRC 1 (OK-UNKWN)	—	—	X	—	
CAN CIRC 2 (OK-UNKWN)	—	—	X	—	
CAN CIRC 3 (OK-UNKWN)	—	—	X	—	
CAN CIRC 4 (OK-UNKWN)	—	—	X	—	
CAN CIRC 5 (OK-UNKWN)	—	—	X	—	
Voltage (V)	—	—	—	X	Displays the value measured by the voltage probe.
F SUN GO REV (rpm)	—	—	—	X	
F CARR GR REV (rpm)	—	—	—	X	
SFT UP ST SW	—	—	—	X	Not mounted but displayed.
SFT DOWN ST SW	—	—	—	X	
ABS SIGNAL	—	—	—	X	
ACC OD CUT	—	—	—	X	Not mounted but displayed.
ACC SIGNAL	—	—	—	X	
TCS GR/P KEEP	—	—	—	X	
TCS SIGNAL 2	—	—	—	X	
TCS SIGNAL 1	—	—	—	X	
ON OFF SOL (ON-OFF display)	—	—	—	X	LC/B solenoid

TROUBLE DIAGNOSIS

Monitored item (Unit)	Monitor Item Selection				Remarks	
	ECU INPUT SIGNALS	MAIN SIG- NALS	CAN DIAG SUP- PORT MNTR	SELEC- TION FROM MENU		
TCC SOL MON	—	—	—	X		A
L/P SOL MON	—	—	—	X		B
I/C SL MON	—	—	—	X		AT
FR/B SOL MON	—	—	—	X		
D/C SOL MON	—	—	—	X		D
HLR/C SOL MON	—	—	—	X		
ON OFF SOL MON	—	—	—	X	LC/B solenoid	
P POSI IND	—	—	—	X		E
R POSI IND	—	—	—	X		
N POSI IND	—	—	—	X		F
D POSI IND	—	—	—	X		
4TH POSI IND	—	—	—	X		
3RD POSI IND	—	—	—	X		G
2ND POSI IND	—	—	—	X		
1ST POSI IND	—	—	—	X		H
M MODE IND	—	—	—	X		
POWER M LAMP	—	—	—	X		
F-SAFE IND/L	—	—	—	X		I
ATF WARN LAMP	—	—	—	X		
BACK-UP LAMP	—	—	—	X		J
STARTER RELAY	—	—	—	X		
PNP SW3 MON	—	—	—	X		
TRGT GR RATIO	—	—	—	X		K
TRGT PRES TCC	—	—	—	X		
TRGT PRES L/P	—	—	—	X		
TRGT PRES I/C	—	—	—	X		L
TRGT PRES FR/B	—	—	—	X		
TRGT PRES D/C	—	—	—	X		M
TRG PRE HLR/C	—	—	—	X		
SHIFT PATTERN	—	—	—	X		
C/V CLB ID1	—	—	—	X		
C/V CLB ID2	—	—	—	X		
C/V CLB ID3	—	—	—	X		
UNIT CLB ID1	—	—	—	X		
UNIT CLB ID2	—	—	—	X		
UNIT CLB ID3	—	—	—	X		
DRV CST JUDGE	—	—	—	X		
START RLY MON	—	—	—	X		
NEXT GR POSI	—	—	—	X		
SHIFT MODE	—	—	—	X		
MANU GR POSI	—	—	—	X		

TROUBLE DIAGNOSIS

Monitored item (Unit)	Monitor Item Selection				Remarks
	ECU INPUT SIGNALS	MAIN SIG- NALS	CAN DIAG SUP- PORT MNTR	SELEC- TION FROM MENU	
Frequency (Hz)	—	—	—	X	The value measured by the pulse probe is displayed.
DUTY·HI (high) (%)	—	—	—	X	
DUTY·LOW (low) (%)	—	—	—	X	
PLS WIDTH·HI (ms)	—	—	—	X	
PLS WIDTH·LOW (ms)	—	—	—	X	

DTC WORK SUPPORT MODE WITH CONSULT-II

Operation procedure

1. Perform "CONSULT-II SETTING PROCEDURE" Refer to [AT-77, "CONSULT-II SETTING PROCEDURE"](#).
2. Touch "DTC WORK SUPPORT".

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
FUNCTION TEST
DTC WORK SUPPORT
ECU PART NUMBER

SCIA1290E

3. Touch select item menu.

SELECT WORK ITEM
LC/B SOL FUNCTN CHECK
TCC SOL FUNCTN CHECK
D/C SOL FUNCTN CHECK
I/C SOL FUNCTN CHECK
FR/B SOL FUNCTN CHECK
HLR/C SOL FUNCTN CHECK

SCIA0512E

4. Touch “START”.

```
graph TD; A[LC/B SOL FUNCTION CHECK] --> B[LC/B SOL function will be checked.  
confirm its check process and start.]; B --> C[SCIA0513E]
```

The diagram is a flowchart with a single rectangular box. Inside the box, the text reads: "LC/B SOL function will be checked.
confirm its check process and start." Below this box, the text "SCIA0513E" is displayed.

TROUBLE DIAGNOSIS

- Perform driving test according to "DTC CONFIRMATION PROCEDURE" in "TROUBLE DIAGNOSIS FOR DTC".

LC/B SOL FUNCTN CHECK	
OUT OF CONDION	
MONITOR	
ACCELE POSI	XXX
GEAR	XXX
TCC SOLENOID	XXXA
VEHICLE SPEED	XXXkm/h

SCIA0514E

- When testing conditions are satisfied, CONSULT-II screen changes from "OUT OF CONDITION" to "TESTING".

LC/B SOL FUNCTN CHECK	
TESTING	
MONITOR	
ACCELE POSI	XXX
GEAR	XXX
TCC SOLENOID	XXXA
VEHICLE SPEED	XXXkm/h

SCIA0515E

- Stop vehicle. If "NG" appears on the screen, malfunction may exist. Go to "DIAGNOSTIC PROCEDURE".
- Perform test drive to check gear shift feeling in accordance with instructions displayed.
- Touch "YES" or "NO".
- CONSULT-II procedure ended.

LC/B SOL FUNCTN CHECK	
NG	

SCIA0517E

If "NG" appears on the scene, a malfunction may exist. Go to "DIAGNOSTIC PROCEDURE".

LC/B SOL FUNCTN CHECK	
OK	

SCIA0518E

TROUBLE DIAGNOSIS

LC/B SOL FUNCTN CHECK
NG

SCIA0517E

Display items list

DTC work support item	Description	Check item
I/C SOL FUNCTN CHECK*	—	—
FR/B SOL FUNCTN CHECK*	—	—
D/C SOL FUNCTN CHECK*	—	—
HLR/C SOL FUNCTN CHECK*	—	—
LC/B SOL FUNCTN CHECK*	—	—
TCC SOL FUNCTN CHECK	<p>Following items for "TCC solenoid function (lock-up) " can be confirmed.</p> <ul style="list-style-type: none"> Self-diagnosis status (whether the diagnosis is being performed or not) Self-diagnosis result (OK or NG) 	<ul style="list-style-type: none"> TCC solenoid valve Hydraulic control circuit

*: Do not use, but displayed.

Diagnostic Procedure Without CONSULT-II OBD-II SELF-DIAGNOSTIC PROCEDURE (WITH GST)

ACS000HZ

Refer to [EC-117, "Generic Scan Tool \(GST\) Function"](#) .

OBD-II SELF-DIAGNOSTIC PROCEDURE (NO TOOLS)

Refer to [EC-63, "Malfunction Indicator Lamp \(MIL\)"](#) .

TCM SELF-DIAGNOSTIC PROCEDURE (NO TOOLS)

Description

In the unlikely event of a malfunction in the electrical system, when the ignition switch is switched "ON", the A/T CHECK indicator lamp lights up for 2 seconds, then flashes for 8 seconds. If there is no malfunction, when the ignition switch is turned "ON", the indicator lamp lights up for 2 seconds. As a method for locating the suspect circuit, when the self-diagnostics start signal is input, the memory for the malfunction location is output and the A/T CHECK indicator lamp flashes to display the corresponding DTC.

Diagnostic procedure

1. CHECK A/T CHECK INDICATOR LAMP

- Start the engine with selector lever in "P" position. Warm engine to normal operating temperature.
- Turn ignition switch "ON" and "OFF" at least twice, then leave it in the "OFF" position.
- Wait 10 seconds.
- Turn ignition switch to "ON" position. (Do not start engine.)

Does A/T CHECK indicator lamp come on for about 2 seconds?

YES >> GO TO 2.

NO >> GO TO [AT-177, "A/T CHECK Indicator Lamp Does Not Come On"](#) .

TROUBLE DIAGNOSIS

2. JUDGEMENT PROCEDURE STEP 1

1. Turn ignition switch "OFF".
2. Push shift lock release button.
3. Move selector lever from "P" to "D" position.
4. Release accelerator pedal. (Set the closed throttle position signal "ON".)
5. Depress brake pedal. (Stop lamp switch signal "ON".)
6. Turn ignition switch "ON". (Do not start engine.)
7. Wait 3 seconds.
8. Move the selector lever to the Manual shift gate side. (Manual mode switch "ON".)
9. Release brake pedal. (Stop lamp switch signal "OFF".)
10. Move the selector lever to "D" position. (Manual mode switch "OFF".)
11. Depress brake pedal. (Stop lamp switch signal "ON".)
12. Release brake pedal. (Stop lamp switch signal "OFF".)
13. Depress accelerator pedal fully and release it.

>> GO TO 3.

3. CHECK SELF-DIAGNOSIS CODE

Check A/T CHECK indicator lamp.

Refer to [AT-87, "Judgement self-diagnosis code"](#).


If the system does not go into self-diagnostics. Refer to [AT-94, "DTC P0705 PARK/NEUTRAL POSITION SWITCH"](#), [AT-113, "DTC P1705 THROTTLE POSITION SENSOR"](#), [AT-159, "DTC P1815 MANUAL MODE SWITCH"](#), [AT-176, "BRAKE SIGNAL CIRCUIT"](#).

>> DIAGNOSIS END

Judgement self-diagnosis code

If there is a malfunction, the lamp lights up for the time corresponding to the suspect circuit.

1	Revolution sensor 1
2	Direct clutch solenoid valve
3	Torque converter clutch solenoid valve
4	Line pressure solenoid valve
5	Input clutch solenoid valve
6	Front brake solenoid valve
7	Low coast brake solenoid valve
8	High & low reverse clutch solenoid valve
9	PNP switch
10	A/T fluid temperature sensor
11	Turbine revolution sensor
12	A/T interlock
13	A/T 1st engine braking
14	Start signal
15	Accelerator pedal position sensor
16	Engine speed signal
17	CAN



※ Solenoid valve is checked for open and short circuit, and malfunctions.

SCIA0497E

Erase self-diagnosis

- In order to make it easier to find the cause of hard-to-duplicate malfunctions, malfunction information is stored into the control unit as necessary during use by the user. This memory is not erased no matter how many times the ignition switch is turned ON and OFF.
- However, this information is erased by turning ignition switch "OFF" after executing self-diagnostics or by erasing the memory using the CONSULT-II.

DTC U1000 CAN COMMUNICATION LINE

DTC U1000 CAN COMMUNICATION LINE

PFP:23710

Description

ACS003MG

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent malfunction detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

On Board Diagnosis Logic

ACS003MH

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "CAN COMM CIRCUIT" with CONSULT-II or U1000 without CONSULT-II is detected when TCM cannot communicate to other control units.

Possible Cause

ACS003MI

Harness or connectors
(CAN communication line is open or shorted.)

DTC Confirmation Procedure

ACS003MJ

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

⑧ WITH CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
3. Start engine and wait for at least 6 seconds.
4. If DTC is detected, go to [AT-89, "Diagnostic Procedure"](#).

SELECT SYSTEM
A/T
ENGINE

SAT014K

⑧ WITH GST

Follow the procedure "WITH CONSULT-II".

DTC U1000 CAN COMMUNICATION LINE

Diagnostic Procedure

ACS003MK

1. CHECK CAN COMMUNICATION CIRCUIT

With CONSULT-II

1. Turn ignition switch "ON" and start engine.
2. Select "SELF-DIAG RESULTS" mode for "A/T" with CONSULT-II.

Is any malfunction of the "CAN COMM CIRCUIT" indicated?

- YES >> Print out CONSULT-II screen, GO TO 2.
NO >> **INSPECTION END**

SELF-DIAG RESULTS
DTC RESULTS
CAN COMM CIRCUIT
[U1000]
ERASE PRINT
MODE BACK LIGHT COPY
PCIA0061E

2. CHECK CAN COMMUNICATION SIGNALS

With CONSULT-II

1. Turn ignition switch "ON" and start engine.
2. Select "CAN DIAG SUPPORT MNTR" in "DATA MONITOR" mode for "A/T" with CONSULT-II.

>> Print out CONSULT-II screen, go to [LAN-3. "Precautions When Using CONSULT-II"](#).

CAN Communication Signals

Normal conditions	Malfunction conditions (examples)
CAN COMM: OK	CAN COMM: OK
CAN CIRC 1: OK	CAN CIRC 1: UNKWN
CAN CIRC 2: OK	CAN CIRC 2: UNKWN
CAN CIRC 3: OK	CAN CIRC 3: UNKWN
CAN CIRC 4: OK	CAN CIRC 4: UNKWN
CAN CIRC 5: UNKWN	CAN CIRC 5: UNKWN

DTC P0615 START SIGNAL CIRCUIT

DTC P0615 START SIGNAL CIRCUIT

PFP:25230

Description

ACS00016

Prohibits cranking other at "P" or "N" position.

CONSULT-II Reference Value

ACS006C0

Item name	Condition	Display value
STARTER RELAY	Selector lever in N, P position.	ON
	Selector lever in other position.	OFF

On Board Diagnosis Logic

ACS00017

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "STARTER RELAY/CIRC" with CONSULT-II or 14th judgement flicker without CONSULT-II is detected when detects as irregular when switched "ON" other than at "P" or "N" position. (Or when switched "OFF" at "P" or "N" position).

Possible Cause

ACS00018

- Harness or connectors
(Starter relay and TCM circuit is open or shorted.)
- Starter relay circuit

DTC Confirmation Procedure

ACS00019

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine.
4. Vehicle start for at least 2 consecutive seconds.
5. If DTC is detected, go to [AT-91, "Diagnostic Procedure"](#).

SELECT SYSTEM
A/T
ENGINE

SAT014K

DTC P0615 START SIGNAL CIRCUIT

Diagnostic Procedure


ACS0001B

1. CHECK STARTER RELAY

With CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II and check monitor "STARTER RELAY" ON/OFF.

Item name	Condition	Display value
STARTER RELAY	Selector lever in N, P position.	ON
	Selector lever in other position.	OFF




Without CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Check the voltage between the IPDM E/R connector and ground.

Item	Connector	Terminal (Wiring color)		Shift position	Voltage (Approx.)
Starter relay	E9	53 (GY/R)	Ground	N and P	Battery voltage
				R, D and M	0V

OK or NG

- OK >> GO TO 3.
NG >> GO TO 2.



2. DETECT MALFUNCTIONING ITEM

Check the following items:

- Starter relay, Refer to [SC-10, "STARTING SYSTEM"](#) .
- Disconnections or short-circuits in the harness between TCM and IPDM E/R.
- Disconnections or short-circuits in the harness between TCM and unified meter and A/C amp.

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

3. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The TCM pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
NG >> Repair or replace damaged parts.

DTC P0615 START SIGNAL CIRCUIT

5. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-90, "DTC Confirmation Procedure"](#).

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 3.

DTC P0700 TCM

PF0:31036

Description

ACS006DL

The TCM consists of a microcomputer and connectors for signal input and output and for power supply. The TCM controls the A/T.

On Board Diagnosis Logic

ACS006DM

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "TCM" with CONSULT-II or P0700 without CONSULT-II is detected when TCM is malfunctioning.

Possible Cause

ACS006DN

TCM.

DTC Confirmation Procedure

ACS006DO

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine.
4. Run engine for at least 2 consecutive seconds at idle speed.
5. If DTC is detected, go to [AT-93, "Diagnostic Procedure"](#).

SELECT SYSTEM
A/T
ENGINE

SAT014K

Diagnostic Procedure

ACS006DP

1. CHECK DTC

With CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "SELF DIAG RESULTS" mode for "A/T" with CONSULT-II.
3. Touch "ERASE".
4. Turn ignition switch "OFF" and wait at least 10 seconds.
5. Perform DTC confirmation procedure, [AT-93, "DTC Confirmation Procedure"](#).

Is the "TCM" displayed again?

- YES >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
- NO >> **INSPECTION END**

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
FUNCTION TEST
DTC WORK SUPPORT
ECU PART NUMBER

SCIA1290E

DTC P0705 PARK/NEUTRAL POSITION SWITCH

DTC P0705 PARK/NEUTRAL POSITION SWITCH

PFP:32006

Description

ACS003ML

- The park/neutral position (PNP) switch includes a transmission range switch.
- The transmission range switch detects the selector lever position and sends a signal to the TCM.

CONSULT-II Reference Value

ACS003MM

Item name	Condition	Display value
SLCTLVR POSI	Selector lever in "N", "P" position.	N/P
	Selector lever in "R" position.	R
	Selector lever in "D" position.	D

On Board Diagnosis Logic

ACS003MN

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "PNP SW/CIRC" with CONSULT-II or P0705 without CONSULT-II is detected under the following conditions.
 - When TCM does not receive the correct voltage signal from the PNP switch 1, 2, 3, 4 based on the gear position.
 - When no other position but "P" position is detected from "N" positions.

Possible Cause

ACS003MO

- Harness or connectors
[Park/neutral position (PNP) switch 1, 2, 3, 4 and TCM circuit is open or shorted.]
- Park/neutral position (PNP) switch 1, 2, 3, 4

DTC Confirmation Procedure

ACS003MP

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

④ WITH CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
3. Start engine.
4. Drive vehicle and maintain the following conditions for at least 2 consecutive seconds.

THRTL POS SEN: More than 1.2V

5. If DTC is detected, go to [AT-95, "Diagnostic Procedure"](#).

SELECT SYSTEM
A/T
ENGINE

SAT014K

④ WITH GST

Follow the procedure "With CONSULT-II".

DTC P0705 PARK/NEUTRAL POSITION SWITCH

Diagnostic Procedure

ACS003MQ

1. CHECK PNP SW CIRCUIT

With CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Read out "N·P", "R" and "D" position switches moving selector lever to each position.

Item name	Condition	Display value
SLCTLVR POSI	Selector lever in "N", "P" position.	N/P
	Selector lever in "R" position.	R
	Selector lever in "D" position.	D

DATA MONITOR	
MONITOR	NO DTC
ATF PRES SW 2	OFF
ATF PRES SW 3	OFF
ATF PRES SW 5	OFF
ATF PRES SW 6	OFF
SLCT LVR POSI	N·P

Δ	▽
RECORD	
MODE	BACK
LIGHT	COPY

PCIA0034E

OK or NG

- OK >> GO TO 6.
NG >> GO TO 2.

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#).

OK or NG

- OK >> GO TO 3.
NG >> GO TO 5.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-94, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
NG >> Repair or replace damaged parts.

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
NG >> Repair or replace damaged parts.

DTC P0705 PARK/NEUTRAL POSITION SWITCH

6. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-94, "DTC Confirmation Procedure"](#).

OK or NG

OK	>> INSPECTION END
NG	>> GO TO 2.

DTC P0720 VEHICLE SPEED SENSOR A/T (REVOLUTION SENSOR)

DTC P0720 VEHICLE SPEED SENSOR A/T (REVOLUTION SENSOR)

PFP:32702

Description

ACS003MR

The revolution sensor detects the revolution of the idler gear parking pawl lock gear and emits a pulse signal. The pulse signal is sent to the TCM which converts it into vehicle speed.

CONSULT-II Reference Value

ACS003MS

Item name	Condition	Display value (km/h)
VHCL/S SE-A/T	During driving	Approximately matches the speedometer reading.

On Board Diagnosis Logic

ACS003MT

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "VEH SPD SEN/CIR AT" with CONSULT-II or P0720 without CONSULT-II is detected under the following conditions.
 - When TCM does not receive the proper voltage signal from the sensor.
 - After ignition switch is turned "ON", irregular signal input from vehicle speed sensor MTR before the vehicle starts moving.

Possible Cause

ACS003MU

- Harness or connectors
(Sensor circuit is open or shorted.)
- Revolution sensor
- Vehicle speed sensor MTR

DTC Confirmation Procedure

ACS003MV

CAUTION:

- Always drive vehicle at a safe speed.
- Be careful not to rev engine into the red zone on the tachometer.

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Drive vehicle and check for an increase of "VHCL/S SE-A/T" value in response to "VHCL/S SE-MTR" value.
If the check result is NG, go to [AT-98, "Diagnostic Procedure"](#).
If the check result is OK, go to following step.
4. Select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
5. Start engine and maintain the following conditions for at least 5 consecutive seconds.
VHCL SPEED SE: 30 km/h (19 MPH) or more
THRTL POS SEN: More than 1.0/8
Selector lever: "D" position
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
If the check result is NG, go to [AT-98, "Diagnostic Procedure"](#).
If the check result is OK, go to following step.
6. Maintain the following conditions for at least 5 consecutive seconds.
ENGINE SPEED: 3,500 rpm or more
THRTL POS SEN: More than 1.0/8
Selector lever: "D" position
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
If the check result is NG, go to [AT-98, "Diagnostic Procedure"](#).

SELECT SYSTEM
A/T
ENGINE

SAT014K

DTC P0720 VEHICLE SPEED SENSOR A/T (REVOLUTION SENSOR)

WITH GST

Follow the procedure "With CONSULT-II".

Diagnostic Procedure

ACS003MW

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start the engine.
4. Read out the value of "VHCL/S SE-A/T" while driving.
Check the value changes according to driving speed.

Item name	Condition	Display value (km/h)
VHCL/S SE-A/T	During driving	Approximately matches the speedometer reading.

DATA MONITOR	
MONITOR	NO DTC
VHCL/S SE-A/T	0km/h
VHCL/S SE-MTR	0km/h
ACCELE POSI	0.0/8
THROTTLE POS	0.0/8
CLSD THL POS	ON
W/O THL POS	OFF
▽	
RECORD	
MODE	BACK
LIGHT	COPY

SCIA2148E

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 2.

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#).

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 5.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-97, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
- NG >> Repair or replace damaged parts.

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
- NG >> Repair or replace damaged parts.

DTC P0720 VEHICLE SPEED SENSOR A/T (REVOLUTION SENSOR)

6. CHECK DTC

Perform “DTC Confirmation Procedure”.

- Refer to [AT-97, "DTC Confirmation Procedure"](#) .

OK or NG

OK >> **INSPECTION END**
NG >> GO TO 2.

A

B

AT

D

E

F

G

H

I

J

K

L

M

DTC P0725 ENGINE SPEED SIGNAL

DTC P0725 ENGINE SPEED SIGNAL

PFP:24825

Description

ACS003MX

The engine speed signal is sent from the ECM to the TCM.

CONSULT-II Reference Value

ACS003MY

Item name	Condition	Display value (rpm)
ENGINE SPEED	Engine running	Closely matches the tachometer reading.

On Board Diagnosis Logic

ACS003MZ

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "ENGINE SPEED SIG" with CONSULT-II or P0725 without CONSULT-II is detected when TCM does not receive the ignition signal from ECM during engine cranking or running.

Possible Cause

ACS003N0

Harness or connectors
(ECM to TCM circuit is open or shorted.)

DTC Confirmation Procedure

ACS003N1

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode for "A/T" with CONSULT-II.
2. Start engine and maintain the following conditions for at least 10 consecutive seconds.
VHCL SPEED SE: 10 km/h (6 MPH) or more
ACCELE POSI: More than 1/8
Selector lever: "D" position
3. If DTC is detected, go to [AT-100, "Diagnostic Procedure"](#).

SELECT SYSTEM
A/T
ENGINE

SAT014K

WITH GST

Follow the procedure "With CONSULT-II".

Diagnostic Procedure

ACS003N2

1. CHECK CAN COMMUNICATION LINE

Perform the self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#), [AT-86, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#).

Is a malfunction in the CAN communication indicated in the results?

- YES >> Check CAN communication line. Refer to [AT-88, "DTC U1000 CAN COMMUNICATION LINE"](#).
- NO >> GO TO 2.

DTC P0725 ENGINE SPEED SIGNAL

2. CHECK DTC WITH TCM

With CONSULT-II

1. Start engine.
2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. While monitoring engine speed, check for engine speed change corresponding to wide-open throttle position signal.

Item name	Condition	Display value (rpm)
ENGINE SPEED	Engine running	Closely matches the tachometer reading.

DATA MONITOR	
MONITOR	NO DTC
W/O THL POS	OFF
BRAKE SW	OFF
ENGINE SPEED	0 rpm
TURBINE REV	0 rpm
OUTPUT REV	0 rpm
<div>▼</div>	
RECORD	
MODE	BACK
LIGHT	COPY

PCIA0041E

With GST

Follow the procedure "With CONSULT-II".

OK or NG

- OK >> GO TO 3.
NG >> Check the ignition signal circuit.
- Refer to [EC-621, "IGNITION SIGNAL"](#) .

3. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
NG >> Repair or replace damaged parts.

5. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-100, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 3.

DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

PFP:31940

Description

ACS003N3

- The torque converter clutch solenoid valve is activated, with the gear in D4 , D5 by the TCM in response to signals sent from the vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Torque converter clutch piston operation will then be controlled.
- Lock-up operation, however, is prohibited when A/T fluid temperature is too low.
- When the accelerator pedal is depressed (less than 1/8) in lock-up condition, the engine speed should not change abruptly. If there is a big jump in engine speed, there is no lock-up.

CONSULT-II Reference Value

ACS003N4

Item name	Condition	Display value (Approx.)
TCC SOLENOID	When performing slip lock-up	0.2 - 0.4 A
	When performing lock-up	0.4 - 0.6 A

On Board Diagnosis Logic

ACS003N5

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code “TCC SOLENOID/CIRC” with CONSULT-II or P0740 without CONSULT-II is detected under the following conditions.
 - When TCM detects an improper voltage drop when it tries to operate the solenoid valve.
 - When TCM detects as irregular by comparing target value with monitor value.

Possible Cause

ACS003N6

- Torque converter clutch solenoid valve
- Harness or connectors
(Solenoid circuit is open or shorted.)

DTC Confirmation Procedure

ACS003N7

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch “OFF” and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

① WITH CONSULT-II

1. Turn ignition switch “ON”. (Do not start engine.)
2. Select “DATA MONITOR” mode for “ENGINE” with CONSULT-II.
3. Start engine and maintain the following conditions for at least 5 consecutive seconds.
VHCL SPEED SE: 80 km/h (50 MPH) or more
ACCELE POSI: 0.5/8 - 1.0/8
SELECTOR LEVER: “D” position
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
4. If DTC is detected go to [AT-103, "Diagnostic Procedure"](#).

SELECT SYSTEM
A/T
ENGINE

SAT014K

② WITH GST

Follow the procedure “With CONSULT-II”.

DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

Diagnostic Procedure

ACS003NB

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start the engine.
4. Read out the value of "TCC SOLENOID" while driving.

DATA MONITOR	
MONITOR	NO DTC
TCC SOLENOID	XXXX
LINE PRES SOL	XXXX
I/C SOLENOID	XXXX
FR/B SOLENOID	XXXX
D/C SOLENOID	XXXX
HLR/C SOL	XXXX
▽	
RECORD	
MODE	BACK
LIGHT	COPY

SCIA4793E

Item name	Condition	Display value (Approx.)
TCC SOLENOID	When performing slip lock-up	0.2 - 0.4 A
	When performing lock-up	0.4 - 0.6 A

OK or NG

- OK >> GO TO 6.
NG >> GO TO 2.

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#).

OK or NG

- OK >> GO TO 3.
NG >> GO TO 5.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-102, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
NG >> Repair or replace damaged parts.

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
NG >> Repair or replace damaged parts.

DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

6. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-102, "DTC Confirmation Procedure"](#).

OK or NG

OK	>> INSPECTION END
NG	>> GO TO 2.

DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

PPF:31940

Description

ACS003N9

This malfunction is detected when the A/T does not shift into 5th gear position or the torque converter clutch does not lock-up as instructed by the TCM. This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation, etc.

CONSULT-II Reference Value

ACS003NA

Item name	Condition	Display value (Approx.)
TCC SOLENOID	When performing slip lock-up	0.2 - 0.4 A
	When performing lock-up	0.4 - 0.6 A

On Board Diagnosis Logic

ACS003NB

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "A/T TCC S/V FNCTN" with CONSULT-II or P0744 without CONSULT-II is detected under the following conditions.
 - When A/T cannot perform lock-up even if electrical circuit is good.
 - When TCM detects as irregular by comparing difference value with slip rotation.

Possible Cause

ACS003NC

- Harness or connectors
(Solenoid circuit is open or shorted.)
- Torque converter clutch solenoid valve
- Hydraulic control circuit

DTC Confirmation Procedure

ACS003ND

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Start engine and Select "TCC SOL FUNCTN CHECK" of "DTC WORK SUPPORT" mode for "A/T" with CONSULT-II and touch "START".
2. Accelerate vehicle to more than 80 km/h (50 MPH) and maintain the following condition continuously until "TESTING" has turned to "COMPLETE". (It will take approximately 30 seconds after "TESTING" shows.)

ACCELE POSI: More than 1.0/8 (at all times during step 4)

TCC SOLENOID: 0.4 - 0.6 A

Selector lever: "D" position

[Reference speed: Constant speed of more than 80 km/h (50 MPH)]

- Make sure "GEAR" shows "5".
 - For shift schedule, refer to [AT-65, "Vehicle Speed When Performing and Releasing Complete Lock-up"](#).
 - If "TESTING" does not appear on CONSULT-II for a long time, select "SELF-DIAG RESULTS". In case a 1st trip DTC other than P0744 is shown, refer to applicable "TROUBLE DIAGNOSIS FOR DTC".
3. Make sure that "OK" is displayed. (If "NG" is displayed, refer to "DIAGNOSTIC PROCEDURE".)
Refer to [AT-106, "Diagnostic Procedure"](#).
Refer to shift schedule, [AT-65, "Vehicle Speed When Performing and Releasing Complete Lock-up"](#).

SELECT SYSTEM
A/T
ENGINE

SAT014K

DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

WITH GST

Follow the procedure "With CONSULT-II".

Diagnostic Procedure

ACS003NE

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start the engine.
4. Read out the value of "TCC SOLENOID" while driving.

DATA MONITOR	
MONITOR	NO DTC
TCC SOLENOID	XXXX
LINE PRES SOL	XXXX
I/C SOLENOID	XXXX
FR/B SOLENOID	XXXX
D/C SOLENOID	XXXX
HLR/C SOL	XXXX
▽	
RECORD	
MODE	BACK
LIGHT	COPY

SCIA4793E

Item name	Condition	Display value (Approx.)
TCC SOLENOID	When performing slip lock-up	0.2 - 0.4 A
	When performing lock-up	0.4 - 0.6 A

With GST

Follow the procedure "With CONSULT-II".

OK or NG

- OK >> GO TO 6.
NG >> GO TO 2.

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

- OK >> GO TO 3.
NG >> GO TO 5.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-105, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
NG >> Repair or replace damaged parts.

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
NG >> Repair or replace damaged parts.

DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

6. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-105, "DTC Confirmation Procedure"](#).

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 2.

A

B

AT

D

E

F

G

H

I

J

K

L

M

DTC P0745 LINE PRESSURE SOLENOID VALVE

DTC P0745 LINE PRESSURE SOLENOID VALVE

PFP:31940

Description

ACS003NF

The line pressure solenoid valve regulates the oil pump discharge pressure to suit the driving condition in response to a signal sent from the TCM.

The line pressure duty cycle value is not consistent when the closed throttle position signal is “ON”. To confirm the line pressure duty cycle at low pressure, the accelerator (throttle) should be open until the closed throttle position signal is “OFF”.

CONSULT-II Reference Value

ACS003NG

Item name	Condition	Display value (Approx.)
LINE PRES SOL	During driving	0.2 - 0.6 A

On Board Diagnosis Logic

ACS003NH

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code “L/PRESS SOL/CIRC” with CONSULT-II or P0745 without CONSULT-II is detected under the following conditions.
 - When TCM detects an improper voltage drop when it tries to operate the solenoid valve.
 - When TCM detects as irregular by comparing target value with monitor value.

Possible Cause

ACS003NI

- Harness or connectors
(Solenoid circuit is open or shorted.)
- Line pressure solenoid valve

DTC Confirmation Procedure

ACS003NJ

NOTE:

If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch “OFF” and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch “ON” and select “DATA MONITOR” mode for “ENGINE” with CONSULT-II.
2. Engine start and wait at least 5 second.
3. If DTC is detected, go to [“AT-109, “Diagnostic Procedure”](#) .

SELECT SYSTEM
A/T
ENGINE

SAT014K

WITH GST

Follow the procedure “With CONSULT-II”.

DTC P0745 LINE PRESSURE SOLENOID VALVE

Diagnostic Procedure

ACS003NK

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start the engine.
4. Read out the value of "LINE PRES SOL" while driving.

Item name	Condition	Display value (Approx.)
LINE PRES SOL	During driving	0.2 - 0.6 A

DATA MONITOR	
MONITOR	NO DTC
TCC SOLENOID	XXXXA
LINE PRES SOL	XXXXA
I/C SOLENOID	XXXXA
FR/B SOLENOID	XXXXA
D/C SOLENOID	XXXXA
HLR/C SOL	XXXXA
▽	
RECORD	
MODE	BACK
LIGHT	COPY

SCIA4793E

With GST

Follow the procedure "With CONSULT-II".

OK or NG

- OK >> GO TO 6.
NG >> GO TO 2.

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#).

OK or NG

- OK >> GO TO 3.
NG >> GO TO 5.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-108, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
NG >> Repair or replace damaged parts.

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
NG >> Repair or replace damaged parts.

DTC P0745 LINE PRESSURE SOLENOID VALVE

6. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-108, "DTC Confirmation Procedure"](#).

OK or NG

OK	>> INSPECTION END
NG	>> GO TO 2.

DTC P1702 TRANSMISSION CONTROL MODULE (RAM)

DTC P1702 TRANSMISSION CONTROL MODULE (RAM)

PDF:31036

Description

ACS003NQ

The TCM consists of a microcomputer and connectors for signal input and output and for power supply. The TCM controls the A/T.

On Board Diagnosis Logic

ACS003NR

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "TCM-RAM" with CONSULT-II is detected when TCM memory RAM is malfunctioning.

Possible Cause

ACS003NS

TCM.

DTC Confirmation Procedure

ACS003NT


NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine.
4. Run engine for at least 2 consecutive seconds at idle speed.
5. If DTC is detected, go to [AT-111, "Diagnostic Procedure"](#).



Diagnostic Procedure

ACS003NU


1. CHECK DTC

With CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "SELF-DIAG RESULTS" mode for "A/T" with CONSULT-II.
3. Touch "ERASE".
4. Turn ignition switch "OFF" and wait at least 10 seconds.
5. Perform "DTC confirmation procedure", [AT-111, "DTC Confirmation Procedure"](#).

Is the "TCM-RAM" displayed again?

- YES >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
- NO >> **INSPECTION END**



DTC P1703 TRANSMISSION CONTROL MODULE (ROM)

DTC P1703 TRANSMISSION CONTROL MODULE (ROM)

PFP:31036

Description

ACS003NV

The TCM consists of a microcomputer and connectors for signal input and output and for power supply. The TCM controls the A/T.

On Board Diagnosis Logic

ACS003NW

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "TCM-ROM" with CONSULT-II is detected when TCM memory ROM is malfunctioning.

Possible Cause

ACS003NX

TCM.

DTC Confirmation Procedure

ACS003NY


NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

① WITH CONSULT-II

1. Turn ignition switch to "ON". (Do not start engine.)
2. Select "DATA MONITOR" mode for A/T with CONSULT-II.
3. Start engine.
4. Run engine for at least 2 consecutive seconds at idle speed.
5. If DTC is detected, go to [AT-112. "Diagnostic Procedure"](#).



Diagnostic Procedure

ACS003NZ


1. CHECK DTC

① With CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "SELF-DIAG RESULTS" mode for "A/T" with CONSULT-II.
3. Touch "ERASE".
4. Turn ignition switch "OFF" and wait at least 10 seconds.
5. Perform "DTC confirmation procedure", [AT-112. "DTC Confirmation Procedure"](#).

Is the "TCM-ROM" displayed again?

- YES >> Replace the transmission assembly. Refer to [AT-212. "Removal and Installation"](#).
- NO >> **INSPECTION END**



DTC P1705 THROTTLE POSITION SENSOR

DTC P1705 THROTTLE POSITION SENSOR

PFP:22620

Description

ACS00305

Electric throttle control actuator consists of throttle control motor, accelerator pedal position sensor, throttle position sensor, etc. The actuator sends a signal to the ECM, and ECM sends signals to TCM with CAN communication.

CONSULT-II Reference Value

ACS006C1

Item name	Condition	Display value (Approx.)
THROTTLE POSI	Released accelerator pedal.	0.0/8
	Fully depressed accelerator pedal.	8/8

On Board Diagnosis Logic

ACS00306

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "TP SEN/CIRC A/T" with CONSULT-II or P1705 without CONSULT-II is detected when TCM does not receive the proper accelerator pedal position signals (input by CAN communication) from ECM.

Possible Cause

ACS00307

Harness or connectors
(Sensor circuit is open or shorted.)

DTC Confirmation Procedure

ACS00308

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to ["AT-113, "Diagnostic Procedure"](#) .

SELECT SYSTEM
A/T
ENGINE

SAT014K

WITH GST

Follow the procedure "With CONSULT-II".

Diagnostic Procedure

ACS00309

1. CHECK CAN COMMUNICATION LINE

Perform the self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-86, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Is a malfunction in the CAN communication indicated in the results?

- YES >> Check CAN communication line. Refer to [AT-88, "DTC U1000 CAN COMMUNICATION LINE"](#) .
- NO >> GO TO 2.

DTC P1705 THROTTLE POSITION SENSOR

2. CHECK DTC WITH ECM

With CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "SELF-DIAG RESULTS" mode for "ENGINE" with CONSULT-II. Refer to [EC-104, "CONSULT-II Function"](#) .

With GST


Follow the procedure "With CONSULT-II".

OK or NG

OK >> GO TO 3.

NG >> Check the DTC detected item. Refer to [EC-104, "CONSULT-II Function"](#) .

- If CAN communication line is detected, go to [AT-88, "DTC U1000 CAN COMMUNICATION LINE"](#) .



3. CHECK DTC WITH TCM

With CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Depress accelerator pedal and read out the value of "ACCLE POS" and "THROTTLE POSI".
Check engine speed changes according to throttle position.

DATA MONITOR	
MONITOR	NO. DTC
ACCELE POSI	0.0/8
THROTTLE POSI	0.0/8
CLSD THL POS	ON
W/O THL POS	OFF
BRAKE SW	OFF
▽	
RECORD	
MODE	BACK
LIGHT	COPY

PCIA0070E

Item name	Condition	Display value (Approx.)
THROTTLE POSI	Released accelerator pedal.	0.0/8
	Fully depressed accelerator pedal.	8/8

4. Select "SELF-DIAG RESULTS" mode for "A/T" with CONSULT-II. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) .

With GST

Follow the procedure "With CONSULT-II".

OK or NG

OK >> GO TO 4.

NG >> Repair or replace damaged parts.

4. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-113, "DTC Confirmation Procedure"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .

DTC P1710 A/T FLUID TEMPERATURE SENSOR CIRCUIT

DTC P1710 A/T FLUID TEMPERATURE SENSOR CIRCUIT

PFP:31940

Description

ACS0030A

The A/T fluid temperature sensor detects the A/T fluid temperature and sends a signal to the TCM.

CONSULT-II Reference Value

ACS0030B

Item name	Condition °C (°F)	Display value (Approx.)
ATF TEMP SE 1	0 (32) - 20 (68) - 80 (176)	3.2 - 2.5 - 0.8 V
ATF TEMP SE 2		3.2 - 2.4 - 0.65 V

On Board Diagnosis Logic

ACS0030C

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "ATF TEMP SEN/CIRC" with CONSULT-II or P1710 (A/T), P0710 (ENGINE) without CONSULT-II is detected when TCM receives an excessively low or high voltage from the sensor.

Possible Cause

ACS0030D

- Harness or connectors
(Sensor circuit is open or shorted.)
- A/T fluid temperature sensors 1, 2

DTC Confirmation Procedure

ACS0030E

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

⑧ WITH CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
3. Start engine and maintain the following conditions for at least 10 minutes (Total). (It is not necessary to maintain continuously.)
VHCL SPEED SE: 10 km/h (6 MPH) or more
THRTL POS SEN: More than 1.0/8
Selector lever: "D" position
4. If DTC is detected, go to [AT-116, "Diagnostic Procedure"](#).

SELECT SYSTEM
A/T
ENGINE

SAT014K

⑧ WITH GST

Follow the procedure "With CONSULT-II".

DTC P1710 A/T FLUID TEMPERATURE SENSOR CIRCUIT

Diagnostic Procedure

ACS0030F

1. CHECK FLUID TEMPERATURE SENSOR

With CONSULT-II

1. Start engine.
2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Read out the value of "ATF TEMP SE 1" and "ATF TEMP SE 2".

Item name	Condition °C (°F)	Display value (Approx.)
ATF TEMP SE 1	0 (32) - 20 (68) - 80 (176)	3.2 - 2.5 - 0.8 V
ATF TEMP SE 2		3.2 - 2.4 - 0.65 V

OK or NG

- OK >> GO TO 6.
NG >> GO TO 2.

DATA MONITOR													
MONITOR	NO. DTC												
OUTPUT REV	0 rpm												
ATF TEMP SE 1	1.84 v												
ATF TEMP SE 2	1.72 v												
BATTERY BOLT	11.5 v												
ATF PRES SW 1	OFF												
<table><tr><td colspan="2">△</td><td colspan="2">▽</td></tr><tr><td colspan="4">RECORD</td></tr><tr><td>MODE</td><td>BACK</td><td>LIGHT</td><td>COPY</td></tr></table>		△		▽		RECORD				MODE	BACK	LIGHT	COPY
△		▽											
RECORD													
MODE	BACK	LIGHT	COPY										

PCIA0039E

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#).

OK or NG

- OK >> GO TO 3.
NG >> GO TO 5.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-115, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
NG >> Repair or replace damaged parts.

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
NG >> Repair or replace damaged parts.

6. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-115, "DTC Confirmation Procedure"](#) .

OK or NG

OK >> **INSPECTION END**
NG >> GO TO 2.

A
B
AT
D
E
F
G
H
I
J
K
L
M

DTC P1716 TURBINE REVOLUTION SENSOR

DTC P1716 TURBINE REVOLUTION SENSOR

PFP:31935

Description

ACS0030G

The turbine revolution sensor detects input shaft rpm (revolutions per minute). It is located on the input side of the automatic transmission. Monitors revolution of sensor 1 and sensor 2 for non-standard conditions.

CONSULT-II Reference Value

ACS0030H

Item name	Condition	Display value (rpm)
TURBINE REV	During driving (lock-up ON)	Approximately matches the engine speed.

On Board Diagnosis Logic

ACS0030I

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "TURBINE REV S/CIRC" with CONSULT-II or P1716 without CONSULT-II is detected under the following conditions.
 - When TCM does not receive the proper voltage signal from the sensor.
 - When TCM detects an irregularity only at position of 4th gear for turbine revolution sensor 2.

Possible Cause

ACS0030J

- Harness or connectors
(Sensor circuit is open or shorted.)
- Turbine revolution sensor 1, 2

DTC Confirmation Procedure

ACS0030K

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

④ WITH CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine and maintain the following conditions for at least 5 consecutive seconds.

VHCL SPEED SE: 40 km/h (25 MPH) or more

ENGINE SPEED: 1,500 rpm or more

ACCELE POSI: 0.5/8 or more

Selector lever: "D" position

Gear position (Turbine revolution sensor 1): 4th or 5th position

Gear position (Turbine revolution sensor 2): All position

Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.

4. If DTC is detected, go to [AT-119, "Diagnostic Procedure"](#).

④ WITH GST

Follow the procedure "With CONSULT-II".

SELECT SYSTEM
A/T
ENGINE

SAT014K

DTC P1716 TURBINE REVOLUTION SENSOR

Diagnostic Procedure

ACS0030L

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Start engine.
2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Vehicle start and read out the value of "TURBINE REV".

Item name	Condition	Display value (rpm)
TURBINE REV	During driving (lock-up ON)	Approximately matches the engine speed.

OK or NG

- OK >> GO TO 6.
NG >> GO TO 2.

DATA MONITOR	
MONITOR	NO DTC
W/O THL POS	OFF
BRAKE SW	OFF
ENGINE SPEED	0 rpm
TURBINE REV	0 rpm
OUTPUT REV	0 rpm
▼	
RECORD	
MODE	BACK
LIGHT	COPY

PCIA0041E

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#).

OK or NG

- OK >> GO TO 3.
NG >> GO TO 5.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-118, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
NG >> Repair or replace damaged parts.

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
NG >> Repair or replace damaged parts.

DTC P1716 TURBINE REVOLUTION SENSOR

6. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-118, "DTC Confirmation Procedure"](#).

OK or NG

OK	>> INSPECTION END
NG	>> GO TO 2.

DTC P1721 VEHICLE SPEED SENSOR MTR

DTC P1721 VEHICLE SPEED SENSOR MTR

PFP:24814

Description

ACS0030M

The vehicle speed sensor-MTR signal is transmitted from combination meter to TCM by CAN communication line. The signal functions as an auxiliary device to the revolution sensor when it is malfunctioning. The TCM will then use the vehicle speed sensor-MTR signal.

CONSULT-II Reference Value

ACS0030N

Item name	Condition	Display value (Approx.) (km/h)
VHCL/S SE-MTR	During driving	Approximately matches the speedometer reading.

On Board Diagnosis Logic

ACS0030O

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "VHE SPD SE/CIR-MTR" with CONSULT-II is detected when TCM does not receive the proper vehicle speed sensor MTR signal (input by CAN communication) from combination meter.

Possible Cause

ACS0030P

Harness or connectors
(Sensor circuit is open or shorted.)

DTC Confirmation Procedure

ACS0030Q

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

⑧ WITH CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine and maintain the following conditions for at least 5 consecutive seconds.
ACCELE POSI: 1/8 or less
VHCL SPEED SE: 30 km/h (17 MPH) or more
4. If DTC is detected, go to [AT-122, "Diagnostic Procedure"](#).

SELECT SYSTEM
A/T
ENGINE

SAT014K

DTC P1721 VEHICLE SPEED SENSOR MTR

ACS0030R

Diagnostic Procedure

1. CHECK CAN COMMUNICATION LINE

Perform the self-diagnosis. Refer [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-86, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Is a malfunction in the CAN communication indicated in the results?

- YES >> Check CAN communication line. Refer to [AT-88, "DTC U1000 CAN COMMUNICATION LINE"](#) .
NO >> GO TO 2.

2. CHECK INPUT SIGNALS

With CONSULT-II

1. Start engine.
2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Drive vehicle and read out the value of "VHCL/S SE·MTR".

Item name	Condition	Display value (km/h)
VHCL/S SE·MTR	During driving	Approximately matches the speedometer reading.

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

DATA MONITOR	
MONITOR	NO DTC
VHCL/S SE·A/T	0km/h
VHCL/S SE·MTR	0km/h
ACCELE POSI	0.0/8
THROTTLE POS	0.0/8
CLSD THL POS	ON
W/O THL POS	OFF
▽	
RECORD	
MODE	BACK
LIGHT	COPY

SCIA2148E

3. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
NG >> Repair or replace damaged parts.

5. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-121, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 3.

DTC P1730 A/T INTERLOCK

DTC P1730 A/T INTERLOCK

PFP:00000

Description

ACS0030S

- Fail-safe function to detect interlock conditions.

On Board Diagnosis Logic

ACS0030T

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "A/T INTERLOCK" with CONSULT-II or P1730 without CONSULT-II is detected when TCM does not receive the proper voltage signal from the sensor and switch.
- TCM monitors and compares gear position and conditions of each ATF pressure switch when gear is steady.

Possible Cause

ACS0030U

- Harness or connectors
(Solenoid and switch circuit is open or shorted.)
- Low coast brake solenoid valve
- ATF pressure switch 2

DTC Confirmation Procedure

ACS0030V


NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine.
4. Drive vehicle and maintain the following conditions for at least 2 consecutive seconds.
Selector lever: "D" position
5. If DTC is detected, go to [AT-124, "Diagnostic Procedure"](#).



WITH GST

Follow the procedure "With CONSULT-II".

Judgement of A/T Interlock

ACS0030W

When A/T Interlock is judged to be malfunctioning, the vehicle should be fixed in 2nd gear, and should be set in a condition in which it can travel.

When one of the following fastening patterns is detected, the fail-safe function in correspondence with the individual pattern should be performed.

DTC P1730 A/T INTERLOCK

A/T INTERLOCK COUPLING PATTERN TABLE

●: NG, X: OK

Gear position		ATF pressure switch output					Fail-safe function	Clutch pressure output pattern after fail-safe function					
		SW3 (I/C)	SW6 (HLR/C)	SW5 (D/C)	SW1 (FR/B)	SW2 (LC/B)		I/C	HLR/C	D/C	FR/B	LC/B	L/U
A/T interlock coupling pattern	3rd	—	X	X	—	●	Held in 2nd gear	OFF	OFF	ON	OFF	OFF	OFF
	4th	—	X	X	—	●	Held in 2nd gear	OFF	OFF	ON	OFF	OFF	OFF
	5th	X	X	—	X	●	Held in 2nd gear	OFF	OFF	ON	OFF	OFF	OFF

Diagnostic Procedure

ACS0030X

1. SELF-DIAGNOSIS

With CONSULT-II

1. Drive vehicle.
2. Stop vehicle and turn ignition switch "OFF".
3. Turn ignition switch "ON". (Do not start engine.)
4. Select "SELF-DIAG RESULTS" mode for "A/T" with CONSULT-II.

SELECT SYSTEM
A/T
ENGINE

SAT014K

Without CONSULT-II

1. Drive vehicle.
2. Stop vehicle and turn ignition switch OFF.
3. Turn ignition switch "ON". (Do not start engine.)
4. Perform self-diagnosis. Refer to [AT-86, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#).

OK or NG

OK >> GO TO 6.

NG >> Check low coast brake solenoid valve circuit and function. Refer to [AT-153, "DTC P1772 LOW COAST BRAKE SOLENOID VALVE"](#), [AT-156, "DTC P1774 LOW COAST BRAKE SOLENOID VALVE FUNCTION"](#).

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#).

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-123, "DTC Confirmation Procedure"](#).

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 5.

DTC P1730 A/T INTERLOCK

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
- NG >> Repair or replace damaged parts.

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
- NG >> Repair or replace damaged parts.

6. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-123, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 2.

DTC P1731 A/T 1ST ENGINE BRAKING

DTC P1731 A/T 1ST ENGINE BRAKING

PFP:00000

Description

ACS0030Y

Fail-safe function to prevent sudden decrease in speed by engine brake other than at M1 position.

CONSULT-II Reference Value

ACS0030Z

Item name	Condition	Display value (ON-OFF display)
ON OFF SOL	Low coast brake operates. Refer to AT-17 .	ON
	Other conditions	OFF
ATF PRES SW 2	Low coast brake operates. Refer to AT-17 .	ON
	Other conditions	OFF

On Board Diagnosis Logic

ACS003P0

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code “A/T 1ST E/BRAKING” with CONSULT-II or 13th judgement flicker without CONSULT-II is detected under the following conditions.
 - When TCM does not receive the proper voltage signal from the sensor.
 - When TCM monitors each ATF pressure switch and solenoid monitor value, and detects as irregular when engine brake of 1st gear acts other than at M1 position.

Possible Cause

ACS003P1

- Harness or connectors
(Sensor circuit is open or shorted.)
- Low coast brake solenoid valve
- ATF pressure switch 2

DTC Confirmation Procedure

ACS003P2

NOTE:

If “DTC Confirmation Procedure” has been previously preformed, always turn ignition switch “OFF” and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch “ON”. (Do not start engine.)
2. Select “DATA MONITOR” mode for “A/T” with CONSULT-II.
3. Start engine.
4. Drive vehicle and maintain the following conditions for at least 2 consecutive seconds.
ENGINE SPEED: 1,200 rpm
Selector lever: “M” position
Gear position: 1st gear
5. If DTC is detected, go to [AT-127, "Diagnostic Procedure"](#) .

SELECT SYSTEM
A/T
ENGINE

SAT014K

DTC P1731 A/T 1ST ENGINE BRAKING

Diagnostic Procedure

ACS003P3

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Start the engine.
2. Select "ECU INPUT SIGNALS" or "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Drive vehicle in the "M" position (1st gear), and confirm the ON/OFF actuation of the "ATF PRES SW 2".

Item name	Condition	Display value (ON-OFF display)
ON OFF SOL	Low coast brake operates. Refer to AT-17 .	ON
	Other conditions	OFF
ATF PRES SW 2	Low coast brake operates. Refer to AT-17 .	ON
	Other conditions	OFF

DATA MONITOR							
MONITOR	NO DTC						
ATF PRES SW 1	OFF						
ATF PRES SW 2	OFF						
ATF PRES SW 3	OFF						
ATF PRES SW 5	OFF						
ATF PRES SW 6	OFF						
<table><tr><td>Δ</td><td>▽</td></tr><tr><td colspan="2">RECORD</td></tr><tr><td>MODE</td><td>COPY</td></tr></table>		Δ	▽	RECORD		MODE	COPY
Δ	▽						
RECORD							
MODE	COPY						

PCIA0067E

OK or NG

- OK >> GO TO 6.
NG >> GO TO 2.

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#).

OK or NG

- OK >> GO TO 3.
NG >> GO TO 5.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-126, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
NG >> Repair or replace damaged parts.

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
NG >> Repair or replace damaged parts.

DTC P1731 A/T 1ST ENGINE BRAKING

6. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-126, "DTC Confirmation Procedure"](#).

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 2.

DTC P1752 INPUT CLUTCH SOLENOID VALVE

DTC P1752 INPUT CLUTCH SOLENOID VALVE

PFP:31940

Description

ACS003P4

Input clutch solenoid valve is controlled by the TCM in response to signals sent from the PNP switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

CONSULT-II Reference Value

ACS003P5

Item name	Condition	Display value (Approx)
I/C SOLENOID	Input clutch solenoid valve operates. Refer to AT-17 .	0.6 - 0.8 A
	Other conditions	0 - 0.05 A

On Board Diagnosis Logic

ACS003P6

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "I/C SOLENOID/CIRC" with CONSULT-II or P1752 without CONSULT-II is detected under the following conditions.
 - When TCM detects an improper voltage drop when it tries to operate the solenoid valve.
 - When TCM detects as irregular by comparing target value with monitor value.

Possible Cause

ACS003P7

- Harness or connectors
(Solenoid circuit is open or shorted.)
- Input clutch solenoid valve

DTC Confirmation Procedure

ACS003P8

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine.
4. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.

ACCELE POSI: 1.5/8 - 2.0/8

Selector lever: "D" position

Gear position: 3rd ⇒ 4th Gear (I/C ON/OFF)

Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.

5. If DTC is detected go to "[AT-130, "Diagnostic Procedure"](#) .

WITH GST

Follow the procedure "With CONSULT-II".

SELECT SYSTEM
A/T
ENGINE

SAT014K

DTC P1752 INPUT CLUTCH SOLENOID VALVE

Diagnostic Procedure

ACS003P9

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start the engine.
4. Read out the value of "I/C SOLENOID" while driving.

Item name	Condition	Display value (Approx)
I/C SOLENOID	Input clutch solenoid valve operates. Refer to AT-17 .	0.6 - 0.8 A
	Other conditions	0 - 0.05 A

DATA MONITOR	
MONITOR	NO DTC
TCC SOLENOID	XXXX
LINE PRES SOL	XXXX
I/C SOLENOID	XXXX
FR/B SOLENOID	XXXX
D/C SOLENOID	XXXX
HLR/C SOL	XXXX
▽	
RECORD	
MODE	BACK
LIGHT	COPY

SCIA4793E

With GST

Follow the procedure "With CONSULT-II".

OK or NG

OK >> GO TO 6.

NG >> GO TO 2.

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#).

OK or NG

OK >> GO TO 3.

NG >> GO TO 5.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-129, "DTC Confirmation Procedure"](#).

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).

NG >> Repair or replace damaged parts.

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).

NG >> Repair or replace damaged parts.

6. CHECK DTC

Perform “DTC Confirmation Procedure”.

- Refer to [AT-129, "DTC Confirmation Procedure"](#) .

OK or NG

OK >> **INSPECTION END**
NG >> GO TO 2.

A
B
AT
D
E
F
G
H
I
J
K
L
M

DTC P1754 INPUT CLUTCH SOLENOID VALVE FUNCTION

DTC P1754 INPUT CLUTCH SOLENOID VALVE FUNCTION

PFP:31940

Description

ACS003PA

- Input clutch solenoid valve is controlled by the TCM in response to signals sent from the PNP switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.
- This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

CONSULT-II Reference Value

ACS003PB

Item name	Condition	Display value (Approx)
I/C SOLENOID	Input clutch solenoid valve operates. Refer to AT-17 .	0.6 - 0.8 A
	Other conditions	0 - 0.05 A
ATF PRES SW 3	Input clutch operates. Refer to AT-17 .	ON
	Other conditions	OFF

On Board Diagnosis Logic

ACS003PC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "I/C SOLENOID FNCTN" with CONSULT-II or P1754 without CONSULT-II is detected under the following conditions.
 - When TCM detects that actual gear ratio is irregular, and relation between gear position and condition of pressure switch 3 is irregular during depressing accelerator pedal. (Other than during shift change)
 - When TCM detects that relation between gear position and condition of ATF pressure switch 3 is irregular during releasing accelerator pedal. (Other than during shift change)

Possible Cause

ACS003PD

- Harness or connectors
(Solenoid and switch circuits are open or shorted.)
- Input clutch solenoid valve
- ATF pressure switch 3

DTC Confirmation Procedure

ACS003PE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

- Start engine.
- Accelerate vehicle to maintain the following conditions.
ACCELE POSI: 1.5/8 - 2.0/8
Selector lever: "D" position
Gear position: 3rd ⇒ 4th Gear (I/C ON/OFF)
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
- Perform step "2" again.
- Turn ignition switch "OFF", then perform step "1" to "3" again.
- Check "SELF-DIAG RESULTS" mode for "A/T" with CONSULT-II. If DTC (P1754) is detected, refer to [AT-133, "Diagnostic Procedure"](#) .
If DTC (P1752) is detected, go to [AT-130, "Diagnostic Procedure"](#) .
If DTC (P1843) is detected, go to [AT-167, "Diagnostic Procedure"](#) .

SELECT SYSTEM
A/T
ENGINE

SAT014K

DTC P1754 INPUT CLUTCH SOLENOID VALVE FUNCTION

WITH GST

Follow the procedure "With CONSULT-II".

Diagnostic Procedure

ACS003PF

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start the engine.
4. Drive vehicle in the "D" position (3rd ⇒ 4th gear), and confirm the ON/OFF actuation of the "ATF PRES SW 3" and electrical current value of "I/C SOLENOID".

Item name	Condition	Display value (Approx.)
I/C SOLENOID	Input clutch solenoid valve operates. Refer to AT-17 .	0.6 - 0.8 A
	Other conditions	0 - 0.05 A
ATF PRES SW 3	Input clutch operates. Refer to AT-17 .	ON
	Other conditions	OFF

DATA MONITOR

MONITOR

NO DTC

I/C SOLENOID

XXX A

ATF PRES SW 3

OFF

RECORD

MODE

BACK

LIGHT

COPY

SCIA4795E

With GST

Follow the procedure "With CONSULT-II".

OK or NG

- OK >> GO TO 6.
NG >> GO TO 2.

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#).

OK or NG

- OK >> GO TO 3.
NG >> GO TO 5.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-132, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
NG >> Repair or replace damaged parts.

DTC P1754 INPUT CLUTCH SOLENOID VALVE FUNCTION

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
- NG >> Repair or replace damaged parts.

6. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-132, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 2.

DTC P1757 FRONT BRAKE SOLENOID VALVE

DTC P1757 FRONT BRAKE SOLENOID VALVE

PFP:31940

Description

ACS003PG

Front brake solenoid valve is controlled by the TCM in response to signals sent from the PNP switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

CONSULT-II Reference Value

ACS003PH

Item name	Condition	Display value (Approx)
FR/B SOLENOID	Front brake solenoid valve operates. Refer to AT-17 .	0.6 - 0.8 A
	Other conditions	0 - 0.05 A

On Board Diagnosis Logic

ACS003PI

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "FR/B SOLENOID/CIRC" with CONSULT-II or P1757 without CONSULT-II is detected under the following conditions.
 - When TCM detects an improper voltage drop when it tries to operate the solenoid valve.
 - When TCM detects as irregular by comparing target value with monitor value.

Possible Cause

ACS003PJ

- Harness or connectors
(Solenoid circuit is open or shorted.)
- Front brake solenoid valve

DTC Confirmation Procedure

ACS003PK

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine.
4. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.
ACCELE POSI: 1.5/8 - 2.0/8
Selector lever: "D" position
Gear position: 3rd ⇒ 4th Gear (FR/B ON/OFF)
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
5. If DTC is detected go to [AT-136, "Diagnostic Procedure"](#) .

SELECT SYSTEM
A/T
ENGINE

SAT014K

WITH GST

Follow the procedure "With CONSULT-II".

DTC P1757 FRONT BRAKE SOLENOID VALVE

Diagnostic Procedure

ACS003PL

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start the engine.
4. Read out the value of "FR/B SOLENOID" while driving.

Item name	Condition	Display value (Approx)
FR/B SOLENOID	Front brake solenoid valve operates. Refer to AT-17 .	0.6 - 0.8 A
	Other conditions	0 - 0.05 A

DATA MONITOR	
MONITOR	NO DTC
TCC SOLENOID	XXXX
LINE PRES SOL	XXXX
I/C SOLENOID	XXXX
FR/B SOLENOID	XXXX
D/C SOLENOID	XXXX
HLR/C SOL	XXXX
	▽
	RECORD
MODE	BACK
LIGHT	COPY

SCIA4793E

With GST

Follow the procedure "With CONSULT-II".

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 2.

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#).

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 5.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-135, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
- NG >> Repair or replace damaged parts.

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
- NG >> Repair or replace damaged parts.

DTC P1757 FRONT BRAKE SOLENOID VALVE

6. CHECK DTC

Perform “DTC Confirmation Procedure”.

- Refer to [AT-135, "DTC Confirmation Procedure"](#) .

OK or NG

OK >> **INSPECTION END**
NG >> GO TO 2.

A
B
AT
D
E
F
G
H
I
J
K
L
M

DTC P1759 FRONT BRAKE SOLENOID VALVE FUNCTION

DTC P1759 FRONT BRAKE SOLENOID VALVE FUNCTION

PFP:31940

Description

ACS003PM

- Front brake solenoid valve is controlled by the TCM in response to signals sent from the PNP switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.
- This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

CONSULT-II Reference Value

ACS003PN

Item name	Condition	Display value (Approx)
FR/B SOLENOID	Front brake solenoid valve operates. Refer to AT-17 .	0.6 - 0.8 A
	Other conditions	0 - 0.05 A
ATF PRES SW 1	Front brake operates. Refer to AT-17 .	ON
	Other conditions	OFF

On Board Diagnosis Logic

ACS003PO

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "FR/B SOLENOID FNCT" with CONSULT-II or P1759 without CONSULT-II is detected under the following conditions.
 - When TCM detects that actual gear ratio is irregular, and relation between gear position and condition of ATF pressure switch 1 is irregular during depressing accelerator pedal. (Other than during shift change)
 - When TCM detects that relation between gear position and condition of ATF pressure switch 1 is irregular during releasing accelerator pedal. (Other than during shift change)

Possible Cause

ACS003PP

- Harness or connectors
(Solenoid and switch circuits are open or shorted.)
- Front brake solenoid valve
- ATF pressure switch 1

DTC Confirmation Procedure

ACS003PQ

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Start engine.
2. Accelerate vehicle to maintain the following conditions.
ACCELE POSI: 1.5/8 - 2.0/8
Selector lever: "D" position
Gear position: 3rd ⇒ 4th Gear (FR/B ON/OFF)
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
3. Perform step "2" again.
4. Turn ignition switch "OFF", then perform step "1" to "3" again.
5. Check "SELF-DIAG RESULTS" mode for "A/T" with CONSULT-II. If DTC (P1759) is detected, refer to [AT-139, "Diagnostic Procedure"](#) .
If DTC (P1757) is detected, go to [AT-136, "Diagnostic Procedure"](#) .
If DTC (P1841) is detected, go to [AT-164, "Diagnostic Procedure"](#) .

SELECT SYSTEM
A/T
ENGINE

SAT014K

DTC P1759 FRONT BRAKE SOLENOID VALVE FUNCTION

WITH GST

Follow the procedure "With CONSULT-II".

Diagnostic Procedure

ACS003PR

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start the engine.
4. Drive vehicle in the "D" position (3rd ⇒ 4th gear), and confirm the ON/OFF actuation of the "ATF PRES SW 1" and electrical current value of "FR/B SOLENOID".

DATA MONITOR			
MONITOR		NO DTC	
ATF PRES SW 1		OFF	
FR/B SOLENOID		XXX A	
<div></div>			
		RECORD	
MODE	BACK	LIGHT	COPY

SCIA4796E

Item name	Condition	Display value (Approx.)
FR/B SOLENOID	Front brake solenoid valve operates. Refer to AT-17 .	0.6 - 0.8 A
	Other conditions	0 - 0.05 A
ATF PRES SW 1	Front brake operates. Refer to AT-17 .	ON
	Other conditions	OFF

With GST

Follow the procedure "With CONSULT-II".

OK or NG

- OK >> GO TO 6.
NG >> GO TO 2.

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#).

OK or NG

- OK >> GO TO 3.
NG >> GO TO 5.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-139, "Diagnostic Procedure"](#).

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
NG >> Repair or replace damaged parts.

DTC P1759 FRONT BRAKE SOLENOID VALVE FUNCTION

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
- NG >> Repair or replace damaged parts.

6. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-139, "Diagnostic Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 2.

DTC P1762 DIRECT CLUTCH SOLENOID VALVE

DTC P1762 DIRECT CLUTCH SOLENOID VALVE

PDF:31940

Description

ACS003PS

Direct clutch solenoid valve is controlled by the TCM in response to signals sent from the PNP switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

CONSULT-II Reference Value

ACS003PT

Item name	Condition	Display value (Approx)
D/C SOLENOID	Direct clutch solenoid valve operates. Refer to AT-17 .	0.6 - 0.8 A
	Other conditions	0 - 0.05 A

On Board Diagnosis Logic

ACS003PU

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "D/C SOLENOID/CIRC" with CONSULT-II or P1762 without CONSULT-II is detected under the following conditions.
 - When TCM detects an improper voltage drop when it tries to operate the solenoid valve.
 - When TCM detects as irregular by comparing target value with monitor value.

Possible Cause

ACS003PV

- Harness or connectors
(Solenoid circuit is open or shorted.)
- Direct clutch solenoid valve

DTC Confirmation Procedure

ACS003PW

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine.
4. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.
ACCELE POSI: 1.5/8 - 2.0/8
Selector lever: "D" position
Gear position: 1st ⇒ 2nd Gear (D/C ON/OFF)
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
5. If DTC is detected, go to [AT-142, "Diagnostic Procedure"](#) .

SELECT SYSTEM
A/T
ENGINE

SAT014K

WITH GST

Follow the procedure "With CONSULT-II".

DTC P1762 DIRECT CLUTCH SOLENOID VALVE

ACS003PX

Diagnostic Procedure

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start the engine.
4. Read out the value of "D/C SOLENOID" while driving.

Item name	Condition	Display value (Approx)
D/C SOLENOID	Direct clutch solenoid valve operates. Refer to AT-17 .	0.6 - 0.8 A
	Other conditions	0 - 0.05 A

DATA MONITOR	
MONITOR	NO DTC
TCC SOLENOID	XXXX
LINE PRES SOL	XXXX
I/C SOLENOID	XXXX
FR/B SOLENOID	XXXX
D/C SOLENOID	XXXX
HLR/C SOL	XXXX
▽	
RECORD	
MODE	BACK
LIGHT	COPY

SCIA4793E

With GST

Follow the procedure "With CONSULT-II".

OK or NG

- OK >> GO TO 6.
NG >> GO TO 2.

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#).

OK or NG

- OK >> GO TO 3.
NG >> GO TO 5.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-141, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
NG >> Repair or replace damaged parts.

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
NG >> Repair or replace damaged parts.

6. CHECK DTC

Perform “DTC Confirmation Procedure”.

- Refer to [AT-141, "DTC Confirmation Procedure"](#) .

OK or NG

OK >> **INSPECTION END**
NG >> GO TO 2.

A
B
AT
D
E
F
G
H
I
J
K
L
M

DTC P1764 DIRECT CLUTCH SOLENOID VALVE FUNCTION

DTC P1764 DIRECT CLUTCH SOLENOID VALVE FUNCTION

PFP:31940

Description

ACS003PY

- Direct clutch solenoid valve is controlled by the TCM in response to signals sent from the PNP switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.
- This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

CONSULT-II Reference Value

ACS003PZ

Item name	Condition	Display value (Approx)
D/C SOLENOID	Direct clutch solenoid valve operates. Refer to AT-17 .	0.6 - 0.8 A
	Other conditions	0 - 0.05 A
ATF PRES SW 5	Direct clutch operates. Refer to AT-17 .	ON
	Other conditions	OFF

On Board Diagnosis Logic

ACS003Q0

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code “D/C SOLENOID FNCTN” with CONSULT-II or P1764 without CONSULT-II is detected under the following conditions.
 - When TCM detects that actual gear ratio is irregular, and relation between gear position and condition of ATF pressure switch 5 is irregular during depressing accelerator pedal. (Other than during shift change)
 - When TCM detects that relation between gear position and condition of ATF pressure switch 5 is irregular during releasing accelerator pedal. (Other than during shift change)

Possible Cause

ACS003Q1

- Harness or connectors
(Solenoid and switch circuits are open or shorted.)
- Direct clutch solenoid valve
- ATF pressure switch 5

DTC Confirmation Procedure

ACS003Q2

NOTE:

If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch “OFF” and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Start engine.
2. Accelerate vehicle to maintain the following conditions.
ACCELE POSI: 1.5/8 - 2.0/8
Selector lever: “D” position
Gear position: 1st ⇒ 2nd Gear (D/C ON/OFF)
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
3. Perform step “2” again.
4. Turn ignition switch “OFF”, then perform step “1” to “3” again.
5. Check “SELF-DIAG RESULTS” mode for “A/T” with CONSULT-II. If DTC (P1764) is detected, refer to [AT-145, "Diagnostic Procedure"](#) .
If DTC (P1762) is detected, go to [AT-142, "Diagnostic Procedure"](#) .
If DTC (P1845) is detected, go to [AT-170, "Diagnostic Procedure"](#) .

SELECT SYSTEM
A/T
ENGINE

SAT014K

WITH GST

Follow the procedure “With CONSULT-II”.

DTC P1764 DIRECT CLUTCH SOLENOID VALVE FUNCTION

Diagnostic Procedure

ACS003Q3

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start the engine.
4. Drive vehicle in the "D" position (1st ⇒ 2nd gear), and confirm the display actuation of the "ATF PRES SW 5" and electrical current value of "D/C SOLENOID".

DATA MONITOR			
MONITOR		NO DTC	
D/C SOLENOID		XXXA	
ATF PRES SW 5		OFF	
		RECORD	
MODE	BACK	LIGHT	COPY

SCIA4797E

Item name	Condition	Display value (Approx.)
D/C SOLENOID	Direct clutch solenoid valve operates. Refer to AT-17 .	0.6 - 0.8 A
	Other conditions	0 - 0.05 A
ATF PRES SW 5	Direct clutch operates. Refer to AT-17 .	ON
	Other conditions	OFF

With GST

Follow the procedure "With CONSULT-II".

OK or NG

- OK >> GO TO 6.
NG >> GO TO 2.

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

- OK >> GO TO 3.
NG >> GO TO 5.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-144, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
NG >> Repair or replace damaged parts.

DTC P1764 DIRECT CLUTCH SOLENOID VALVE FUNCTION

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .

NG >> Repair or replace damaged parts.

6. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-144, "DTC Confirmation Procedure"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 2.

DTC P1767 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE

DTC P1767 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE

PFP:31940

Description

ACS003Q4

High and low reverse clutch solenoid valve is controlled by the TCM in response to signals sent from the PNP switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

CONSULT-II Reference Value

ACS003Q5

Item name	Condition	Display value (Approx)
HLR/C SOL	High and low reverse clutch solenoid valve operates. Refer to AT-17 .	0.6 - 0.8 A
	Other conditions	0 - 0.05 A

On Board Diagnosis Logic

ACS003Q6

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "HLR/C SOL/CIRC" with CONSULT-II or P1767 without CONSULT-II is detected under the following conditions.
 - When TCM detects an improper voltage drop when it tries to operate the solenoid valve.
 - When TCM detects as irregular by comparing target value with monitor value.

Possible Cause

ACS003Q7

- Harness or connectors
(Solenoid circuit is open or shorted.)
- High and low reverse clutch solenoid valve

DTC Confirmation Procedure

ACS003Q8

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine.
4. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.
ACCELE POSI: 1.5/8 - 2.0/8
Selector lever: "D" position
Gear position: 2nd ⇒ 3rd Gear (HLR/C ON/OFF)
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
5. If DTC is detected, go to [AT-148, "Diagnostic Procedure"](#) .

SELECT SYSTEM
A/T
ENGINE

SAT014K

WITH GST

Follow the procedure "With CONSULT-II".

DTC P1767 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE

ACS003Q9

Diagnostic Procedure

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start the engine.
4. Read out the value of "HLR/C SOLENOID" while driving.

Item name	Condition	Display value (Approx)
HLR/C SOL	High and low reverse clutch solenoid valve operates. Refer to AT-17 .	0.6 - 0.8 A
	Other conditions	0 - 0.05 A

DATA MONITOR	
MONITOR	NO DTC
TCC SOLENOID	XXXX
LINE PRES SOL	XXXX
I/C SOLENOID	XXXX
FR/B SOLENOID	XXXX
D/C SOLENOID	XXXX
HLR/C SOL	XXXX
▽	
RECORD	
MODE	BACK
LIGHT	COPY

SCIA4793E

With GST

Follow the procedure "With CONSULT-II".

OK or NG

- OK >> GO TO 6.
NG >> GO TO 2.

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#).

OK or NG

- OK >> GO TO 3.
NG >> GO TO 5.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-147, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
NG >> Repair or replace damaged parts.

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
NG >> Repair or replace damaged parts.

DTC P1767 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE

6. CHECK DTC

Perform “DTC Confirmation Procedure”.

- Refer to [AT-147, "DTC Confirmation Procedure"](#) .

OK or NG

OK >> **INSPECTION END**
NG >> GO TO 2.

A

B

AT

D

E

F

G

H

I

J

K

L

M

DTC P1769 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE FUNCTION

DTC P1769 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE FUNCTION

PFP:31940

Description

ACS003QA

- High and low reverse clutch solenoid valve is controlled by the TCM in response to signals sent from the PNP switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.
- This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

CONSULT-II Reference Value

ACS003QB

Item name	Condition	Display value (Approx)
HLR/C SOL	High and low reverse clutch solenoid valve operates. Refer to AT-17 .	0.6 - 0.8 A
	Other conditions	0 - 0.05 A
ATF PRES SW 6	High and low reverse clutch operates. Refer to AT-17 .	ON
	Other conditions	OFF

On Board Diagnosis Logic

ACS003QC

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "HLR/C SOL FNCTN" with CONSULT-II or P1769 without CONSULT-II is detected under the following conditions.
 - When TCM detects that actual gear ratio is irregular, and relation between gear position and condition of ATF pressure switch 6 is irregular during depressing accelerator pedal. (Other than during shift change)
 - When TCM detects that relation between gear position and condition of ATF pressure switch 6 is irregular during releasing accelerator pedal. (Other than during shift change)

Possible Cause

ACS003QD

- Harness or connectors
(Solenoid and switch circuits are open or shorted.)
- High and low reverse clutch solenoid valve
- ATF pressure switch 6

DTC Confirmation Procedure

ACS003QE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

⑧ WITH CONSULT-II

- Start engine.
- Accelerate vehicle to maintain the following conditions.
ACCELE POSI: 1.5/8 - 2.0/8
Selector lever: "D" position
Gear position: 2nd ⇒ 3rd Gear (HLR/C ON/OFF)
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
- Perform step "2" again.
- Turn ignition switch "OFF", then perform step "1" to "3" again.
- Check "SELF-DIAG RESULTS" mode for "A/T" with CONSULT-II. If DTC (P1769) is detected, refer to [AT-151, "Diagnostic Procedure"](#) .
If DTC (P1767) is detected, go to [AT-148, "Diagnostic Procedure"](#) .
If DTC (P1846) is detected, go to [AT-173, "Diagnostic Procedure"](#) .

SELECT SYSTEM
A/T
ENGINE

SAT014K

DTC P1769 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE FUNCTION



WITH GST

Follow the procedure "With CONSULT-II".

Diagnostic Procedure

ACS003QF

1. CHECK INPUT SIGNALS



With CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start the engine.
4. Drive vehicle in the "D" position (2nd ⇒ 3rd gear), and confirm the ON/OFF actuation of the "ATF PRES SW 6" and electrical current value of "HLR/C SOL".

Item name	Condition	Display value (Approx.)
HLR/C SOL	High and low reverse clutch solenoid valve operates. Refer to AT-17 .	0.6 - 0.8 A
	Other conditions	0 - 0.05 A
ATF PRES SW 6	High and low reverse clutch operates. Refer to AT-17 .	ON
	Other conditions	OFF

DATA MONITOR

MONITOR	NO DTC
HLR/C SOL	XXX A
ATF PRES SW 6	OFF

RECORD	
MODE	BACK
LIGHT	COPY

SCIA4798E



With GST

Follow the procedure "With CONSULT-II".

OK or NG

- OK >> GO TO 6.
NG >> GO TO 2.

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

- OK >> GO TO 3.
NG >> GO TO 5.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-150, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
NG >> Repair or replace damaged parts.

DTC P1769 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE FUNCTION

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .

NG >> Repair or replace damaged parts.

6. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-150, "DTC Confirmation Procedure"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 2.

DTC P1772 LOW COAST BRAKE SOLENOID VALVE

DTC P1772 LOW COAST BRAKE SOLENOID VALVE

PFP:31940

Description

ACS003QG

Low coast brake solenoid valve is turned "ON" or "OFF" by the TCM in response to signals sent from the PNP switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

CONSULT-II Reference Value

ACS003QH

Item name	Condition	Display value (ON-OFF display)
ON OFF SOL	Low coast brake solenoid valve operates. Refer to AT-17 .	ON
	Other conditions	OFF

On Board Diagnosis Logic

ACS003QI

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "LC/B SOLENOID/CIRC" with CONSULT-II or P1772 without CONSULT-II is detected when TCM detects an improper voltage drop when it tries to operate the solenoid valve.

Possible Cause

ACS003QJ

- Harness or connectors
(Solenoid circuit is open or shorted.)
- Low coast brake solenoid valve

DTC Confirmation Procedure

ACS003QK

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
3. Start engine.
4. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.
Selector lever: "M" position
Gear position: "M1-1st" or "M2-2nd" gear (LC/B ON/OFF)
5. If DTC is detected, go to [AT-154, "Diagnostic Procedure"](#) .

SELECT SYSTEM
A/T
ENGINE

SAT014K

WITH GST

Follow the procedure "With CONSULT-II".

DTC P1772 LOW COAST BRAKE SOLENOID VALVE

Diagnostic Procedure

ACS003QL

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start the engine.
4. Read out the value of "ON OFF SOL" while driving.

Item name	Condition	Display value (ON-OFF display)
ON OFF SOL	Low coast brake solenoid valve operates. Refer to AT-17 .	ON
	Other conditions	OFF

DATA MONITOR			
MONITOR		NO DTC	
ON OFF SOL		OFF	
ATF PRES SW 2		OFF	
		RECORD	
MODE	BACK	LIGHT	COPY

SCIA4794E

With GST

Follow the procedure "With CONSULT-II".

OK or NG

OK >> GO TO 6.

NG >> GO TO 2.

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

OK >> GO TO 3.

NG >> GO TO 5.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-153, "DTC Confirmation Procedure"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .

NG >> Repair or replace damaged parts.

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .

NG >> Repair or replace damaged parts.

DTC P1772 LOW COAST BRAKE SOLENOID VALVE

6. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-153, "DTC Confirmation Procedure"](#) .

OK or NG

OK >> **INSPECTION END**
NG >> GO TO 2.

A

B

AT

D

E

F

G

H

I

J

K

L

M

DTC P1774 LOW COAST BRAKE SOLENOID VALVE FUNCTION

DTC P1774 LOW COAST BRAKE SOLENOID VALVE FUNCTION

PFP:31940

Description

ACS003QM

- Low coast brake solenoid valve is turned "ON" or "OFF" by the TCM in response to signals sent from the PNP switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.
- This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

CONSULT-II Reference Value

ACS003QN

Item name	Condition	Display value (ON-OFF display)
ON OFF SOL	Low coast brake solenoid valve operates. Refer to AT-17 .	ON
	Other conditions	OFF
ATF PRES SW 2	Low coast brake operates. Refer to AT-17 .	ON
	Other conditions	OFF

On Board Diagnosis Logic

ACS003QQ

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "LC/B SOLENOID FNCT" with CONSULT-II or P1774 without CONSULT-II is detected under the following conditions.
 - When TCM detects that actual gear ratio is irregular, and relation between gear position and condition of ATF pressure switch 2 is irregular during depressing accelerator pedal. (Other than during shift change)
 - When TCM detects that relation between gear position and condition of ATF pressure switch 2 is irregular during releasing accelerator pedal. (Other than during shift change)

Possible Cause

ACS003QP

- Harness or connectors
(Solenoid and switch circuits are open or shorted.)
- Low coast brake solenoid valve
- ATF pressure switch 2

DTC Confirmation Procedure

ACS003QQ

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

- Start engine.
- Accelerate vehicle to maintain the following conditions.
Selector lever: "M" position
Gear position: "M1-1st" or "M2-2nd" gear (LC/B ON/OFF)
- Perform step "2" again.
- Turn ignition switch "OFF", then perform step "1" to "3" again.
- Check "SELF-DIAG RESULTS" mode for "A/T" with CONSULT-II. If DTC (P1774) is detected, refer to [AT-157, "Diagnostic Procedure"](#) .
If DTC (P1772) is detected, go to [AT-154, "Diagnostic Procedure"](#) .

SELECT SYSTEM
A/T
ENGINE

SAT014K

WITH GST

Follow the procedure "With CONSULT-II".

DTC P1774 LOW COAST BRAKE SOLENOID VALVE FUNCTION

Diagnostic Procedure

ACS003QR

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "SELECTION FORM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start the engine.
4. Drive vehicle in the manual mode ("M1-1st" or "M2-2nd" gear), and confirm the ON/OFF actuation of the "ATF PRES SW 2" and "ON OFF SOL".

DATA MONITOR			
MONITOR		NO DTC	
ON OFF SOL		OFF	
ATF PRES SW 2		OFF	
		RECORD	
MODE	BACK	LIGHT	COPY

SCIA4794E

Item name	Condition	Display value (ON-OFF display)
ON OFF SOL	Low coast brake solenoid valve operates. Refer to AT-17 .	ON
	Other conditions	OFF
ATF PRES SW 2	Low coast brake operates. Refer to AT-17 .	ON
	Other conditions	OFF

With GST

Follow the procedure "With CONSULT-II".

OK or NG

- OK >> GO TO 6.
NG >> GO TO 2.

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

- OK >> GO TO 3.
NG >> GO TO 5.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-156, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
NG >> Repair or replace damaged parts.

DTC P1774 LOW COAST BRAKE SOLENOID VALVE FUNCTION

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
- NG >> Repair or replace damaged parts.

6. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-156, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 2.

DTC P1815 MANUAL MODE SWITCH

DTC P1815 MANUAL MODE SWITCH

PFP:34901

Description

ACS004YC

Manual mode switch is installed in A/T device. It sends manual mode switch, shift up and shift down switch signals to TCM.

TCM sends the switch signals to unified meter and A/C amp. By CAN communication line. Then manual mode switch position is indicated on the A/T indicator. For inspection, refer to [AT-161, "Position Indicator"](#).

CONSULT-II Reference Value in Data Monitor Mode

ACS003QT

Item name	Condition	Display Value (ON-OFF display)
MANU MODE SW	Manual shift gate position (neutral)	ON
	Other than the above	OFF
NON M-MODE SW	Manual shift gate position	OFF
	Other than the above	ON
UP SW LEVER	Selector lever: + side	ON
	Other than the above	OFF
DOWN SW LEVER	Selector lever: - side	ON
	Other than the above	OFF

On Board Diagnosis Logic

ACS003QU

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "MANU MODE SW/CIR" with CONSULT-II is detected when TCM monitors Manual mode, Non manual mode, Up or Down switch signal, and detects as irregular when impossible input pattern occurs 1 second or more.

Possible Cause

ACS003QV

- Harness or connectors
(These switches circuit is open or shorted.)
- Mode select switch (Into control device)
- Position select switch (Into control device)

DTC Confirmation Procedure

ACS003QW

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

⑧ WITH CONSULT-II

1. Turn ignition switch "ON". (Do not start engine.)
2. Select "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine.
4. Move selector lever to "M" position.
5. Drive vehicle for at least 2 consecutive seconds.
6. If DTC is detected, go to [AT-160, "Diagnostic Procedure"](#).

SELECT SYSTEM
A/T
ENGINE

SAT014K

DTC P1815 MANUAL MODE SWITCH

ACS003QX

Diagnostic Procedure

1. CHECK CAN COMMUNICATION LINE

Perform the self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-86, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Is a malfunction in the CAN communication indicated in the results?

- YES >> Check CAN communication line. Refer to [AT-88, "DTC U1000 CAN COMMUNICATION LINE"](#) .
NO >> GO TO 2.

2. CHECK MANUAL MODE SWITCH CIRCUIT

With CONSULT-II

- Turn ignition switch ON. (Do not start engine.)
- Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "TRANSMISSION" with CONSULT-II.
- Read out ON/OFF switching action of the "MMODE", "NON M-MODE", "UPLVR", "DOWNLVR".

Item name	Condition	Display Value (ON-OFF display)
MANU MODE SW	Manual shift gate position (neutral)	ON
	Other than the above	OFF
NON M-MODE SW	Manual shift gate position	OFF
	Other than the above	ON
UP SW LEVER	Selector lever: + side	ON
	Other than the above	OFF
DOWN SW LEVER	Selector lever: - side	ON
	Other than the above	OFF

DATA MONITOR			
MONITOR		NO DTC	
DOWNLVR		OFF	
UPLVR		OFF	
NON M-MODE		ON	
MMODE		OFF	
△			
		REDORD	
MODE	BACK	LIGHT	COPY

SCIA4588E

Without CONSULT-II

Drive vehicle in the manual mode, and confirm that the actual gear position and the meter's indication of the position mutually coincide when the selector lever is shifted to the "+ (up)" or "- (down)" side (1st ⇔ 5th gear).

OK or NG

- OK >> GO TO 6.
NG >> GO TO 3.

3. DETECT MALFUNCTIONING ITEM

Check the following items.

- Manual mode switch. Refer to [AT-161, "Component Inspection"](#) .
- Pin terminals for damage or loose connection with harness connector.
- Open circuit or short to ground or short to power in harness or connector for A/T device (manual mode switch).
- Unified meter and A/C amp.

OK or NG

- OK >> GO TO 4.
NG >> Repair or replace damaged parts.

4. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

- OK >> GO TO 6.
NG >> GO TO 5.

DTC P1815 MANUAL MODE SWITCH

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
- NG >> Repair or replace damaged parts.

6. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-159, "DTC Confirmation Procedure"](#) .

OK or NG


- OK >> **INSPECTION END**
- NG >> GO TO 4.

Component Inspection MANUAL MODE SWITCH

ACS003QY

Check continuity between terminals.

Item	Position	Connector	Terminal (Unit side)	Continuity
Manual mode (select) switch	Auto	M47	9 - 10	Yes
	Manual		6 - 9	
UP switch	UP		8 - 9	
DOWN switch	DOWN		7 - 9	



ACS003QZ

Position Indicator DIAGNOSTIC PROCEDURE

1. CHECK INPUT SIGNALS

⑧ With CONSULT-II

1. Start engine.
2. Select "MAIN SIGNALS" in "DATA MONITOR" mode for A/T with CONSULT-II and read out the value of "GEAR".
3. Drive vehicle in the manual mode, and confirm that the actual gear position and the meter's indication of the position mutually coincide when the selector lever is shifted to the "+ (up)" or "- (down)" side (1st ⇔ 5th gear).

OK or NG

- OK >> **INSPECTION END**
- NG >> Check the following items.

DATA MONITOR	
MONITOR	NO DTC
VHCL/S SE-A/T	0 km/h
THROTTLE POSI	0. 0/8
GEAR	1
ENGINE SPEED	0 rpm
TURBINE REV	0 rpm
▽	
RECORD	
MODE	BACK
LIGHT	COPY

PCIA0065E

Position indicator lamp symptom chart

Items	Presumed Location of Trouble
The actual gear position does not change, or shifting into the manual mode is not possible (no gear shifting in the manual mode possible). The position indicator is not indicated.	Manual mode switch Refer to AT-159, "DTC P1815 MANUAL MODE SWITCH" . A/T main system (Fail-safe function actuated) <ul style="list-style-type: none">• Refer to AT-77, "SELF-DIAGNOSTIC RESULT MODE" .
The actual gear position changes, but the position indicator is not indicated.	Perform the self-diagnosis function. <ul style="list-style-type: none">• Refer to AT-77, "SELF-DIAGNOSTIC RESULT MODE" .

DTC P1815 MANUAL MODE SWITCH

Items	Presumed Location of Trouble
The actual gear position and the indication on the position indicator do not coincide.	Perform the self-diagnosis function. <ul style="list-style-type: none">● Refer to AT-77, "SELF-DIAGNOSTIC RESULT MODE" .
Only a specific position or positions is/are not indicated on the position indicator.	Check the unified meter and A/C amp. Refer to DI-4, "COMBINATION METERS" .

DTC P1841 ATF PRESSURE SWITCH 1

DTC P1841 ATF PRESSURE SWITCH 1

PFP:25240

Description

ACS003R0

Fail-safe function to detect front brake clutch solenoid valve condition.

CONSULT-II Reference Value

ACS003R1

Item name	Condition	Display value (ON-OFF display)
ATF PRES SW 1	Front brake operates. Refer to AT-17 .	ON
	Other conditions	OFF

On Board Diagnosis Logic

ACS003R2

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code “ATF PRES SW 1/CIRC” with CONSULT-II is detected when TCM detects that actual gear ratio is normal, and relation between gear position and condition of ATF pressure switch 1 is irregular during depressing accelerator pedal. (Other than during shift change)

Possible Cause

ACS003R3

- ATF pressure switch 1
- Harness or connectors
(Switch circuit is open or shorted.)

DTC Confirmation Procedure

ACS003R4

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch “OFF” and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

⑧ WITH CONSULT-II

1. Start engine.
2. Accelerate vehicle to maintain the following conditions.
ACCELE POSI: 1.5/8 - 2.0/8
Selector lever: “D” position
Gear position: 3rd ⇒ 4th Gear (FR/B ON/OFF)
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
3. Perform step “2” again.
4. Turn ignition switch “OFF”, then perform step “1” to “3” again.
5. Check “SELF-DIAG RESULTS” mode for “A/T” with CONSULT-II.
If DTC (P1841) is detected, go to [AT-164. "Diagnostic Procedure"](#) .
If DTC (P1757) is detected, go to [AT-136. "Diagnostic Procedure"](#) .

SELECT SYSTEM
A/T
ENGINE

SAT014K

DTC P1841 ATF PRESSURE SWITCH 1

ACS003R5

Diagnostic Procedure

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Start engine.
2. Select "ECU INPUT SIGNALS" or "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Drive vehicle in the "D" position (3rd ⇒ 4th gear), and confirm the ON/OFF actuation of the "ATF PRES SW 1".

Item name	Condition	Display value (ON-OFF display)
ATF PRES SW 1	Front brake operates. Refer to AT-17 .	ON
	Other conditions	OFF

DATA MONITOR	
MONITOR	NO. DTC
ATF PRES SW 1	OFF
ATF PRES SW 2	OFF
ATF PRES SW 3	OFF
ATF PRES SW 5	OFF
ATF PRES SW 6	OFF
<div><div>Δ</div><div>▽</div></div>	
RECORD	
MODE	BACK
LIGHT	COPY

PCIA0067E

OK or NG

- OK >> GO TO 6.
NG >> GO TO 2.

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

- OK >> GO TO 3.
NG >> GO TO 5.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-163, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
NG >> Repair or replace damaged parts.

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
NG >> Repair or replace damaged parts.

DTC P1841 ATF PRESSURE SWITCH 1

6. CHECK DTC

Perform “DTC Confirmation Procedure”.

- Refer to [AT-163, "DTC Confirmation Procedure"](#) .

OK or NG

OK >> **INSPECTION END**
NG >> GO TO 2.

A
B
AT
D
E
F
G
H
I
J
K
L
M

DTC P1843 ATF PRESSURE SWITCH 3

DTC P1843 ATF PRESSURE SWITCH 3

PFP:25240

Description

ACS003R6

Fail-safe function to detect input clutch solenoid valve condition.

CONSULT-II Reference Value

ACS003R7

Item name	Condition	Display value (ON-OFF display)
ATF PRES SW 3	Input clutch operates. Refer to AT-17 .	ON
	Other conditions	OFF

On Board Diagnosis Logic

ACS003R8

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code “ATF PRES SW 3/CIRC” with CONSULT-II is detected when TCM detects that actual gear ratio is normal, and relation between gear position and condition of ATF pressure switch 3 is irregular during depressing accelerator pedal. (Other than during shift change)

Possible Cause

ACS003R9

- ATF pressure switch 3
- Harness or connectors
(Switch circuit is open or shorted.)

DTC Confirmation Procedure

ACS003RA

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch “OFF” and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

④ WITH CONSULT-II

1. Start engine.
2. Accelerate vehicle to maintain the following conditions.
ACCELE POSI: 1.5/8 - 2.0/8
Selector lever: “D” position
Gear position: 3rd ⇒ 4th Gear (I/C ON/OFF)
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
3. Perform step “2” again.
4. Turn ignition switch “OFF”, then perform step “1” to “3” again.
5. Check “SELF-DIAG RESULTS” mode for “A/T” with CONSULT-II.
If DTC (P1843) is detected, go to [AT-167, "Diagnostic Procedure"](#) .
If DTC (P1752) is detected, go to [AT-130, "Diagnostic Procedure"](#) .

SELECT SYSTEM
A/T
ENGINE

SAT014K

DTC P1843 ATF PRESSURE SWITCH 3

Diagnostic Procedure

ACS003RB

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Start engine.
2. Select "ECU INPUT SIGNALS" or "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Drive vehicle in the "D" position (3rd ⇒ 4th gear), and confirm the ON/OFF actuation of the "ATF PRES SW 3".

Item name	Condition	Display value (ON-OFF display)
ATF PRES SW 3	Input clutch operates. Refer to AT-17 .	ON
	Other conditions	OFF

DATA MONITOR									
MONITOR	NO DTC								
ATF PRES SW 1	OFF								
ATF PRES SW 2	OFF								
ATF PRES SW 3	OFF								
ATF PRES SW 5	OFF								
ATF PRES SW 6	OFF								
<table><tr><td>Δ</td><td>▽</td></tr><tr><td colspan="2">RECORD</td></tr><tr><td>MODE</td><td>BACK</td></tr><tr><td>LIGHT</td><td>COPY</td></tr></table>		Δ	▽	RECORD		MODE	BACK	LIGHT	COPY
Δ	▽								
RECORD									
MODE	BACK								
LIGHT	COPY								

PCIA0067E

OK or NG

- OK >> GO TO 6.
NG >> GO TO 2.

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#).

OK or NG

- OK >> GO TO 3.
NG >> GO TO 5.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-166, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
NG >> Repair or replace damaged parts.

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
NG >> Repair or replace damaged parts.

DTC P1843 ATF PRESSURE SWITCH 3

6. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-166, "DTC Confirmation Procedure"](#).

OK or NG

OK	>> INSPECTION END
NG	>> GO TO 2.

DTC P1845 ATF PRESSURE SWITCH 5

DTC P1845 ATF PRESSURE SWITCH 5

PFP:25240

Description

ACS003RC

Fail-safe function to detect direct clutch solenoid valve condition.

CONSULT-II Reference Value

ACS003RD

Item name	Condition	Display value (ON-OFF display)
ATF PRES SW 5	Direct clutch operates. Refer to AT-17 .	ON
	Other conditions	OFF

On Board Diagnosis Logic

ACS003RE

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code “ATF PRES SW 5/CIRC” with CONSULT-II is detected when TCM detects that actual gear ratio is normal, and relation between gear position and condition of ATF pressure switch 5 is irregular during depressing accelerator pedal. (Other than during shift change)

Possible Cause

ACS003RF

- ATF pressure switch 5
- Harness or connectors
(Switch circuit is open or shorted.)

DTC Confirmation Procedure

ACS003RG

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch “OFF” and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

⑧ WITH CONSULT-II

1. Start engine.
2. Accelerate vehicle to maintain the following conditions.
ACCELE POSI: 1.5/8 - 2.0/8
Selector lever: “D” position
Gear position: 1st ⇒ 2nd Gear (D/C ON/OFF)
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
3. Perform step “2” again.
4. Turn ignition switch “OFF”, then perform step “1” to “3” again.
5. Check “SELF-DIAG RESULTS” mode for “A/T” with CONSULT-II.

If DTC (P1845) is detected, go to [AT-170. "Diagnostic Procedure"](#) .

If DTC (P1762) is detected, go to [AT-142. "Diagnostic Procedure"](#) .

SELECT SYSTEM
A/T
ENGINE

SAT014K

DTC P1845 ATF PRESSURE SWITCH 5

ACS003RH

Diagnostic Procedure

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Start engine.
2. Select "ECU INPUT SIGNALS" or "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Drive vehicle in the "D" position (1st ⇒ 2nd gear), and confirm the ON/OFF actuation of the "ATF PRES SW 5".

Item name	Condition	Display value (ON-OFF display)
ATF PRES SW 5	Direct clutch operates. Refer to AT-17 .	ON
	Other conditions	OFF

DATA MONITOR	
MONITOR	NO. DTC
ATF PRES SW 1	OFF
ATF PRES SW 2	OFF
ATF PRES SW 3	OFF
ATF PRES SW 5	OFF
ATF PRES SW 6	OFF
<div><div>Δ</div><div>▽</div></div>	
RECORD	
MODE	BACK
LIGHT	COPY

PCIA0067E

OK or NG

- OK >> GO TO 6.
NG >> GO TO 2.

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

- OK >> GO TO 3.
NG >> GO TO 5.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-169, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
NG >> Repair or replace damaged parts.

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
NG >> Repair or replace damaged parts.

6. CHECK DTC

Perform “DTC Confirmation Procedure”.

- Refer to [AT-169, "DTC Confirmation Procedure"](#) .

OK or NG

OK >> **INSPECTION END**
NG >> GO TO 2.

A

B

AT

D

E

F

G

H

I

J

K

L

M

DTC P1846 ATF PRESSURE SWITCH 6

DTC P1846 ATF PRESSURE SWITCH 6

PFP:25240

Description

ACS003RJ

Fail-safe function to detect high and low reverse clutch solenoid valve condition.

CONSULT-II Reference Value

ACS003RJ

Item name	Condition	Display value (ON-OFF display)
ATF PRES SW 6	High and low reverse clutch operates. Refer to AT-17 .	ON
	Other conditions	OFF

On Board Diagnosis Logic

ACS003RK

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code “ATF PRES SW 6/CIRC” with CONSULT-II is detected when TCM detects that actual gear ratio is normal, and relation between gear position and condition of ATF pressure switch 6 is irregular during depressing accelerator pedal. (Other than during shift change)

Possible Cause

ACS003RL

- ATF pressure switch 6
- Harness or connectors
(Switch circuit is open or shorted.)

DTC Confirmation Procedure

ACS003RM

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch “OFF” and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

⑧ WITH CONSULT-II

1. Start engine.
2. Accelerate vehicle to maintain the following conditions.
ACCELE POSI: 1.5/8 - 2.0/8
Selector lever: “D” position
Gear position: 2nd ⇒ 3rd Gear (HLR/C ON/OFF)
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
3. Perform step “2” again.
4. Turn ignition switch “OFF”, then perform step “1” to “3” again.
5. Check “SELF-DIAG RESULTS” mode for “A/T” with CONSULT-II.
If DTC (P1846) is detected, go to [AT-173, "Diagnostic Procedure"](#) .
If DTC (P1767) is detected, go to [AT-148, "Diagnostic Procedure"](#) .

SELECT SYSTEM
A/T
ENGINE

SAT014K

DTC P1846 ATF PRESSURE SWITCH 6

Diagnostic Procedure

ACS003RN

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Start the engine.
2. Select "ECU INPUT SIGNALS" or "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Drive vehicle in the "D" position (2nd ⇒ 3rd gear), and confirm the ON/OFF actuation of the "ATF PRES SW 6".

DATA MONITOR	
MONITOR	NO DTC
ATF PRES SW 1	OFF
ATF PRES SW 2	OFF
ATF PRES SW 3	OFF
ATF PRES SW 5	OFF
ATF PRES SW 6	OFF

Δ	▽
RECORD	
MODE	BACK
LIGHT	COPY

PCIA0067E

Item name	Condition	Display value (ON-OFF display)
ATF PRES SW 6	High and low reverse clutch operates. Refer to AT-17 .	ON
	Other conditions	OFF

OK or NG

- OK >> GO TO 6.
NG >> GO TO 2.

2. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#).

OK or NG

- OK >> GO TO 3.
NG >> GO TO 2.

3. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-172, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
NG >> Repair or replace damaged parts.

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#).
NG >> Repair or replace damaged parts.

DTC P1846 ATF PRESSURE SWITCH 6

6. CHECK DTC

Perform "DTC Confirmation Procedure".

- Refer to [AT-172, "DTC Confirmation Procedure"](#).

OK or NG

OK	>> INSPECTION END
NG	>> GO TO 2.

CLOSED THROTTLE POSITION AND WIDE OPEN THROTTLE POSITION CIRCUIT

CLOSED THROTTLE POSITION AND WIDE OPEN THROTTLE POSITION CIRCUIT

PFP:18002

CONSULT-II Reference Value

ACS006C2

Item name	Condition	Display value (ON-OFF display)
CLSD THL POS	Released accelerator pedal.	ON
	Fully depressed accelerator pedal.	OFF
W/O THL POS	Fully depressed accelerator pedal.	ON
	Released accelerator pedal.	OFF

Diagnostic Procedure

ACS003R0

1. CHECK CAN COMMUNICATION LINE

Perform the self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-86, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Is a malfunction in the CAN communication indicated in the results?

- YES >> Check CAN communication line. Refer to [AT-88, "DTC U1000 CAN COMMUNICATION LINE"](#) .
NO >> GO TO 2.

2. CHECK THROTTLE POSITION SIGNAL CIRCUIT

With CONSULT-II

- Turn ignition switch "ON". (Do not start engine.)
- Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
- Depress accelerator pedal and read out the value of "CLSD THL POS" and "W/O THL POS".

Accelerator Pedal Operation	Monitor Item	
	CLSD THL POS	W/O THL POS
Released	ON	OFF
Fully depressed	OFF	ON

DATA MONITOR			
MONITOR		NO DTC	
ACCELE POSI	0.0/8		
THROTTLE POSI	0.0/8		
CLSD THL POS	ON		
W/O THL POS	OFF		
BRAKE SW	OFF		
		▼	
		RECORD	
MODE	BACK	LIGHT	COPY

PCIA0070E

OK or NG

OK >> **INSPECTION END**

NG >> Check the following items. If NG, repair or replace damaged parts.

- Perform the self-diagnosis for "ENGINE" with CONSULT-II. Refer to [EC-104, "CONSULT-II Function"](#) .
- Open circuit or short to ground or short to power in harness or connectors.
- Pin terminals for damage or loose connection with harness connector.

BRAKE SIGNAL CIRCUIT

BRAKE SIGNAL CIRCUIT

PFP:25320

CONSULT-II Reference Value

ACS006C3

Item name	Condition	Display value (ON-OFF display)
BRAKE SW	Depressed brake pedal.	ON
	Released brake pedal.	OFF

Diagnostic Procedure

ACS003RP

1. CHECK CAN COMMUNICATION LINE

Perform the self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-86, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Is a malfunction in the CAN communication indicated in the results?

- YES >> Check CAN communication line. Refer to [AT-88, "DTC U1000 CAN COMMUNICATION LINE"](#) .
NO >> GO TO 2.

2. CHECK STOP LAMP SWITCH CIRCUIT

With CONSULT-II

- Turn ignition switch "ON". (Do not start engine.)
- Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
- Read out ON/OFF switching action of the "BRAKE SW".

Item name	Condition	Display value (ON-OFF display)
BRAKE SW	Depressed brake pedal.	ON
	Released brake pedal.	OFF

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 3.

DATA MONITOR	
MONITOR	NO DTC
ACCELE POSI	0.0/8
THROTTLE POSI	0.0/8
CLSD THL POS	ON
W/O THL POS	OFF
BRAKE SW	OFF
▽	
RECORD	
MODE	BACK
LIGHT	COPY

PCIA0070E

3. CHECK STOP LAMP SWITCH


Check continuity between stop lamp switch harness connector E111 terminals 1 (R/Y) and 2 (P/L).

Condition	Continuity
When brake pedal is depressed	Yes
When brake pedal is released	No

Check stop lamp switch after adjusting brake pedal — refer to [BR-6, "BRAKE PEDAL"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> Check the following items. If NG, repair or replace damaged parts.
- Harness for short or open between battery and stop lamp switch.
 - Harness for short or open between stop lamp switch and unified meter and A/C amp.



TROUBLE DIAGNOSIS FOR SYMPTOMS

TROUBLE DIAGNOSIS FOR SYMPTOMS

PFP:00007

A/T CHECK Indicator Lamp Does Not Come On SYMPTOM:

ACS003S9

A/T CHECK indicator lamp does not come on for about 2 seconds when turning ignition switch to "ON".

DIAGNOSTIC PROCEDURE

1. CHECK CAN COMMUNICATION LINE

Perform the self-diagnosis. [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-86, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .


Is a malfunction in the CAN communication indicated in the results?

- YES >> Check CAN communication line. Refer to [AT-88, "DTC U1000 CAN COMMUNICATION LINE"](#) .
NO >> GO TO 2.

2. CHECK TCM POWER SOURCE


1. Disconnect A/T assembly harness connector.
2. Turn ignition switch "ON". (Do not start engine.)
3. Check voltage between A/T assembly harness connector and ground. Refer to [AT-49, "Wiring Diagram — AT —"](#) .

Item	Connector	Terminal (Wire color)	Voltage
TCM	F6	1 (R/W) - Ground	Battery voltage
		2 (R/W) - Ground	
		6 (Y/R) - Ground	



4. Turn ignition switch "OFF".
5. Check voltage between A/T assembly harness connector and ground. Refer to [AT-49, "Wiring Diagram — AT —"](#) .

Item	Connector	Terminal (Wire color)	Voltage
TCM	F6	1 (R/W) - Ground	Battery voltage
		2 (R/W) - Ground	
		6 (Y/R) - Ground	0V



OK or NG

- OK >> GO TO 4.
NG >> GO TO 3.

TROUBLE DIAGNOSIS FOR SYMPTOMS

3. DETECT MALFUNCTIONING ITEM

Check the following items:

- Harness for short or open between battery and A/T assembly harness connector terminals 1, 2
- Harness for short or open between ignition switch and A/T assembly harness connector terminal 6
- 10A fuse (No. 32, located in the fuse and fusible link box)
- 10A fuse (No. 83, located in the IPDM E/R)
- Ignition switch, Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) .

OK or NG

OK >> GO TO 4.

NG >> Repair or replace damaged parts.

4. CHECK TCM GROUND CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect A/T assembly harness connector.
3. Check the continuity between A/T assembly harness connector 5 (B), 10 (B) and ground. Refer to [AT-49, "Wiring Diagram — AT —"](#) .


Continuity should exist.

4. If OK, check the harness for short-circuit to ground or the power source.

OK or NG

OK >> GO TO 5.

NG >> Repair the open or short circuit in the harness or connector.



5. CHECK A/T CHECK INDICATOR LAMP CIRCUIT

1. Turn ignition switch "OFF".
2. Check the combination meter.
Refer to [DI-4, "COMBINATION METERS"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> Replace the combination meter. Refer to [DI-29, "Removal and Installation for Combination Meter"](#)

Engine Cannot Be Started In "P" or "N" Position

SYMPTOM:

- Engine cannot be started with selector lever in "P" or "N" position.
- Engine can be started with selector lever in "D" or "R" position.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-86, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Do the self-diagnosis results indicate PNP switch?

YES >> Check the malfunctioning system. Refer to [AT-94, "DTC P0705 PARK/NEUTRAL POSITION SWITCH"](#) .

NO >> GO TO 2.

ACS003SA

TROUBLE DIAGNOSIS FOR SYMPTOMS

2. CHECK CONTROL LINKAGE

Check the control linkage.

- Refer to [AT-201, "Checking of A/T Position"](#) .

OK or NG

OK >> GO TO 3.

NG >> Adjust control linkage. Refer to [AT-201, "Adjustment of A/T Position"](#) .

3. CHECK STARTING SYSTEM

Check the starting system. Refer to [SC-10, "STARTING SYSTEM"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> Repair or replace damaged parts.

In "P" Position, Vehicle Moves When Pushed SYMPTOM:

ACS003SB

Even though the selector lever is set in the "P" position, the parking mechanism is not actuated, allowing the vehicle to be moved when it is pushed.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-86, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Do the self-diagnosis results indicate PNP switch?

YES >> Check the malfunctioning system. Refer to [AT-94, "DTC P0705 PARK/NEUTRAL POSITION SWITCH"](#) .

NO >> GO TO 2.

2. CHECK CONTROL LINKAGE

Check the control linkage.

- Refer to [AT-201, "Checking of A/T Position"](#) .

OK or NG

OK >> GO TO 3.

NG >> Adjust control linkage. Refer to [AT-201, "Adjustment of A/T Position"](#) .

3. CHECK SYMPTOM

Check again. Refer to [AT-59, "Check at Idle"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .

TROUBLE DIAGNOSIS FOR SYMPTOMS

ACS003SC

In “N” Position, Vehicle Moves

SYMPTOM:

Vehicle moves forward or backward when selecting “N” position.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-86, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Do the self-diagnosis results indicate PNP switch?

- YES >> Check the malfunctioning system. Refer to [AT-94, "DTC P0705 PARK/NEUTRAL POSITION SWITCH"](#) .
- NO >> GO TO 2.

2. CHECK CONTROL LINKAGE

Check the control linkage.

- Refer to [AT-201, "Checking of A/T Position"](#) .

OK or NG

- OK >> GO TO 3.
- NG >> Adjust control linkage. Refer to [AT-201, "Adjustment of A/T Position"](#) .

3. CHECK A/T FLUID LEVEL

Check the A/T fluid level. Refer to [AT-10, "Checking A/T Fluid"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Refill ATF.

4. CHECK SYMPTOM

Check again. Refer to [AT-59, "Check at Idle"](#) .

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 5.

5. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 6.

6. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
- NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

Large Shock ("N" to "D" Position)

ACS003SD

SYMPTOM:

A noticeable shock occurs when the selector lever is shifted from the "N" to "D" position.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#).

Do the self-diagnosis results indicate A/T fluid temperature sensor, engine speed signal, accelerator pedal position sensor, ATF pressure switch 1, front brake solenoid valve, CAN communication line?

YES >> Check the malfunctioning system. Refer to [AT-115, "DTC P1710 A/T FLUID TEMPERATURE SENSOR CIRCUIT"](#), [AT-100, "DTC P0725 ENGINE SPEED SIGNAL"](#), [EC-588, "DTC P2122, P2123 APP SENSOR"](#), [EC-596, "DTC P2127, P2128 APP SENSOR"](#), [EC-612, "DTC P2138 APP SENSOR"](#), [AT-163, "DTC P1841 ATF PRESSURE SWITCH 1"](#), [AT-135, "DTC P1757 FRONT BRAKE SOLENOID VALVE"](#), [AT-88, "DTC U1000 CAN COMMUNICATION LINE"](#).

NO >> GO TO 2.

2. ENGINE IDLE SPEED

Check the engine idle speed. Refer to [EC-30, "Idle Speed and Ignition Timing Check"](#).

OK or NG

OK >> GO TO 3.

NG >> Repair or replace damaged parts.

3. CHECK CONTROL LINKAGE

Check the control linkage.

- Refer to [AT-201, "Checking of A/T Position"](#).

OK or NG

OK >> GO TO 4.

NG >> Adjust control linkage. Refer to [AT-201, "Adjustment of A/T Position"](#).

4. CHECK A/T FLUID LEVEL

Check the A/T fluid level. Refer to [AT-10, "Checking A/T Fluid"](#).

OK or NG

OK >> GO TO 5.

NG >> Refill ATF.

5. CHECK SYMPTOM

Check again. Refer to [AT-59, "Check at Idle"](#).

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 6.

6. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#).

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 7.

TROUBLE DIAGNOSIS FOR SYMPTOMS

7. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
- NG >> Repair or replace damaged parts.

Vehicle Does Not Creep Backward In “R” Position

ACS003SE

SYMPTOM:

The vehicle does not creep in the “R” position. Or an extreme lack of acceleration is observed.

DIAGNOSTIC PROCEDURE

1. CHECK A/T FLUID LEVEL

Check the A/T fluid level. Refer to [AT-10, "Checking A/T Fluid"](#) .

OK or NG

- OK >> GO TO 2.
- NG >> Refill ATF.

2. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) .

Do the self-diagnosis results indicate accelerator pedal position sensor, ATF pressure switch 6, high and low reverse clutch solenoid valve, CAN communication line, PNP switch?

- YES >> Check the malfunctioning system. Refer to [EC-588, "DTC P2122, P2123 APP SENSOR"](#) , [EC-596, "DTC P2127, P2128 APP SENSOR"](#) , [EC-612, "DTC P2138 APP SENSOR"](#) , [AT-172, "DTC P1846 ATF PRESSURE SWITCH 6"](#) , [AT-147, "DTC P1767 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE"](#) , [AT-88, "DTC U1000 CAN COMMUNICATION LINE"](#) , [AT-94, "DTC P0705 PARK/NEUTRAL POSITION SWITCH"](#) .

- NO >> GO TO 3.

3. CHECK LINE PRESSURE

Check the line pressure with the engine idling. Refer to [AT-57, "LINE PRESSURE TEST"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Check the line pressure system. Refer to [AT-58, "Judgement of line pressure test"](#) .

4. CHECK CONTROL LINKAGE

Check the control linkage.

- Refer to [AT-201, "Checking of A/T Position"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> Adjust control linkage. Refer to [AT-201, "Adjustment of A/T Position"](#) .

5. CHECK SYMPTOM

Check again. Refer to [AT-59, "Check at Idle"](#) .

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 6.

TROUBLE DIAGNOSIS FOR SYMPTOMS

6. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
- NG >> Repair or replace damaged parts.

Vehicle Does Not Creep Forward In “D” Position SYMPTOM:

ACS003SF

Vehicle does not creep forward when selecting “D” position.

DIAGNOSTIC PROCEDURE

1. CHECK A/T FLUID LEVEL

Check the A/T fluid level. Refer to [AT-10, "Checking A/T Fluid"](#) .

OK or NG

- OK >> GO TO 2.
- NG >> Refill ATF.

2. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-86, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Do the self-diagnosis results indicate accelerator pedal position sensor, CAN communication line, PNP switch?

- YES >> Check the malfunctioning system. Refer to [EC-588, "DTC P2122, P2123 APP SENSOR"](#) , [EC-596, "DTC P2127, P2128 APP SENSOR"](#) , [EC-612, "DTC P2138 APP SENSOR"](#) , [AT-88, "DTC U1000 CAN COMMUNICATION LINE"](#) , [AT-94, "DTC P0705 PARK/NEUTRAL POSITION SWITCH"](#) .
- NO >> GO TO 3.

3. CHECK LINE PRESSURE

Check the line pressure at idle with selector lever in “R” position. Refer to [AT-57, "LINE PRESSURE TEST"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Check the line pressure solenoid valve. Refer to [AT-108, "DTC P0745 LINE PRESSURE SOLENOID VALVE"](#) .

4. CHECK CONTROL LINKAGE

Check the control linkage.

- Refer to [AT-201, "Checking of A/T Position"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> Adjust control linkage. Refer to [AT-201, "Adjustment of A/T Position"](#) .

TROUBLE DIAGNOSIS FOR SYMPTOMS

5. CHECK SYMPTOM

Check again. Refer to [AT-59, "Check at Idle"](#) .

OK or NG

OK >> **INSPECTION END**
NG >> GO TO 6.

6. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

OK >> **INSPECTION END**
NG >> GO TO 7.

7. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
NG >> Repair or replace damaged parts.

Vehicle Cannot Be Started From D1 SYMPTOM:

ACS003SG

The vehicle cannot be started from D1 .

DIAGNOSTIC PROCEDURE

1. CONFIRM THE SYMPTOM

Check if vehicle creeps in "R" position.

OK or NG

OK >> GO TO 2.
NG >> Refer to [AT-182, "Vehicle Does Not Creep Backward In "R" Position"](#) .

2. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-86, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Is any malfunction detected by self-diagnosis results?

YES >> Check the malfunctioning system.
NO >> GO TO 3.

3. CHECK LINE PRESSURE

Check the line pressure at the engine stall point. Refer to [AT-57, "LINE PRESSURE TEST"](#) .

OK or NG

OK >> GO TO 4.
NG >> Check the line pressure system. Refer to [AT-58, "Judgement of line pressure test"](#) .

4. CHECK SYMPTOM

Check again. Refer to [AT-59, "Check at Idle"](#) .

OK or NG

OK >> **INSPECTION END**
NG >> GO TO 5.

TROUBLE DIAGNOSIS FOR SYMPTOMS

5. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 6.

6. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
- NG >> Repair or replace damaged parts.

A/T Does Not Shift: D1 → D2

ACS003SH

SYMPTOM:

The vehicle does not shift-up from the D1 to D2 gear at the specified speed.

DIAGNOSTIC PROCEDURE

1. CONFIRM THE SYMPTOM

Check if vehicle creeps forward in "D" position and vehicle can be started from D1. Refer to [AT-61, "Cruise Test - Part 1"](#) .

OK or NG

- OK >> GO TO 2.
- NG >> Refer to [AT-183, "Vehicle Does Not Creep Forward In "D" Position"](#) , [AT-184, "Vehicle Cannot Be Started From D1"](#) .

2. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) .

Do the self-diagnosis results indicate ATF pressure switch 5, direct clutch solenoid valve, accelerator pedal position sensor, vehicle speed sensor A/T (revolution sensor) and vehicle speed sensor MTR?

- YES >> Check the malfunctioning system. Refer to [AT-169, "DTC P1845 ATF PRESSURE SWITCH 5"](#) , [AT-141, "DTC P1762 DIRECT CLUTCH SOLENOID VALVE"](#) , [EC-588, "DTC P2122, P2123 APP SENSOR"](#) , [EC-596, "DTC P2127, P2128 APP SENSOR"](#) , [EC-612, "DTC P2138 APP SENSOR"](#) , [AT-97, "DTC P0720 VEHICLE SPEED SENSOR A/T \(REVOLUTION SENSOR\)"](#) , [AT-121, "DTC P1721 VEHICLE SPEED SENSOR MTR"](#) .
- NO >> GO TO 3.

3. CHECK A/T FLUID LEVEL

Check the A/T fluid level. Refer to [AT-10, "Checking A/T Fluid"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Refill ATF.

4. CHECK LINE PRESSURE

Check the line pressure at the engine stall point. Refer to [AT-57, "LINE PRESSURE TEST"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> Check the line pressure system. Refer to [AT-58, "Judgement of line pressure test"](#) .

TROUBLE DIAGNOSIS FOR SYMPTOMS

5. CHECK SYMPTOM

Check again. Refer to [AT-61, "Cruise Test - Part 1"](#) , [AT-63, "Cruise Test - Part 2"](#) .

OK or NG

OK >> **INSPECTION END**
NG >> GO TO 6.

6. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

OK >> **INSPECTION END**
NG >> GO TO 7.

7. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
NG >> Repair or replace damaged parts.

A/T Does Not Shift: D2 → D3

ACS003SI

SYMPTOM:

The vehicle does not shift-up from D2 to D3 gear at the specified speed.

DIAGNOSTIC PROCEDURE

1. CONFIRM THE SYMPTOM

Check if vehicle creeps forward in "D" position" and vehicle can be started from D1. Refer to [AT-61, "Cruise Test - Part 1"](#) .

OK or NG

OK >> GO TO 2.
NG >> Refer to [AT-183, "Vehicle Does Not Creep Forward In "D" Position"](#) , [AT-184, "Vehicle Cannot Be Started From D1"](#) .

2. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) .

Do the self-diagnosis results indicate ATF pressure switch 6, high and low reverse clutch solenoid valve, accelerator pedal position sensor, vehicle speed sensor A/T (revolution sensor) and vehicle speed sensor MTR?

YES >> Check the malfunctioning system. Refer to [AT-172, "DTC P1846 ATF PRESSURE SWITCH 6"](#) , [AT-147, "DTC P1767 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE"](#) , [EC-588, "DTC P2122, P2123 APP SENSOR"](#) , [EC-596, "DTC P2127, P2128 APP SENSOR"](#) , [EC-612, "DTC P2138 APP SENSOR"](#) , [AT-97, "DTC P0720 VEHICLE SPEED SENSOR A/T \(REVOLUTION SENSOR\)"](#) , [AT-121, "DTC P1721 VEHICLE SPEED SENSOR MTR"](#) .

NO >> GO TO 3.

3. CHECK A/T FLUID LEVEL

Check the A/T fluid level. Refer to [AT-10, "Checking A/T Fluid"](#) .

OK or NG

OK >> GO TO 4.
NG >> Refill ATF.

TROUBLE DIAGNOSIS FOR SYMPTOMS

4. CHECK LINE PRESSURE

Check the line pressure at the engine stall point. Refer to [AT-57, "LINE PRESSURE TEST"](#) .

OK or NG

OK >> GO TO 5.

NG >> Check the line pressure system. Refer to [AT-58, "Judgement of line pressure test"](#) .

5. CHECK SYMPTOM

Check again. Refer to [AT-61, "Cruise Test - Part 1"](#) , [AT-63, "Cruise Test - Part 2"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 6.

6. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 7.

7. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .

NG >> Repair or replace damaged parts.

A/T Does Not Shift: D3 → D4

ACS003SJ

SYMPTOM:

- The vehicle does not shift-up from the D3 to D4 gear at the specified speed.
- The vehicle does not shift-up from the D3 to D4 gear unless A/T is warmed up.

DIAGNOSTIC PROCEDURE

1. CONFIRM THE SYMPTOM

Check if vehicle creeps forward in "D" position and vehicle can be started from D1. Refer to [AT-61, "Cruise Test - Part 1"](#) .

OK or NG

OK >> GO TO 2.

NG >> Refer to [AT-183, "Vehicle Does Not Creep Forward In "D" Position"](#) , [AT-184, "Vehicle Cannot Be Started From D1"](#) .

2. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) .

Do the self-diagnosis results indicate ATF pressure switch 1, ATF pressure switch 3, front brake solenoid valve, input clutch solenoid valve, accelerator pedal position sensor, vehicle speed sensor A/T (revolution sensor) and vehicle speed sensor MTR?

YES >> Check the malfunctioning system. Refer to [AT-163, "DTC P1841 ATF PRESSURE SWITCH 1"](#) , [AT-166, "DTC P1843 ATF PRESSURE SWITCH 3"](#) , [AT-135, "DTC P1757 FRONT BRAKE SOLENOID VALVE"](#) , [AT-129, "DTC P1752 INPUT CLUTCH SOLENOID VALVE"](#) , [EC-588, "DTC P2122, P2123 APP SENSOR"](#) , [EC-596, "DTC P2127, P2128 APP SENSOR"](#) , [EC-612, "DTC](#)

TROUBLE DIAGNOSIS FOR SYMPTOMS

[P2138 APP SENSOR](#) , [AT-97, "DTC P0720 VEHICLE SPEED SENSOR A/T \(REVOLUTION SENSOR\)"](#) , [AT-121, "DTC P1721 VEHICLE SPEED SENSOR MTR"](#) .

NO >> GO TO 3.

3. CHECK A/T FLUID LEVEL

Check the A/T fluid level. Refer to [AT-10, "Checking A/T Fluid"](#) .

OK or NG

OK >> GO TO 4.

NG >> Refill ATF.

4. CHECK LINE PRESSURE

Check the line pressure at the engine stall point. Refer to [AT-57, "LINE PRESSURE TEST"](#) .

OK or NG

OK >> GO TO 5.

NG >> Check the line pressure system. Refer to [AT-58, "Judgement of line pressure test"](#) .

5. CHECK SYMPTOM

Check again. Refer to [AT-61, "Cruise Test - Part 1"](#) , [AT-63, "Cruise Test - Part 2"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 6.

6. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 7.

7. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .

NG >> Repair or replace damaged parts.

A/T Does Not Shift: D4 → D5

SYMPTOM:

- The vehicle does not shift-up from the D4 to D5 gear at the specified speed.
- The vehicle does not shift-up from the D4 to D5 gear unless A/T is warmed up.

DIAGNOSTIC PROCEDURE

1. CONFIRM THE SYMPTOM

Check if vehicle creeps forward in "D" position and vehicle can be started from D1. Refer to [AT-61, "Cruise Test - Part 1"](#) .

OK or NG

OK >> GO TO 2.

NG >> Refer to [AT-183, "Vehicle Does Not Creep Forward In "D" Position"](#) , [AT-184, "Vehicle Cannot Be Started From D1"](#) .

ACS003SK

TROUBLE DIAGNOSIS FOR SYMPTOMS

2. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) .

Do the self-diagnosis results indicate ATF pressure switch 1, ATF pressure switch 5, front brake solenoid valve, direct clutch solenoid valve, accelerator pedal position sensor, turbine revolution sensor, vehicle speed sensor A/T (revolution sensor) and vehicle speed sensor MTR?

YES >> Check the malfunctioning system. Refer to [AT-163, "DTC P1841 ATF PRESSURE SWITCH 1"](#) , [AT-169, "DTC P1845 ATF PRESSURE SWITCH 5"](#) , [AT-135, "DTC P1757 FRONT BRAKE SOLENOID VALVE"](#) , [AT-141, "DTC P1762 DIRECT CLUTCH SOLENOID VALVE"](#) , [EC-588, "DTC P2122, P2123 APP SENSOR"](#) , [EC-596, "DTC P2127, P2128 APP SENSOR"](#) , [EC-612, "DTC P2138 APP SENSOR"](#) , [AT-118, "DTC P1716 TURBINE REVOLUTION SENSOR"](#) , [AT-97, "DTC P0720 VEHICLE SPEED SENSOR A/T \(REVOLUTION SENSOR\)"](#) , [AT-121, "DTC P1721 VEHICLE SPEED SENSOR MTR"](#) .

NO >> GO TO 3.

3. CHECK A/T FLUID LEVEL

Check the A/T fluid level. Refer to [AT-10, "Checking A/T Fluid"](#) .

OK or NG

OK >> GO TO 4.

NG >> Refill ATF.

4. CHECK LINE PRESSURE

Check the line pressure at the engine stall point. Refer to [AT-57, "LINE PRESSURE TEST"](#) .

OK or NG

OK >> GO TO 5.

NG >> Check the line pressure system. Refer to [AT-58, "Judgement of line pressure test"](#) .

5. CHECK SYMPTOM

Check again. Refer to [AT-61, "Cruise Test - Part 1"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 6.

6. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 7.

7. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .

NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

ACS003SL

A/T Does Not Perform Lock-up

SYMPTOM:

A/T does not perform lock-up at the specified speed.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-86, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Do the self-diagnosis results indicate torque converter clutch solenoid valve, engine speed signal, turbine revolution sensor, accelerator pedal position sensor, CAN communication?

YES >> Check the malfunctioning system. Refer to [AT-102, "DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE"](#) , [AT-100, "DTC P0725 ENGINE SPEED SIGNAL"](#) , [AT-118, "DTC P1716 TURBINE REVOLUTION SENSOR"](#) , [EC-588, "DTC P2122, P2123 APP SENSOR"](#) , [EC-596, "DTC P2127, P2128 APP SENSOR"](#) , [EC-612, "DTC P2138 APP SENSOR"](#) , [AT-88, "DTC U1000 CAN COMMUNICATION LINE"](#) .

NO >> GO TO 2.

2. CHECK A/T FLUID LEVEL

Check the A/T fluid level. Refer to [AT-10, "Checking A/T Fluid"](#) .

OK or NG

OK >> GO TO 3.

NG >> Refill ATF.

3. CHECK LINE PRESSURE

Check the line pressure at the engine stall point. Refer to [AT-57, "LINE PRESSURE TEST"](#) .

OK or NG

OK >> GO TO 4.

NG >> Check the line pressure system. Refer to [AT-58, "Judgement of line pressure test"](#) .

4. CHECK SYMPTOM

Check again. Refer to [AT-61, "Cruise Test - Part 1"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 5.

5. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 6.

6. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .

NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

A/T Does Not Hold Lock-up Condition

ACS003SM

SYMPTOM:

The lock-up condition cannot be maintained for more than 30 seconds.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-86, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Do the self-diagnosis results indicate torque converter clutch solenoid valve, engine speed signal, turbine revolution sensor, CAN communication?

YES >> Check the malfunctioning system. Refer to [AT-102, "DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE"](#) , [AT-100, "DTC P0725 ENGINE SPEED SIGNAL"](#) , [AT-118, "DTC P1716 TURBINE REVOLUTION SENSOR"](#) , [AT-88, "DTC U1000 CAN COMMUNICATION LINE"](#)

NO >> GO TO 2.

2. CHECK SYMPTOM

Check again. Refer to [AT-61, "Cruise Test - Part 1"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 3.

3. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .

NG >> Repair or replace damaged parts.

Lock-up Is Not Released

ACS003SN

SYMPTOM:

The lock-up condition cannot be cancelled.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-86, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Do the self-diagnosis results indicate torque converter clutch solenoid valve, engine speed signal, turbine revolution sensor, CAN communication?

YES >> Check the malfunctioning system. Refer to [AT-102, "DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE"](#) , [AT-100, "DTC P0725 ENGINE SPEED SIGNAL"](#) , [AT-118, "DTC P1716 TURBINE REVOLUTION SENSOR"](#) , [AT-88, "DTC U1000 CAN COMMUNICATION LINE"](#)

NO >> GO TO 2.

TROUBLE DIAGNOSIS FOR SYMPTOMS

2. CHECK SYMPTOM

Check again. Refer to [AT-61, "Cruise Test - Part 1"](#) .

OK or NG

OK >> **INSPECTION END**
NG >> GO TO 3.

3. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

OK >> **INSPECTION END**
NG >> GO TO 4.

4. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
NG >> Repair or replace damaged parts.

Engine Speed Does Not Return To Idle

SYMPTOM:

ACS003SO

When a shift-down is performed, the engine speed does not smoothly return to the idling speed.

DIAGNOSTIC PROCEDURE

1. CHECK A/T FLUID LEVEL

Check the A/T fluid level. Refer to [AT-10, "Checking A/T Fluid"](#) .

OK or NG

OK >> GO TO 2.
NG >> Refill ATF.

2. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) .

Do the self-diagnosis results indicate front brake solenoid valve, direct clutch solenoid valve, ATF pressure switch 1, ATF pressure switch 5, accelerator pedal position sensor, vehicle speed sensor A/T (revolution sensor) and vehicle speed sensor MTR?

YES >> Check the malfunctioning system. Refer to [AT-135, "DTC P1757 FRONT BRAKE SOLENOID VALVE"](#) , [AT-141, "DTC P1762 DIRECT CLUTCH SOLENOID VALVE"](#) , [AT-163, "DTC P1841 ATF PRESSURE SWITCH 1"](#) , [AT-169, "DTC P1845 ATF PRESSURE SWITCH 5"](#) , [EC-588, "DTC P2122, P2123 APP SENSOR"](#) , [EC-596, "DTC P2127, P2128 APP SENSOR"](#) , [EC-612, "DTC P2138 APP SENSOR"](#) , [AT-97, "DTC P0720 VEHICLE SPEED SENSOR A/T \(REVOLUTION SENSOR\)"](#) , [AT-121, "DTC P1721 VEHICLE SPEED SENSOR MTR"](#) .

NO >> GO TO 3.

3. CHECK SYMPTOM

Check again. Refer to [AT-61, "Cruise Test - Part 1"](#) .

OK or NG

OK >> **INSPECTION END**
NG >> GO TO 4.

TROUBLE DIAGNOSIS FOR SYMPTOMS

4. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .
OK or NG

OK >> **INSPECTION END**
NG >> GO TO 5.

5. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
NG >> Repair or replace damaged parts.

Cannot Be changed to Manual Mode SYMPTOM:

ACS003SP

Does not change to manual mode when manual shift gate is used.

DIAGNOSTIC PROCEDURE

1. MANUAL MODE SWITCH

Check the manual mode switch. Refer to [AT-159, "DTC P1815 MANUAL MODE SWITCH"](#) .

OK or NG

OK >> GO TO 2.
NG >> Repair or replace damaged parts.

2. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) .

Do the self-diagnosis results indicate turbine revolution sensor?

YES >> Check the malfunctioning system. Refer to [AT-118, "DTC P1716 TURBINE REVOLUTION SENSOR"](#) .
NO >> **INSPECTION END**

A/T Does Not Shift: 5th gear → 4th gear SYMPTOM:

ACS003SQ

When shifted from M5 to M4 position in manual mode, does not downshift from 5th to 4th gears.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) .

Do the self-diagnosis results indicate PNP switch, ATF pressure switch 1?

YES >> Check the malfunctioning system. Refer to [AT-94, "DTC P0705 PARK/NEUTRAL POSITION SWITCH"](#) , [AT-163, "DTC P1841 ATF PRESSURE SWITCH 1"](#) .
NO >> GO TO 2.

2. CHECK A/T FLUID LEVEL

Check the A/T fluid level. Refer to [AT-10, "Checking A/T Fluid"](#) .

OK or NG

OK >> GO TO 3.
NG >> Refill ATF.

TROUBLE DIAGNOSIS FOR SYMPTOMS

3. CHECK CONTROL LINKAGE

Check the control linkage.

- Refer to [AT-201, "Checking of A/T Position"](#) .

OK or NG

OK >> GO TO 4.

NG >> Adjust control linkage. Refer to [AT-201, "Adjustment of A/T Position"](#) .

4. MANUAL MODE SWITCH

Check the manual mode switch. Refer to [AT-159, "DTC P1815 MANUAL MODE SWITCH"](#) .

OK or NG

OK >> GO TO 5.

NG >> Repair or replace damaged parts.

5. CHECK SYMPTOM

Check again. Refer to [AT-64, "Cruise Test - Part 3"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 6.

6. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 7.

7. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .

NG >> Repair or replace damaged parts.

A/T Does Not Shift: 4th gear → 3rd gear

SYMPTOM:

When shifted from M4 to M3 position in manual mode, does not downshift from 4th to 3rd gears.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) .

Do the self-diagnosis results indicate PNP switch, ATF pressure switch 1, ATF pressure switch 3?

YES >> Check the malfunctioning system. Refer to [AT-94, "DTC P0705 PARK/NEUTRAL POSITION SWITCH"](#) , [AT-163, "DTC P1841 ATF PRESSURE SWITCH 1"](#) , [AT-166, "DTC P1843 ATF PRESSURE SWITCH 3"](#) .

NO >> GO TO 2.

ACS003SR

TROUBLE DIAGNOSIS FOR SYMPTOMS

2. CHECK A/T FLUID LEVEL

Check the A/T fluid level. Refer to [AT-10, "Checking A/T Fluid"](#) .

OK or NG

- OK >> GO TO 3.
- NG >> Refill ATF.

3. CHECK CONTROL LINKAGE

Check the control linkage.

- Refer to [AT-201, "Checking of A/T Position"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Adjust control linkage. Refer to [AT-201, "Adjustment of A/T Position"](#) .

4. MANUAL MODE SWITCH

Check the manual mode switch. Refer to [AT-159, "DTC P1815 MANUAL MODE SWITCH"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace damaged parts.

5. CHECK SYMPTOM

Check again. Refer to [AT-64, "Cruise Test - Part 3"](#) .

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 6.

6. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
- NG >> Repair or replace damaged parts.

A/T Does Not Shift: 3rd gear → 2nd gear

SYMPTOM:

When shifted from M3 to M2 position in manual mode, does not downshift from 3rd to 2nd gears.

ACS003SS

TROUBLE DIAGNOSIS FOR SYMPTOMS

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) .

Do the self-diagnosis results indicate PNP switch, ATF pressure switch 6?

- YES >> Check the malfunctioning system. Refer to [AT-94, "DTC P0705 PARK/NEUTRAL POSITION SWITCH"](#) , [AT-172, "DTC P1846 ATF PRESSURE SWITCH 6"](#) .
- NO >> GO TO 2.

2. CHECK A/T FLUID LEVEL

Check the A/T fluid level. Refer to [AT-10, "Checking A/T Fluid"](#) .

OK or NG

- OK >> GO TO 3.
- NG >> Refill ATF.

3. CHECK CONTROL LINKAGE

Check the control linkage.

- Refer to [AT-201, "Checking of A/T Position"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Adjust control linkage. Refer to [AT-201, "Adjustment of A/T Position"](#) .

4. MANUAL MODE SWITCH

Check the manual mode switch. Refer to [AT-159, "DTC P1815 MANUAL MODE SWITCH"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace damaged parts.

5. CHECK SYMPTOM

Check again. Refer to [AT-64, "Cruise Test - Part 3"](#) .

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 6.

6. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
- NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

ACS003ST

A/T Does Not Shift: 2nd gear → 1st gear

SYMPTOM:

When shifted from M2 to M1 position in manual mode, does not downshift from 2nd to 1st gears.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) .

Do the self-diagnosis results indicate PNP switch, ATF pressure switch 5?

YES >> Check the malfunctioning system. Refer to [AT-94, "DTC P0705 PARK/NEUTRAL POSITION SWITCH"](#) , [AT-169, "DTC P1845 ATF PRESSURE SWITCH 5"](#) .

NO >> GO TO 2.

2. CHECK A/T FLUID LEVEL

Check the A/T fluid level. Refer to [AT-10, "Checking A/T Fluid"](#) .

OK or NG

OK >> GO TO 3.

NG >> Refill ATF.

3. CHECK CONTROL LINKAGE

Check the control linkage.

- Refer to [AT-201, "Checking of A/T Position"](#) .

OK or NG

OK >> GO TO 4.

NG >> Adjust control linkage. Refer to [AT-201, "Adjustment of A/T Position"](#) .

4. MANUAL MODE SWITCH

Check the manual mode switch. Refer to [AT-159, "DTC P1815 MANUAL MODE SWITCH"](#) .

OK or NG

OK >> GO TO 5.

NG >> Repair or replace damaged parts.

5. CHECK SYMPTOM

Check again. Refer to [AT-64, "Cruise Test - Part 3"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 6.

6. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 7.

TROUBLE DIAGNOSIS FOR SYMPTOMS

7. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .

NG >> Repair or replace damaged parts.

Vehicle Does Not Decelerate By Engine Brake

ACS003SU

SYMPTOM:

No engine brake is applied when the gear is shifted from the M2 to M1.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. [AT-77, "SELF-DIAGNOSTIC RESULT MODE"](#) .

Do the self-diagnosis results indicate PNP switch, ATF pressure switch 5?

YES >> Check the malfunctioning system. Refer to [AT-94, "DTC P0705 PARK/NEUTRAL POSITION SWITCH"](#) , [AT-169, "DTC P1845 ATF PRESSURE SWITCH 5"](#) .

NO >> GO TO 2.

2. CHECK A/T FLUID LEVEL

Check the A/T fluid level. Refer to [AT-10, "Checking A/T Fluid"](#) .

OK or NG

OK >> GO TO 3.

NG >> Refill ATF.

3. CHECK CONTROL LINKAGE

Check the control linkage.

- Refer to [AT-201, "Checking of A/T Position"](#) .

OK or NG

OK >> GO TO 4.

NG >> Adjust control linkage. Refer to [AT-201, "Adjustment of A/T Position"](#) .

4. MANUAL MODE SWITCH

Check the manual mode switch. Refer to [AT-159, "DTC P1815 MANUAL MODE SWITCH"](#) .

OK or NG

OK >> GO TO 5.

NG >> Repair or replace damaged parts.

5. CHECK SYMPTOM

Check again. Refer to [AT-64, "Cruise Test - Part 3"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 6.

6. CHECK TCM

Perform TCM input/output signal inspection. Refer to [AT-74, "TCM Input/Output Signal Reference Values"](#) .
OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING ITEM

Check the following items:

- Power supply and ground circuit for TCM.
- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the transmission assembly. Refer to [AT-212, "Removal and Installation"](#) .
- NG >> Repair or replace damaged parts.

A

B

AT

D

E

F

G

H

I

J

K

L

M

SHIFT CONTROL SYSTEM


SHIFT CONTROL SYSTEM

PFP:34901

Control Device Removal and Installation

ACS00006

SEC.349



SCIA3699E

- | | | |
|--|---------------------------------|-----------------------------|
| 1. Selector lever knob | 2. Knob cover | 3. Lock pin |
| 4. Control device assembly | 5. A/T device harness connector | 6. Position indicator plate |
| 7. Shift lock solenoid and park position switch assembly | 8. Snap pin | 9. Conical washer |
| 10. Plain washer | 11. Bracket | 12. Control rod |
| 13. Dust cover | 14. Dust cover plate | 15. Bulb case |
| 16. Position lamp | | |

SHIFT CONTROL SYSTEM

REMOVAL

1. Disconnect lower lever of control device and control rod.
2. Remove knob cover below selector lever downward.
3. Pull lock pin out of selector lever knob.
4. Remove selector lever knob.
5. Remove console finisher (A/T ring) and console finisher.
 - Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .
6. Remove center console.
 - Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .
7. Remove key interlock cable from control device.
 - Refer to [AT-207, "KEY INTERLOCK CABLE"](#) .
8. Disconnect A/T device harness connector.
9. Remove control device assembly.

CAUTION:

Do not impact, or damage propeller shaft tube.

INSTALLATION

Install in reverse order of removal. Be careful of the following:



- After installation is completed, adjust and check A/T position.

Adjustment of A/T Position

1. Loosen nut of control rod.
2. Place PNP switch and selector lever in "P" position.
3. While pressing lower lever toward rear of vehicle (in P position direction), tighten nut to specified torque.




: 26 N·m (2.7 kg·m, 19 ft·lb)



Checking of A/T Position

1. Place selector lever in "P" position, and turn ignition switch ON (engine stop).
2. Check that selector lever can be shifted to other than "P" position when brake pedal is depressed. Also check that selector lever can be shifted from "P" position only when brake pedal is depressed.
3. Move the selector lever and check for excessive effort, sticking, noise or rattle.
4. Confirm the selector lever stops at each position with the feel of engagement when it is moved through all the positions. Check whether or not the actual position the selector lever is in matches the position shown by the shift position indicator and the transmission body.
5. The method of operating the lever to individual positions correctly should be as shown in the figure.
6. When selector button is pressed in "P", "R", or "N" position without applying forward/backward force to selector lever, check button operation for sticking.
7. Confirm the back-up lamps illuminate only when lever is placed in the "R" position. Confirm the back-up lamps does not illuminate when selector lever is pushed against "R" position in the "P" or "N" position.
8. Confirm the engine can only be started with the selector lever in the "P" and "N" positions. (With selector lever in the "P" position, engine can be started even when selector lever is moved forward and backward.)
9. Check that transmission is locked completely in "P" position.



SHIFT CONTROL SYSTEM

10. When selector lever is set to manual shift gate, check that manual mode is displayed on combination meter.
Shift selector lever to “+” and “-” sides, and check that set shift position changes.

A/T SHIFT LOCK SYSTEM

PFP:34950

Description



ACS00009

- The mechanical key interlock mechanism also operates as a shift lock:
With the ignition switch turned to ON, the selector lever cannot be shifted from "P" (parking) to any other position unless the brake pedal is depressed.
With the key removed, the selector lever cannot be shifted from "P" to any other position.
The key cannot be removed unless the selector lever is placed in "P".
- The shift lock and key interlock mechanisms are controlled by the ON-OFF operation of the shift lock solenoid and by the operation of the rotator and slider located inside the key cylinder.


Shift Lock System Electrical Parts Location

ACS0000A

View with center console removed



Reverse side








SCIA1544E

A/T SHIFT LOCK SYSTEM

Wiring Diagram — AT — SHIFT

ACS001LG

AT-SHIFT-01



REFER TO THE FOLLOWING.

(E108) -SUPER MULTIPLE JUNCTION (SMJ)

(E101) -FUSE BLOCK-JUNCTION BOX (J/B)

TCWT0202E

A/T SHIFT LOCK SYSTEM

ACS003RQ

Diagnostic Procedure

SYMPTOM 1:

- Selector lever cannot be moved from "P" position with key in ON position and brake pedal applied.
- Selector lever can be moved from "P" position with key in ON position and brake pedal released.
- Selector lever can be moved from "P" position when key is removed from key cylinder.

SYMPTOM 2:

- Ignition key cannot be removed when selector lever is set to "P" position.
- Ignition key can be removed when selector lever is set to any position except "P".

1. CHECK KEY INTERLOCK CABLE

Check the key interlock cable for damage.

OK or NG

OK >> GO TO 2.

NG >> Replace key interlock cable. Refer to [AT-207, "KEY INTERLOCK CABLE"](#) .

2. CHECK SELECTOR LEVER POSITION

Check the selector lever position for damage. Refer to [AT-201, "Checking of A/T Position"](#) .

OK or NG

OK >> GO TO 3.

NG >> Check selector lever. Refer to [AT-201, "Adjustment of A/T Position"](#) .

3. CHECK SHIFT LOCK SOLENOID AND PARK POSITION SWITCH

1. Connect A/T device harness connector.
2. Turn ignition switch "ON". (Do not start engine.)
3. Selector lever is set in "P" position.
4. Check operation.

Condition	Brake pedal	Operation
When ignition switch is turned to "ON" position and selector lever is set in "P" position.	Depressed	Yes
	Released	No

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 4.

4. CHECK POWER SOURCE


1. Turn ignition switch "ON". (Do not start engine.)
2. Check voltage between A/T device harness connector M47 terminal 1 (Y/B) and ground.

Voltage: Battery voltage

OK or NG

OK >> GO TO 5.


NG >> GO TO 6.



A/T SHIFT LOCK SYSTEM

5. CHECK STOP LAMP SWITCH

Check continuity between stop lamp switch harness connector E111 terminals 3 (B/Y) and 4 (B).



Check stop lamp switch after adjusting brake pedal — refer to [BR-6, "BRAKE PEDAL"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> Repair or replace damaged parts.

6. DETECT MALFUNCTIONING ITEM

Check the following items. If any items are damaged, repair or replace damaged parts.

1. Harness for short or open between ignition switch and A/T device harness connector terminal 1
2. 10A fuse [No.12, located in the fuse block (J/B)]
3. Ignition switch (Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) .)

OK or NG

- OK >> **INSPECTION END**
- NG >> Repair or replace damaged parts.

7. CHECK GROUND CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect stop lamp switch harness connector.
3. Check continuity between stop lamp switch harness connector E111 terminal 4 (B) and ground.


Continuity should exist.

If OK, check harness for short to ground and short to power.

4. Connect stop lamp switch harness connector.

OK or NG

- OK >> GO TO 8.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.



8. DETECT MALFUNCTIONING ITEM

Check the following items. If any items are damaged, repair or replace damaged parts.

- Harness for short or open between A/T device harness connector M47 terminal 2 (P/B) and stop lamp switch harness connector E111 terminal 3 (B/Y).

OK or NG

- OK >> Replace shift lock solenoid or park position switch.
- NG >> Repair or replace damaged parts.

KEY INTERLOCK CABLE


KEY INTERLOCK CABLE

PFP:34908

Components

ACS0000D

SEC.349



SCIA1546E

CAUTION:

- Install key interlock cable in such a way that it will not be damaged by sharp bends, twists or interference with adjacent parts.
- After installing key interlock cable to control device, make sure that casing cap and bracket are firmly secured in their positions. If casing cap be removed with an external load of less than 39.2 N (4.0 kg, 8.8 lb), replace key interlock cable with new one.


KEY INTERLOCK CABLE

Removal and Installation


ACS0000E

REMOVAL

1. Unlock slider by squeezing lock tabs on slider from adjuster holder.
2. Remove casing cap from bracket of control device assembly and remove interlock rod from adjuster holder.



3. Remove lock plate from key cylinder.
4. Remove holder from key cylinder and remove key interlock cable.



KEY INTERLOCK CABLE


INSTALLATION

1. Set holder of key interlock cable to key cylinder and install lock plate.

CAUTION:

Do not reuse the lock plate


2. Clamp key interlock cable and fix to key interlock cable with band.
3. Turn ignition key to lock position.
4. Set selector lever to "P" position.



5. Insert interlock rod into adjuster holder.
6. Install casing cap to bracket.
7. Move slider in order to fix adjuster holder to interlock rod.

CAUTION:

Do not touch any parts except slider. Do not add any force to slider except force toward slider.




ON-VEHICLE SERVICE

PFP:00000

Oil Pan REMOVAL

ACS0064Q

1. Drain ATF through drain plug.
2. Remove oil pan and oil pan gasket.
3. Check foreign materials in oil pan to help determine causes of malfunction. If the ATF is very dark, smells burned, or contains foreign particles, frictional material (clutches, band) may need replacement. A tacky film that will not wipe clean indicates varnish build up. Varnish can cause valves, servo, and clutches to stick and can inhibit pump pressure.
 - If frictional material is detected, perform A/T fluid cooler cleaning. Refer to [AT-11, "A/T Fluid Cooler Cleaning"](#).



INSTALLATION

1. Install oil pan in transmission case according to the following procedures.

- a. Install oil pan gasket in oil pan.


CAUTION:

- Do not reuse oil pan gasket.
- Install it in the direction to align hole positions.

- b. Install oil pan in transmission case.

CAUTION:

- Install it so that drain plug comes to the position as shown in the figure.
- Be careful not to pinch harnesses.



- c. Tighten oil pan mounting bolts to the specified torque in numerical order shown in the figure after temporarily tightening them.

CAUTION:

Do not reuse oil pan mounting bolts.



: 7.9 N·m (0.81 kg-m, 70 in-lb)


2. Install drain plug in oil pan.

CAUTION:

Do not reuse drain plug gasket.



: 34 N·m (3.5 kg-m, 25 ft-lb)



3. Pour ATF into transmission assembly. Refer to [AT-10, "Changing A/T Fluid"](#).

AIR BREATHER HOSE


AIR BREATHER HOSE

PFP:31098

Removal and Installation

ACS0000G

Refer to the figure below for air breather hose removal and installation procedure.



CAUTION:

- When installing an air breather hose, be careful not to be crushed or blocked by folding or bending the hose.
- When inserting a hose to the transmission tube, be sure to insert it fully until its end reaches the tube bend R portion.

TRANSMISSION ASSEMBLY


TRANSMISSION ASSEMBLY

PFP:31020

Removal and Installation

ACS0000H

SEC.112·310



SCIA3948E

REMOVAL

CAUTION:

When removing the A/T assembly from engine, first remove the crankshaft position sensor (POS) from the A/T assembly.

Be careful not to damage sensor edge.

1. Disconnect the negative battery terminal.
2. Remove tower bar with power tool. Refer to [FSU-20, "Removal and Installation"](#).
3. Remove engine under cover with power tool.
4. Remove front cross bar with power tool. Refer to [FSU-19, "Removal and Installation"](#).
5. Remove exhaust front tube with power tool. Refer to [EX-3, "Removal and Installation"](#).
6. Remove three way catalyst. Refer to [EM-23, "Removal and Installation"](#).
7. Remove propeller shaft. Refer to [PR-7, "Removal and Installation"](#).

CAUTION:

Do not impact, or damage propeller shaft tube.

8. Remove control rod. Refer to [AT-200, "SHIFT CONTROL SYSTEM"](#).
9. Disconnect A/T assembly connector.

TRANSMISSION ASSEMBLY

10. Remove crankshaft position sensor (POS) from A/T assembly. Refer to [EM-27, "Removal and Installation"](#).

CAUTION:

- Do not subject it to impact by dropping or hitting it.
- Do not disassemble.
- Do not allow metal filings, etc., to get on the sensor's front edge magnetic area.
- Do not place in an area affected by magnetism.

11. Remove fluid cooler tube and A/T fluid charging pipe.

12. Plug up openings such as the fluid charging pipe hole, etc.

13. Remove air breather hose. Refer to [AT-211, "Removal and Installation"](#).

14. Remove starter motor with power tool. Refer to [SC-19, "Removal and Installation"](#).

15. Remove dust cover from converter housing part.

16. Turn crankshaft, and remove the four tightening bolts for drive plate and torque converter.

CAUTION:

When turning crankshaft, turn it clockwise as viewed from the front of the engine.

17. Support transmission assembly with a transmission jack.

CAUTION:



When setting the transmission jack, be careful not to allow it to collide against the drain plug.

18. Remove engine rear member with power tool.

19. Remove bolts fixing transmission assembly to engine with power tool.

20. Remove transmission assembly from vehicle with a transmission jack.

- Secure torque converter to prevent it from dropping.
- Secure transmission assembly to a transmission jack.




INSPECTION

Installation and inspection of torque converter

- After inserting a torque converter to a transmission, be sure to check dimension A to ensure it is within the reference value limit.

Dimension A : 25.0 mm (0.98 in) or more




TRANSMISSION ASSEMBLY

INSTALLATION

Install the removed parts in the reverse order of the removal, while paying attention to the following work.

- When installing transmission assembly to the engine, attach the fixing bolts in accordance with the following standard.

Bolt No.	1	2	3	4
Number of bolts	1	5	2	2
Bolt length "ℓ"mm (in)	55 (2.17)	65 (2.56)	56 (2.20)	35 (1.38)
Tightening torque N·m (kg·m, ft·lb)	75 (7.7, 55)		55 (5.6, 41)	47 (4.8, 35)




- Align the positions of tightening bolts for drive plate with those of the torque converter, and temporarily tighten the bolts. Then, tighten the bolts with the specified torque.

 : 5.1 N·m (5.2 kg·m, 38 ft·lb)

CAUTION:

- When turning crankshaft, turn it clockwise as viewed from the front of the engine.
- When tightening the tightening bolts for the torque converter after fixing the crankshaft pulley bolts, be sure to confirm the tightening torque of the crankshaft pulley mounting bolts.
- After converter is installed to drive plate, rotate crankshaft several turns and check to be sure that transmission rotates freely without binding.
- Install crankshaft position sensor (POS). Refer to [EM-27, "Removal and Installation"](#).
- After completing installation, check fluid leakage, fluid level, and the A/T positions of A/T. Refer to [AT-10, "Checking A/T Fluid"](#), [AT-201, "Adjustment of A/T Position"](#), [AT-201, "Checking of A/T Position"](#).



SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

General Specifications

ACS0000I

Applied model	VQ35DE engine	
Automatic transmission model	RE5R05A	
Transmission model code number	92X01	
Stall torque ratio	2.0: 1	
Transmission gear ratio	1st	3.540
	2nd	2.264
	3rd	1.471
	4th	1.000
	5th	0.834
	Reverse	2.370
Recommended fluid	Genuine Nissan Matic J ATF*1	
Fluid capacity	10.3 liter (10-7/8 US qt, 9-1/8 Imp qt)	

CAUTION:

- Use only Genuine Nissan Matic J ATF. Do not mix with other fluid.
- Using automatic transmission fluid other than Genuine Nissan Matic J ATF will deteriorate in driveability and automatic transmission durability, and may damage the automatic transmission, which is not covered by the warranty.

*1: Refer to [MA-12, "Fluids and Lubricants"](#) .

Vehicle Speed When Shifting Gears

ACS0000J

Throttle position	Vehicle speed km/h (MPH)							
	D1 →D2	D2 →D3	D3 →D4	D4 →D5	D5 →D4	D4 →D3	D3 →D2	D2 →D1
Full throttle	58 - 62 (36 - 39)	90 - 98 (56 - 61)	140 - 150 (87 - 93)	201 - 211 (125 - 131)	197 - 207 (122 - 129)	122 - 132 (76 - 82)	74 - 82 (46 - 51)	34 - 38 (23 - 25)
Half throttle	46 - 50 (29 - 31)	71 - 79 (44 - 49)	107 - 117 (66 - 73)	135 - 145 (84 - 90)	88 - 98 (55 - 61)	63 - 73 (39 - 45)	29 - 37 (18 - 23)	11 - 15 (7 - 9)

- At half throttle, the accelerator opening is 4/8 of the full opening.

Vehicle Speed When Performing and Releasing Complete Lock-up

ACS0000K

Throttle position	Vehicle speed km/h (MPH)	
	Lock-up "ON"	Lock-up "OFF"
Closed throttle	56 - 64 (35 - 40)	53 - 61 (33 - 38)
Half throttle	168 - 176 (104 - 109)	131 - 139 (81 - 86)

- At closed throttle, the accelerator opening is less than 1/8 condition.
- At half throttle, the accelerator opening is 4/8 of the full opening.

Vehicle Speed When Performing and Releasing Slip Lock-up

ACS0000L

Throttle position	Gear position	Vehicle speed km/h (MPH)	
		Slip lock-up "ON"	Slip lock-up "OFF"
Closed throttle	4th	37 - 45 (23 - 28)	34 - 42 (21 - 26)
	5th	44 - 52 (27 - 32)	41 - 49 (25 - 30)

- At closed throttle, the accelerator opening is less than 1/8 condition.

Stall Speed

ACS0000M

Stall speed	2,650 - 2,950 rpm
-------------	-------------------

SERVICE DATA AND SPECIFICATIONS (SDS)

Line Pressure

ACS0000N

Engine speed	Line pressure [kPa (kg/cm ² , psi)]	
	R position	D, M positions
At idle speed	392 - 441 (4.0 - 4.5, 57 - 64)	373 - 422 (3.8 - 4.3, 54 - 61)
At stall speed	1,700 - 1,890 (17.3 - 19.3, 247 - 274)	1,310 - 1,500 (13.3 - 15.3, 190 - 218)