

SECTION **IDX**  
ALPHABETICAL INDEX

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L

# ALPHABETICAL INDEX

## Numerics

3METER - Wiring diagram ..... [DI-36](#)

## A

A/C component layout ..... [ATC-23](#)  
A/C compressor mounting ..... [ATC-131](#)  
A/C compressor precaution ..... [ATC-11](#)  
A/C compressor special service tool ..... [ATC-15](#)  
A/C controller ..... [ATC-108](#)  
A/C diagnostic work flow (auto A/C) ..... [ATC-97](#)  
A/C evaporator ..... [ATC-144](#)  
A/C HFC134a (R134a) system precaution ..... [ATC-5](#)  
A/C HFC134a (R134a) system service procedure ..... [ATC-129](#)  
A/C HFC134a (R134a) system service tools ... [ATC-16](#)  
A/C HFC134a system service equipment precaution ... [ATC-12](#)  
A/C lubricant (R134a) ..... [ATC-24](#)  
A/C lubrication oil ..... [ATC-150](#)  
A/C operational check ..... [ATC-57](#)  
A/C self-diagnoses (auto A/C) ..... [ATC-49](#), [ATC-97](#)  
A/C service data specification ..... [ATC-150](#)  
A/C trouble diagnoses (auto A/C) ..... [ATC-36](#)  
A/C, A - Wiring diagram ..... [ATC-42](#)  
A/T - Wiring diagram ..... [AT-49](#)  
A/T fluid checking ..... [AT-10](#), [AT-55](#), [MA-22](#)  
A/T fluid replacement ..... [AT-10](#), [MA-24](#)  
A/T fluid temperature sensor ..... [AT-115](#)  
A/T IND - Wiring diagram ..... [DI-77](#)  
A/T self-diagnoses ..... [AT-86](#)  
A/T shift lock system ..... [AT-203](#)  
A/T shift lock system - Wiring diagram ..... [AT-204](#)  
A/T trouble diagnoses ..... [AT-39](#)  
Accelerator control system ..... [ACC-3](#)  
Accelerator pedal position (APP) sensor ..... [EC-588](#), [EC-596](#), [EC-612](#)  
Accelerator pedal released position learning ..... [EC-42](#)  
AF1B1-Wiring diagram ..... [EC-465](#), [EC-473](#), [EC-481](#), [EC-490](#), [EC-500](#), [EC-509](#), [EC-521](#)  
AF1B2-Wiring diagram ..... [EC-467](#), [EC-475](#), [EC-483](#), [EC-492](#), [EC-502](#), [EC-511](#), [EC-523](#)  
AF1HB1-Wiring diagram ..... [EC-380](#)  
AF1HB2-Wiring diagram ..... [EC-382](#)  
Air bag ..... [SRS-3](#)  
Air bag disposal ..... [SRS-54](#)  
Air bag precautions ..... [SRS-3](#)  
Air bleeding (hydraulic clutch) ..... [CL-7](#)  
Air bleeding for brake system ..... [BR-10](#)  
Air cleaner and air duct ..... [EM-14](#)  
Air cleaner filter replacement ..... [MA-18](#)  
Air conditioner cut control ..... [EC-28](#)  
Air flow meter - See Mass air flow sensor ..... [EC-154](#), [EC-163](#)  
Air fuel ratio sensor 1 ..... [EC-463](#), [EC-471](#), [EC-479](#), [EC-488](#), [EC-497](#), [EC-506](#), [EC-518](#)  
Air fuel ratio sensor 1 heater ..... [EC-379](#)  
Air mix. door motor ..... [ATC-68](#), [ATC-123](#)

Air spoiler, rear ..... [EI-30](#)  
Ambient sensor ..... [ATC-98](#), [ATC-110](#)  
Angular tightening application ..... [EM-3](#)  
Antenna ..... [AV-45](#)  
APPS1 - Wiring diagram ..... [EC-590](#)  
APPS2 - Wiring diagram ..... [EC-598](#)  
APPS3 - Wiring diagram ..... [EC-614](#)  
ASC/BS - Wiring diagram ..... [EC-557](#)  
ASC/SW - Wiring diagram ..... [EC-549](#)  
ASCBOF - Wiring diagram ..... [EC-654](#)  
ASCD ..... [EC-688](#)  
ASCD (automatic speed control device) ..... [ACS-2](#)  
ASCIND - Wiring diagram ..... [EC-670](#)  
Ashtray illumination ..... [LT-211](#)  
AT indicator lamp ..... [DI-77](#)  
Audio ..... [AV-6](#)  
AUDIO - Wiring diagram ..... [AV-11](#)  
Auto air conditioner - Wiring diagram ..... [ATC-42](#)  
Auto amp ..... [ATC-109](#)  
Auto anti-dazzling inside mirror ..... [GW-54](#)  
Automatic amplifier ..... [ATC-59](#), [ATC-109](#)  
Axle ..... [MA-29](#)  
Axle housing (rear) ..... [RAX-8](#)

## B

Back Door ..... [BL-105](#), [BL-106](#)  
Back door ..... [BL-105](#), [BL-106](#)  
Back door opener - See Back door ..... [BL-110](#)  
BACK/L - Wiring diagram ..... [LT-180](#)  
Back-up lamp ..... [LT-180](#)  
Back-up lamp switch (M/T) ..... [MT-12](#)  
Battery ..... [SC-4](#)  
Battery/Starting/Charging System Tester [SC-6](#), [SC-15](#), [SC-23](#)  
BCM (Body control module) ..... [BCS-3](#)  
Blower motor ..... [ATC-75](#), [ATC-116](#)  
Blower unit ..... [ATC-114](#)  
Bose speaker amp. .... [AV-6](#), [AV-7](#)  
Brake booster ..... [BR-22](#)  
Brake fluid change ..... [BR-9](#)  
Brake fluid level ..... [MA-27](#)  
Brake fluid level and line check ..... [BR-9](#)  
Brake hydraulic line ..... [BR-11](#)  
Brake inspection ..... [MA-27](#)  
Brake lines and cables inspection ..... [MA-27](#)  
Brake master cylinder ..... [BR-14](#)  
Brake pedal ..... [BR-6](#)  
Brake switch ..... [EC-582](#)  
BRK/SW - Wiring diagram ..... [EC-583](#)  
Bulb specifications ..... [LT-249](#)  
Bumper, front ..... [EI-14](#)  
Bumper, rear ..... [EI-17](#)

## C

Camshaft ..... [EM-76](#)  
Camshaft inspection ..... [EM-78](#)  
Camshaft position sensor (PHASE) ..... [EC-275](#)

# ALPHABETICAL INDEX

CAN - Wiring diagram ..... [EC-140](#), [LAN-13](#), [LAN-40](#),  
[LAN-64](#), [LAN-88](#)  
CAN (Controller Area Network) ..... [LAN-5](#), [LAN-12](#),  
[LAN-39](#), [LAN-63](#), [LAN-87](#)  
CAN communication ... [EC-29](#), [EC-139](#), [AT-28](#), [AT-88](#),  
[WT-11](#), [LT-9](#), [LT-41](#), [LT-147](#), [LT-187](#), [LT-238](#), [WW-10](#),  
[LAN-5](#), [LAN-12](#), [LAN-39](#), [LAN-63](#), [LAN-87](#)  
Canister-See EVAP canister ..... [EC-677](#)  
CHARGE - Wiring diagram ..... [SC-22](#)  
Charging system ..... [SC-21](#)  
Chassis and body maintenance ..... [MA-22](#)  
CHIME - Wiring diagram ..... [DI-84](#)  
Circuit breaker ..... [PG-16](#)  
Clock ..... [DI-99](#)  
CLOCK - Wiring diagram ..... [DI-99](#)  
Closed loop control ..... [EC-26](#)  
Clutch cover ..... [CL-15](#)  
Clutch disc ..... [CL-15](#)  
Clutch master cylinder ..... [CL-8](#)  
Clutch operating cylinder ..... [CL-11](#)  
Clutch pedal ..... [CL-5](#)  
Clutch release bearing ..... [CL-13](#)  
Clutch release mechanism ..... [CL-13](#)  
Clutch withdrawal lever ..... [CL-13](#)  
Coil spring (front) ..... [FSU-10](#)  
Collision diagnosis ..... [SRS-61](#)  
Combination lamp, front, removal and installation .....  
[LT-66](#), [LT-141](#)  
Combination lamp, rear, removal and installation .....  
[LT-207](#)  
Combination meter ..... [DI-4](#)  
Combination meter removal and installation - See  
Instrument panel ..... [IP-11](#)  
Combination switch ..... [LT-168](#)  
Component Location (auto A/C) ..... [ATC-39](#)  
Compression pressure ..... [EM-92](#)  
Compressor special service tool ..... [ATC-15](#)  
Condenser ... [ATC-139](#), [ATC-142](#), [ATC-143](#), [ATC-144](#),  
[ATC-145](#)  
Console box - See Instrument panel ..... [IP-10](#)  
CONSULT for VDC ..... [BRC-111](#)  
Control units (terminal arrangement) ..... [PG-82](#)  
Control valve (A/T) ..... [AT-33](#)  
Controller Area Network (CAN) ..... [LAN-5](#), [LAN-12](#),  
[LAN-39](#), [LAN-63](#), [LAN-87](#)  
Converter housing installation ..... [AT-214](#)  
COOL/F - Wiring diagram ..... [EC-445](#)  
Cooling circuit (engine) ..... [CO-7](#)  
Cooling fan ..... [CO-19](#)  
Cooling fan motor ..... [EC-453](#)  
Cowl top ..... [EI-20](#)  
Cowl top cover ..... [EI-20](#)  
Crankcase ventilation system - See Positive crankcase  
ventilation ..... [EC-686](#)  
Crankshaft position sensor (POS) ..... [EC-268](#)  
Crash zone sensor ..... [SRS-50](#)  
Cylinder head ..... [EM-92](#)

## D

D/LOCK - Wiring diagram ..... [BL-26](#)  
Daytime light system ..... [LT-69](#), [LT-106](#)  
Daytime running light - See Daytime light system .....  
[LT-69](#), [LT-106](#)  
DEF - Wiring diagram ..... [GW-60](#), [GW-64](#)  
Diagnosis sensor unit ..... [SRS-53](#)  
Diagnostic trouble code (DTC) for OBD system .. [EC-8](#)  
Differential carrier assembly ..... [RFD-12](#)  
Differential carrier disassembly ..... [RFD-16](#)  
Differential gear oil replacement ..... [MA-25](#)  
Direct clutch solenoid valve ..... [AT-141](#), [AT-144](#)  
Display and amp.assembly ..... [ATC-59](#)  
Door glass ..... [GW-51](#)  
Door glass Fitting Adjustment(Front) ..... [GW-53](#)  
Door lock ..... [BL-103](#)  
Door mirror ..... [GW-83](#)  
Door trim ..... [EI-33](#)  
Door, front ..... [BL-97](#), [BL-98](#), [GW-51](#)  
Drive belt ..... [EM-12](#)  
Drive pinion diff. inspection ..... [RFD-15](#)  
Drive pinion height ..... [RFD-21](#), [RFD-24](#)  
Drive shaft (rear) ..... [RAX-10](#)  
Driver air bag ..... [SRS-41](#)  
DTRL - Wiring diagram ..... [LT-74](#), [LT-111](#)  
Duct and grilles ..... [ATC-125](#)

## E

ECM power supply ..... [EC-130](#), [EC-386](#)  
ECM/PW - Wiring diagram ..... [EC-387](#)  
ECTS - Wiring diagram ..... [EC-179](#)  
Electric throttle control actuator ..... [EC-397](#), [EC-399](#)  
Electrical load signal circuit ..... [EC-652](#)  
Electrical unit ..... [PG-82](#)  
Electrical units location ..... [PG-74](#)  
Electronic ignition (EI) system ..... [EC-27](#)  
Engine control module (ECM) ..... [EC-376](#)  
Engine control system diagram and chart ..... [EC-22](#)  
Engine coolant ..... [CO-9](#)  
Engine coolant temperature sensor (ECTS) ... [EC-177](#),  
[EC-191](#)  
Engine oil ..... [LU-6](#)  
Engine oil filter replacement ..... [MA-19](#)  
Engine oil precautions ..... [GI-7](#)  
Engine removal ..... [EM-105](#)  
ETC1 - Wiring diagram ..... [EC-400](#)  
ETC2 - Wiring diagram ..... [EC-408](#)  
ETC3 - Wiring diagram ..... [EC-412](#)  
EVAP canister ..... [EC-677](#)  
EVAP canister purge volume control solenoid valve ....  
[EC-302](#), [EC-530](#)  
EVAP canister vent control valve ..... [EC-309](#), [EC-538](#)  
EVAP control system (small leak) diagnosis .. [EC-293](#),  
[EC-340](#)  
EVAP control system pressure sensor ..... [EC-318](#),  
[EC-321](#), [EC-330](#)  
EVAP control system purge flow monitoring diagnosis

# ALPHABETICAL INDEX

## EC-288

EVAP vapor lines inspection .....	<a href="#">MA-21</a>
Evaporative emission (EVAP) system .....	<a href="#">EC-674</a>
Evaporator .....	<a href="#">ATC-144</a>
Exhaust manifold .....	<a href="#">EM-23</a>
Exhaust system .....	<a href="#">EX-3</a>
Exhaust system inspection .....	<a href="#">EX-3</a> , <a href="#">MA-22</a>
Expansion valve .....	<a href="#">ATC-145</a>

## F

F/LID - Wiring diagram .....	<a href="#">BL-54</a>
F/PUMP - Wiring diagram .....	<a href="#">EC-640</a>
Final drive disassembly .....	<a href="#">RFD-16</a>
Final drive pre-inspection .....	<a href="#">RFD-15</a>
Final drive removal and installation .....	<a href="#">RFD-10</a>
Floor trim .....	<a href="#">EI-43</a>
Flow charts .....	<a href="#">GI-27</a>
Fluid temperature sensor (A/T) .....	<a href="#">AT-115</a>
Fluorescent leak detector .....	<a href="#">ATC-146</a>
Flywheel (clutch) .....	<a href="#">CL-15</a>
Flywheel runout(QR) .....	<a href="#">EM-139</a>
Front axle .....	<a href="#">FAX-4</a>
Front brake solenoid valve .....	<a href="#">AT-135</a> , <a href="#">AT-138</a>
Front bumper .....	<a href="#">EI-14</a>
Front combination lamp removal and installation .....	<a href="#">LT-66</a> , <a href="#">LT-141</a>
Front door .....	<a href="#">BL-97</a> , <a href="#">BL-98</a> , <a href="#">GW-51</a>
Front passenger air bag .....	<a href="#">SRS-45</a>
Front seat belt .....	<a href="#">SB-4</a>
Front seat belt pre-tensioner ....	<a href="#">SB-2</a> , <a href="#">SRS-3</a> , <a href="#">SRS-52</a>
Front side air bag .....	<a href="#">SRS-46</a>
Front suspension .....	<a href="#">FSU-5</a>
Front washer .....	<a href="#">WW-4</a>
Front wiper .....	<a href="#">WW-4</a>
FTTS - Wiring diagram .....	<a href="#">EC-239</a> , <a href="#">EC-244</a>
Fuel cut control (at no load high engine speed) .	<a href="#">EC-28</a>
Fuel filter replacement .....	<a href="#">FL-4</a>
Fuel gauge .....	<a href="#">DI-4</a>
Fuel level sensor .....	<a href="#">EC-358</a> , <a href="#">EC-360</a> , <a href="#">EC-362</a>
Fuel lid opener, electric .....	<a href="#">BL-53</a>
Fuel line inspection .....	<a href="#">FL-3</a> , <a href="#">MA-17</a>
Fuel precautions .....	<a href="#">GI-5</a>
Fuel pressure check .....	<a href="#">EC-45</a>
Fuel pressure release .....	<a href="#">EC-45</a>
Fuel pump .....	<a href="#">EC-639</a>
Fuel pump and gauge .....	<a href="#">FL-4</a>
Fuel system .....	<a href="#">FL-3</a>
Fuel tank .....	<a href="#">FL-10</a>
Fuel tank temperature sensor .....	<a href="#">EC-237</a> , <a href="#">EC-243</a>
Fuel tank vacuum relief valve .....	<a href="#">EC-677</a>
FUELB1 - Wiring diagram .....	<a href="#">EC-222</a> , <a href="#">EC-231</a>
FUELB2 - Wiring diagram .....	<a href="#">EC-223</a> , <a href="#">EC-232</a>
Fuse .....	<a href="#">PG-16</a>
Fuse and fusible link box .....	<a href="#">PG-89</a>
Fusible link .....	<a href="#">PG-16</a>

## G

Gauges .....	<a href="#">DI-4</a>
Glass .....	<a href="#">GW-11</a> , <a href="#">GW-51</a>
GPS antenna .....	<a href="#">AV-50</a>
Ground distribution .....	<a href="#">PG-31</a>

## H

H/LAMP - Wiring diagram .....	<a href="#">LT-11</a> , <a href="#">LT-43</a>
Harness connector .....	<a href="#">PG-80</a>
Harness layout .....	<a href="#">PG-47</a>
Hazard warning lamp .....	<a href="#">LT-144</a>
Headlamp .....	<a href="#">LT-7</a> , <a href="#">LT-39</a>
Headlamp removal and installation .....	<a href="#">LT-66</a> , <a href="#">LT-141</a>
Headlining - See Roof trim .....	<a href="#">EI-44</a> , <a href="#">EI-45</a>
Heated oxygen sensor 2 (bank 1) ....	<a href="#">EC-200</a> , <a href="#">EC-209</a> , <a href="#">EC-416</a> , <a href="#">EC-427</a>
Heated oxygen sensor 2 (bank 2) ....	<a href="#">EC-200</a> , <a href="#">EC-209</a> , <a href="#">EC-416</a> , <a href="#">EC-427</a>
Heated oxygen sensor 2 heater (bank 1) .....	<a href="#">EC-145</a>
Heated oxygen sensor 2 heater (bank 2) .....	<a href="#">EC-145</a>
Heated seat .....	<a href="#">SE-57</a>
Heater and cooling unit (Heater core) .....	<a href="#">ATC-118</a>
HFC134a (R134a) system precaution .....	<a href="#">ATC-5</a>
HFC134a (R134a) system service procedure .....	<a href="#">ATC-129</a>
HFC134a (R134a) system service tools .....	<a href="#">ATC-16</a>
HFC134a system service equipment precaution .....	<a href="#">ATC-12</a>
High & low reverse clutch solenoid valve .....	<a href="#">AT-147</a> , <a href="#">AT-150</a>
Hood .....	<a href="#">BL-13</a>
Hood lock system .....	<a href="#">BL-16</a>
Horn .....	<a href="#">WW-55</a>
HORN - Wiring diagram .....	<a href="#">WW-55</a>

## I

IATS - Wiring diagram .....	<a href="#">EC-173</a>
Idle air volume learning .....	<a href="#">EC-43</a>
Idle mixture ratio .....	<a href="#">EC-31</a>
Idle speed .....	<a href="#">EC-31</a>
Idle speed control (ISC) .....	<a href="#">EC-366</a> , <a href="#">EC-368</a>
Ignition coil .....	<a href="#">EM-33</a> , <a href="#">EC-621</a>
Ignition control system .....	<a href="#">EC-621</a>
Ignition timing .....	<a href="#">EC-31</a>
IGNSYS - Wiring diagram .....	<a href="#">EC-622</a>
ILL - Wiring diagram .....	<a href="#">LT-240</a>
Illumination .....	<a href="#">LT-237</a>
In vehicle sensor .....	<a href="#">ATC-100</a> , <a href="#">ATC-111</a>
INJECT - Wiring diagram .....	<a href="#">EC-634</a>
Injector .....	<a href="#">EC-633</a>
Input clutch solenoid valve .....	<a href="#">AT-129</a> , <a href="#">AT-132</a>
Instrument panel .....	<a href="#">IP-10</a>
Intake air temperature sensor .....	<a href="#">EC-171</a> , <a href="#">EC-195</a>
Intake door control linkage adjustment .....	<a href="#">ATC-74</a>
Intake door motor .....	<a href="#">ATC-72</a> , <a href="#">ATC-117</a>
Intake manifold .....	<a href="#">EM-21</a>
Intake manifold collector .....	<a href="#">EM-16</a>

# ALPHABETICAL INDEX

Intake sensor ..... [ATC-106](#), [ATC-113](#)  
 Intake valve timing control (Bank 1) ..... [EC-142](#)  
 Intake valve timing control (Bank 2) ..... [EC-142](#)  
 Intake valve timing control solenoid valve (Bank 1) .....  
[EC-390](#)  
 Intake valve timing control solenoid valve (Bank 2) .....  
[EC-390](#)  
 Integrated homelink transmitter ..... [BL-174](#)  
 Interior ..... [EI-35](#)  
 Interior lamp ..... [LT-212](#)  
 IPDM (Intelligent power distribution module engine  
 room) ..... [PG-17](#)  
 IVCB1 - Wiring diagram ..... [EC-391](#)  
 IVCB2 - Wiring diagram ..... [EC-393](#)  
 IVIS (Infiniti vehicle immobilizer system) precautions ...  
[GI-3](#)

## K

KEYLES - Wiring diagram ..... [BL-67](#)  
 Knock sensor (KS) ..... [EC-263](#)  
 KS - Wiring diagram ..... [EC-264](#)

## L

LAN system circuit ..... [ATC-61](#)  
 License lamp ..... [LT-185](#)  
 Line pressure solenoid valve ..... [AT-108](#)  
 Line pressure test (A/T) ..... [AT-57](#)  
 Liquid gasket application ..... [LU-2](#), [CO-2](#)  
 Location of electrical units ..... [PG-74](#)  
 Lock, door ..... [BL-103](#)  
 Low coast brake solenoid valve ..... [AT-153](#), [AT-156](#)  
 Low tire pressure warning system ..... [WT-9](#)  
 Lubricant (R134a) A/C ..... [ATC-6](#), [ATC-24](#)  
 Lubrication circuit (engine) ..... [LU-4](#)  
 Lubrication oil A/C ..... [ATC-150](#)

## M

M/ANT - Wiring diagram ..... [AV-46](#)  
 M/T major overhaul ..... [MT-27](#)  
 M/T oil replacement ..... [MT-10](#)  
 M/T removal and installation ..... [MT-19](#)  
 MAFS - Wiring diagram ..... [EC-157](#), [EC-165](#)  
 Magnet clutch ..... [ATC-80](#)  
 MAIN - Wiring diagram ..... [EC-130](#)  
 Maintenance (engine) ..... [MA-14](#)  
 Manual transmission oil replacement ..... [MA-22](#)  
 Mass air flow sensor (MAFS) ..... [EC-154](#), [EC-163](#)  
 Master cylinder (clutch) ..... [CL-8](#)  
 Meter ..... [DI-4](#)  
 METER - Wiring diagram ..... [DI-9](#)  
 MIL data link connectors circuit ..... [EC-672](#)  
 MIL/DL - Wiring diagram ..... [EC-672](#)  
 MIRROR - Wiring diagram ..... [GW-82](#)  
 Mirror, door ..... [GW-83](#)  
 Mirror, out side ..... [GW-83](#)  
 Misfire ..... [EC-256](#)

Mode door control linkage adjustment ..... [ATC-67](#)  
 Mode door motor ..... [ATC-65](#), [ATC-122](#)  
 Molding - See Exterior ..... [EI-22](#), [EI-26](#)  
 Multiport fuel injection (MFI) system ..... [EC-25](#)  
 Multiport fuel injection precautions ..... [GI-6](#)

## N

NATS - Wiring diagram ..... [BL-158](#)  
 NAVI - Wiring diagram ..... [AV-64](#)  
 Navigation system ..... [AV-49](#)  
 NVH troubleshooting (BR) ..... [BR-5](#)  
 NVIS (Nissan vehicle immobilizer system) ..... [BL-155](#)  
 NVIS (Nissan vehicle immobilizer system) precautions  
[GI-3](#)

## O

O2H2B1 - Wiring diagram ..... [EC-147](#)  
 O2H2B2 - Wiring diagram ..... [EC-149](#)  
 O2S2B1 - Wiring diagram .. [EC-202](#), [EC-212](#), [EC-419](#),  
[EC-430](#)  
 O2S2B2 - Wiring diagram .. [EC-204](#), [EC-214](#), [EC-421](#),  
[EC-432](#)  
 Oil cooler (engine) ..... [LU-10](#)  
 Oil filter ..... [LU-9](#)  
 Oil pan (engine) ..... [EM-27](#)  
 Oil pressure (engine) ..... [LU-7](#)  
 Oil pump (engine) ..... [LU-12](#)  
 Oil pump regulator valve (engine) ..... [LU-12](#)  
 Oil seal replacement (front of final drive) ..... [RFD-6](#)  
 Oil seal replacement (side of final drive) ..... [RFD-8](#)  
 Operating cylinder (clutch) ..... [CL-11](#)  
 ORVR (On-board Refueling Vapor Recovery) . [EC-681](#)  
 Out side mirror ..... [GW-83](#)  
 Overheat ..... [EC-441](#)

## P

P/SCKT - Wiring diagram ..... [WW-53](#)  
 Park/Neutral position switch ..... [EC-574](#)  
 Park/neutral position switch (A/T) ..... [AT-94](#)  
 Parking brake control ..... [PB-3](#)  
 Parking lamp ..... [LT-185](#)  
 PCV (positive crankcase ventilation) ..... [EC-686](#)  
 PGC/V - Wiring diagram ..... [EC-304](#), [EC-532](#)  
 PHSB1 - Wiring diagram ..... [EC-276](#)  
 PHSB2 - Wiring diagram ..... [EC-278](#)  
 Pinion bearing preload diff. .... [RFD-30](#)  
 Pinion gear height diff. .... [RFD-24](#)  
 PNP/SW - Wiring diagram ..... [EC-576](#)  
 POS - Wiring diagram ..... [EC-269](#)  
 POWER - Wiring diagram ..... [PG-5](#)  
 Power door lock ..... [BL-21](#)  
 Power socket ..... [WW-53](#)  
 Power steering fluid level ..... [PS-6](#), [MA-29](#)  
 Power steering gear ..... [PS-17](#)  
 Power steering oil pump ..... [PS-29](#)  
 Power steering system bleeding ..... [PS-6](#)



# ALPHABETICAL INDEX

Power supply routing .....	<a href="#">PG-4</a>
Power window .....	<a href="#">GW-18</a>
PRE/SE - Wiring diagram .....	<a href="#">EC-323</a> , <a href="#">EC-332</a>
Precautions for Leak detection dye .....	<a href="#">ATC-14</a>
Precautions (General) .....	<a href="#">GI-4</a>
Pressure plate - See Clutch cover .....	<a href="#">CL-15</a>
Pressure switch 1 .....	<a href="#">AT-138</a> , <a href="#">AT-163</a>
Pressure switch 2 .....	<a href="#">AT-156</a>
Pressure switch 3 .....	<a href="#">AT-132</a> , <a href="#">AT-166</a>
Pressure switch 5 .....	<a href="#">AT-144</a> , <a href="#">AT-169</a>
Pressure switch 6 .....	<a href="#">AT-150</a> , <a href="#">AT-172</a>
Pressure test (A/T) .....	<a href="#">AT-57</a>
Propeller shaft .....	<a href="#">PR-5</a>
Propeller shaft inspection .....	<a href="#">MA-24</a>
Propeller shaft on vehicle service .....	<a href="#">PR-5</a>
Propeller shaft vibration .....	<a href="#">PR-5</a>
PS/SEN - Wiring diagram .....	<a href="#">EC-371</a>

## R

Radiator .....	<a href="#">CO-12</a>
Radio - See Audio .....	<a href="#">AV-6</a>
Rear axle .....	<a href="#">RAX-6</a>
Rear bumper .....	<a href="#">EI-17</a>
Rear combination lamp removal and installation .....	<a href="#">LT-207</a>
Rear cover packing replacement diff. ....	<a href="#">RFD-31</a>
Rear suspension .....	<a href="#">RSU-5</a>
Rear washer .....	<a href="#">WW-38</a>
Rear window defogger .....	<a href="#">GW-56</a>
Rear wiper .....	<a href="#">WW-38</a>
Refrigerant connection precaution .....	<a href="#">ATC-6</a>
Refrigerant discharging evacuating charging .....	<a href="#">ATC-129</a>
Refrigerant general precaution .....	<a href="#">ATC-6</a>
Refrigerant lines .....	<a href="#">ATC-129</a>
Refrigerant pressure sensor .....	<a href="#">EC-646</a> , <a href="#">ATC-85</a> , <a href="#">ATC-143</a>
Refrigeration cycle .....	<a href="#">ATC-19</a>
Release bearing (clutch) .....	<a href="#">CL-13</a>
Remote keyless entry system .....	<a href="#">BL-61</a>
Removal and installation (A/T) .....	<a href="#">AT-212</a>
Reverse lamp switch (M/T) - See Back-up lamp switch (M/T) .....	<a href="#">MT-12</a>
Revolution sensor (A/T) .....	<a href="#">AT-97</a>
Ring gear diff. inspection .....	<a href="#">RFD-15</a>
Rocker cover .....	<a href="#">EM-42</a>
Room lamp - See Interior lamp .....	<a href="#">LT-212</a>
ROOM/L - Wiring diagram .....	<a href="#">LT-216</a>
RP/SEN - Wiring diagram .....	<a href="#">EC-647</a>

## S

SEAT - Wiring diagram .....	<a href="#">SE-12</a>
Seat belt inspection .....	<a href="#">SB-8</a>
Seat belt pre-tensioner disposal .....	<a href="#">SRS-54</a>
Seat belt, front .....	<a href="#">SB-4</a>
SEN/PW - Wiring diagram .....	<a href="#">EC-459</a>
SHIFT - Wiring diagram .....	<a href="#">AT-204</a>
Shift lock system .....	<a href="#">AT-203</a>

Shift schedule .....	<a href="#">AT-215</a>
Shock absorber (front) .....	<a href="#">FSU-10</a>
Shock absorber (rear) .....	<a href="#">RSU-9</a>
Side air bag (satellite) sensor .....	<a href="#">SRS-51</a>
Side bearing preload diff. ....	<a href="#">RFD-23</a>
Side flange installation diff. ....	<a href="#">RFD-9</a>
Side trim .....	<a href="#">EI-35</a>
SMJ (super multiple junction) .....	<a href="#">PG-84</a>
Spark plug .....	<a href="#">EM-34</a>
Spark plug replacement .....	<a href="#">MA-20</a>
Specification value .....	<a href="#">EC-125</a>
Speedometer .....	<a href="#">DI-4</a>
Spiral cable .....	<a href="#">SRS-43</a>
SRS - See Supplemental Restraint System ....	<a href="#">SRS-6</a>
SRS - Wiring diagram .....	<a href="#">SRS-12</a>
SRS Trouble diagnoses .....	<a href="#">SRS-8</a>
Stabilizer bar (rear) .....	<a href="#">RSU-16</a>
Stall test (A/T) .....	<a href="#">AT-56</a>
Standardized relay .....	<a href="#">PG-86</a>
START - Wiring diagram .....	<a href="#">SC-12</a>
Starter .....	<a href="#">SC-10</a>
Starting system .....	<a href="#">SC-10</a>
Steering gear and linkage inspection .....	<a href="#">MA-28</a>
Steering linkage .....	<a href="#">PS-17</a>
Steering wheel and column .....	<a href="#">PS-8</a> , <a href="#">PS-10</a>
Steering wheel turning force .....	<a href="#">PS-8</a>
Stop lamp .....	<a href="#">LT-174</a>
Stop lamp switch .....	<a href="#">EC-582</a>
STOP/L - Wiring diagram .....	<a href="#">LT-176</a>
Sunload sensor .....	<a href="#">ATC-103</a> , <a href="#">ATC-112</a>
Supplemental Restraint System .....	<a href="#">SRS-6</a>
Supplemental restraint system - Wiring diagram .....	<a href="#">SRS-12</a>
Suspension .....	<a href="#">MA-29</a>
Symbols and abbreviations .....	<a href="#">GI-10</a> , <a href="#">GI-23</a>

## T

Tachometer .....	<a href="#">DI-4</a>
Tail lamp .....	<a href="#">LT-185</a>
TAIL/L - Wiring diagram .....	<a href="#">LT-189</a>
TCM circuit diagram .....	<a href="#">AT-48</a>
TCM inspection table .....	<a href="#">AT-74</a>
Three way catalyst .....	<a href="#">EM-23</a>
Three way catalyst function (Bank 1) .....	<a href="#">EC-284</a>
Three way catalyst function (Bank 2) .....	<a href="#">EC-284</a>
Three way catalyst precautions .....	<a href="#">GI-5</a>
Throttle body .....	<a href="#">EM-20</a>
Throttle control motor .....	<a href="#">EC-411</a>
Throttle control motor relay .....	<a href="#">EC-406</a>
Throttle position sensor (TPS) .....	<a href="#">EC-183</a> , <a href="#">EC-248</a> , <a href="#">EC-454</a> , <a href="#">EC-456</a> , <a href="#">EC-604</a>
Throwout bearing - See Clutch release bearing .....	<a href="#">CL-13</a>
Thrust washer selection diff. ....	<a href="#">RFD-22</a>
Tie-rod .....	<a href="#">PS-17</a>
Timing chain .....	<a href="#">EM-55</a>
Tire rotation .....	<a href="#">WT-8</a> , <a href="#">MA-27</a>
Tooth contact diff. ....	<a href="#">RFD-27</a>
Torque converter installation .....	<a href="#">AT-213</a> , <a href="#">AT-214</a>

# ALPHABETICAL INDEX

Torque convertor clutch solenoid valve	<a href="#">AT-102</a> , <a href="#">AT-105</a>	Window, door	<a href="#">GW-51</a>
TPS1 - Wiring diagram	<a href="#">EC-250</a>	Windshield	<a href="#">GW-11</a>
TPS2 - Wiring diagram	<a href="#">EC-185</a>	WIP/R - Wiring diagram	<a href="#">WW-40</a>
TPS3 - Wiring diagram	<a href="#">EC-606</a>	WIPER - Wiring diagram	<a href="#">WW-12</a>
Transverse link (front)	<a href="#">FSU-13</a>	Wiper, front	<a href="#">WW-4</a>
Triple meter	<a href="#">DI-31</a>	Wiper, rear	<a href="#">WW-38</a>
TRNSCV - Wiring diagram	<a href="#">BL-174</a>	Wiring Diagram (Cell code) list	<a href="#">PG-71</a>
Trouble diagnoses	<a href="#">GI-11</a>	Wiring diagrams	<a href="#">GI-15</a>
Trunk lid	<a href="#">BL-111</a>	Withdrawal lever (clutch)	<a href="#">CL-13</a>
Turbine revolution sensor	<a href="#">AT-118</a>	WT-T/WARN - Wiring diagram	<a href="#">WT-13</a>
TURN - Wiring diagram	<a href="#">LT-149</a>		
Turn signal lamp	<a href="#">LT-144</a>		
Tyre pressure monitoring system - trouble diagnoses ..	<a href="#">WT-12</a>		
Tyre pressure monitoring system - wiring diagram .....	<a href="#">WT-13</a>		

## U

Unified meter and A/C amp.	<a href="#">DI-55</a>
Upper link (front susp.)	<a href="#">FSU-14</a>

## V

Vacuum hose (brake system)	<a href="#">BR-24</a>
Vacuum hose drawing (Engine control)	<a href="#">EC-23</a>
Valve clearance	<a href="#">EM-84</a>
Valve guide	<a href="#">EM-100</a>
Valve lifter	<a href="#">EM-80</a>
Valve seat	<a href="#">EM-102</a>
Valve spring	<a href="#">EM-103</a>
Vanity mirror lamp	<a href="#">LT-208</a>
VDC -Wiring diagram	<a href="#">BRC-101</a>
Vehicle security (theft warning) system	<a href="#">BL-126</a>
Vehicle speed sensor (VSS)	<a href="#">EC-364</a>
VEHSEC - Wiring diagram	<a href="#">BL-131</a>
VENT/V - Wiring diagram	<a href="#">EC-311</a> , <a href="#">EC-540</a>
VIN registration	<a href="#">EC-42</a>

## W

WARN - Wiring diagram	<a href="#">DI-66</a>
Warning chime	<a href="#">DI-80</a>
Warning lamps	<a href="#">DI-65</a>
Washer, front	<a href="#">WW-4</a>
Washer, rear	<a href="#">WW-38</a>
Water pump	<a href="#">CO-21</a>
Water temperature gauge	<a href="#">DI-4</a>
Wheel alignment (front)	<a href="#">FSU-6</a>
Wheel alignment (rear)	<a href="#">RSU-5</a>
Wheel balance	<a href="#">WT-7</a> , <a href="#">MA-25</a>
Wheel bearing (front)	<a href="#">FAX-4</a>
Wheel bearing (rear)	<a href="#">RAX-6</a>
Wheel hub (front)	<a href="#">FAX-4</a>
Wheel hub (rear)	<a href="#">RAX-6</a>
Wheel sensor (VDC)	<a href="#">BRC-146</a>
Wheel sensors (ABS)	<a href="#">BRC-39</a>
Wheel sensors (TCS)	<a href="#">BRC-85</a>
WINDOW - Wiring diagram	<a href="#">GW-23</a>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L

IDX